
ASSEMBLY AND INSTALLATION INSTRUCTIONS


H0175

WARNING: TO AVOID RISK OF ELECTRICAL SHOCK, BE SURE TO SHUT OFF POWER BEFORE INSTALLING OR SERVICING THIS FIXTURE.

NOTES: 1. Before installing, consult local electrical codes for wiring and grounding requirements.
2. READ AND SAVE THESE INSTRUCTIONS.

Hardware Package (included):





Installation Steps

Turn off the power at fuse or circuit box

1. Attach the threaded pipe to the mounting strap, and then secure it with a washer and a hex nut.
2. Attach the mounting strap to the outlet box by using two mounting screws.
3. Secure the top loop to the threaded pipe.
4. Secure the loop to the set threaded pipe of the fixture body.
5. Connect the chain:
   - Determine length of chain needed to achieve desired fixture height. (To remove excess chain section, use pliers to bend link open.)
   - Weave the fixture wires and fixture grounding wire through the chain, collar and canopy.
6. Connect one end of the chain to the loop using a loop lock.
7. Connect the other end of the chain to top loop by using the other loop lock.
8. Thread the fixture wire and fixture grounding wire through the top loop, threaded pipe and mounting strap.

VAXCEL


161013

9.Pull out the source wires from the outlet box. Make wire connections using wire nuts as follows:
---Connect the smooth-coated wire (marked) from the fixture to the black wire from the power source.
---Connect the ribbed-coated wire (unmarked) from the fixture to the white wire from the power source.
---Attach the fixture grounding wire to the mounting strap with the green grounding screw, and then connect it to the house grounding wire with a wire nut.
Carefully put the wires back into the outlet box.
10. Attach the canopy to the mounting strap by inserting the top loop, and then secure it with the collar.
11. Attach the glass shade onto the socket and tighten it with the socket ring.
12. Install the bulbs (not included). Check relamping label at socket area or packaging for maximum allowed wattage.


Turn on the power at fuse or circuit box

The following parts are available for re-order if damaged or missing.


Spare Parts List:



Mounting Hardware
5619MM (1 SET)



Glass Shade
9844EW



A: 32”
B: 25-1/2"

VAXCEL

161013