SONDER

LIVING

LUCAS ROUND DINING TABLE

Thank you for choosing this quality product. Be sure to check all packaging materials carefully for small parts that may have become loose during shipment and place all parts on a non-abrasive surface.

<u>IMPORTANT</u>: These parts can be cumbersome and heavy to some people, therefore the assistance of two or more people is recommended in order to prevent personal injury and insure the furniture is not damaged during the assembly Process.

PART LIST

A [1] TOP

B [1] BASE

ASSEMBLY INSTRUCTIONS

- Place the top (A) on the base (B). Align and insert Allen bolt (1) together with lock washer (2) and flat washer (3) to each hole under top through the hole on the stretcher of the base.
- 2. Tighten all the bolts by using wrench (4). **DO NOT OVER TIGHTEN**. See sketch.

HARDWARE LIST

NO	ITEM	DESCRIPTION	QTY.
1		Allen Bolt	8 pcs.
2	P	Lock Washer	8 pcs.
3	0	Flat Washer	8 pcs.
4		Allen Wrench	1 pc.

