



GEOMETRIC DINING TABLE

Thank you for choosing this quality product. Be sure to check all packaging materials carefully for small parts that may have become loose during shipment and place all parts on a non-abrasive surface.

IMPORTANT :These parts can be cumbersome and heavy to some people, therefore the assistance of two or more people is recommended in order to prevent personal injury and insure the furniture is not damaged during the assembly Process.

PART LIST

- A [1] TOP
- B [2] LEG

ASSEMBLY INSTRUCTIONS

1. On a plain and non-abrasive surface gently turn the table top upside down.
2. under the table top are holes for the bolt to pass through that corresponds to the holes of the legs. Align and insert Allen bolt (1) together with lock washer (2) and flat washer (3), Tighten all the bolts by using Allen wrench (4) (do not over tighten). See **FIGURE 01**.
3. After assembly, gently lift the table into upright position

HARDWARE LIST

NO	ITEM	DESCRIPTION	QTY.
1		Allen Bolt	8 pcs.
2		Lock Washer	8 pcs.
3		Flat Washer	8 pcs.
4		Allen Wrench	1 pc.

FIGURE 01

