

LUNAR FLOOR LAMP

IMPORTANT SAFETY INSTRUCTIONS

- Consult certified electrician before installation that familiar with commercial type of applications.
- To reduce risk of fire, use 40 Watt Compact Fluorescent smaller lamp and do not exceed the recommended wattage.
- The manufacturer and distributor accepts no liability for incorrect installation.
- Wall must have at least the capacity of 5 times the weight of the wall sconce. For this light at least a wall capacity of 30 kg is required.
- Maximum Supply Current 1 A

W	\mathbf{r}		. ~

- Turn-off electricity supply at main circuit panel before installing. All wires are connected. Do not remove the wall sconce from its packaging by pulling on the power cord, as a bad connection may result.
- To reduce the risk of fire, electrical shock, or personal injury, always turn off the wall sconce and allow it to cool prior to replacing light bulb. Do not touch bulb when fixture is turned on or look directly at light bulb. Keep flammable materials away from light bulb.
- Deviation from instructions may result in a risk of fire or electric shock.
- Suitable for indoor use only
- The external flexible cable or cord of this luminaire cannot be replaced; if the cord is damaged, the luminaire shall be destroyed.
- Terminal block not included. Installation may require advice from a qualified person.
- Only to be installed outside arms reach.

ASSEMBLY INSTRUCTIONS

- 1. Insert the deco plate to the lamp base and re-install the bolt together with the deco nut to fix the deco plate to the lamp base.
- 2. Insert the lamp shade to the lamp base and re-install the hex nut together with the plain washer to fix the deco plate to the lamp base.

NO	DESCRIPTION	QTY
1		LAMP 1
2	LAMPS	HADE 1
3	DECO	PLATE 1
4	S NUT & WA	ASHER 1

