


10-412-2




REPLACEMENT PARTS LIST

Part #	Description
10-412-01A	Main Body & Dial Assembly
10-412-02A	Extension Channel
10-412-03	Nap Grip Inserts (set of 3 with screws)
10-412-04	Base Plate Assembly
10-412-05	Pin Cover
10-412-06A	Bottom Plate (with 10 screws)

Part #	Description
10-412-07	Kicker Teeth
10-412-08	Trigger Assembly (with spring)
10-412-09	Bumper Assembly (with 4 screws)
10-412-10	Bumper Body
10-422-09	3 in. Bumper Pad (with 4 screws)



10-422BK



REPLACEMENT PARTS LIST

Part #	Description
10-422-01	Main Body & Dial Assembly
10-412-02A	Extension Channel
10-412-03	Nap Grip Inserts (set of 3 with screws)
10-501-07A	Base Plate Assembly
10-501-08	Pin Cover
10-422-06	Bottom Plate (with 10 screws)

Part #	Description
10-412-07	Kicker Teeth
10-422-08	Trigger Assembly (with spring)
10-422-09	Bumper Assembly (with 4 screws)
10-422-10	Bumper Body
10-412-12	Bumper Screws