

INSTALLATION INSTRUCTIONS

LAUNDRY RACK

FEATURES

Laundry basket for removable frame.

PARTS


A. Modular Frame

B. Laundry bag

C. Plastic caps

MAINTENANCE


Clean with a soft, dry cloth. Avoid using solvents or abrasive.



1


PARTS: (A) Frame (C) Plastic caps

Fit the plastic caps (C) into the frame (A) as shown.




2

PARTS: (A) Frame (B) Laundry Bag
Hook the laundry bag (B) to the frame.

**3**

Insert the completed laundry bag holder inside the frame.



ISTRUCCIONES DE INSTALACIÓN / LES INSTRUCTIONS D'INSTALLTION

ESTANTE DE LAVANDERÍA / SUPPORT À VÊTEMENTS

CARACTERÍSTICAS / CARACTERÍSTICAS


Cesta de lavandería para marco removible.
Panier à linge pour cadre amovible.

PARTES / PIÈCES

- A.** Marco modular / Cadre modulaire
- B.** Bolsa de lavandería / Sac à linge
- C.** Tapas de plástico / Capsules en plastique

MANTENIMIENTO / ENTRETIEN


Limpiar con un paño suave y seco.
Evitar el uso de disolventes o productos abrasivos.
Nettoyez l'appareil à l'aide d'un chiffon doux et sec.
Évitez les solvants ou les produits abrasifs.



1

PIEZAS: (A) Marco E5250 (C) Tapas de plástico
Coloque las tapas de plástico (C) en el marco (A) como se muestra en la figura.


PIÈCES : (A) Cadre E5250 (C) Embouts en plastique
Fixez les embouts en plastique (C) sur le cadre (A) de la manière indiquée.



2

PARTES: (A) Marco E5250 (B) Bolsa de lavandería
Enganche la bolsa de lavandería (B) al marco.

PIÈCES : (A) Cadre E5250 (B) Sac à vêtements
Accrochez le sac à vêtements (B) sur le cadre.



3

Inserte el soporte para bolsa de lavandería completo dentro del marco.
Insérez le support de sac à vêtements assemblé dans le cadre.

