









# THE CLOUD FLOOR LAMP



A		FINIAL	
B		LAMP BASE	
C		TOP DECO	
D		LARGE GLASS DECO	20 PCS
E		MEDIUM GLASS DECO	28 PCS
F		SMALL GLASS DECO	34 PCS


## INSTRUCTIONS

1. Place the base on a flat working surface.
2. Align and insert the Top deco spider ring into the threaded nipple of the harp and secure these with the finial.
3. Install Type A Medium base bulb into the lamp-holder.

## CARE INSTRUCTIONS:

Avoid the use of all polishers, cleaners, and abrasives, as they will damage the finish of your lamp. To remove dust or fingerprints, wipe gently with a soft, clean cloth.


**FIGURE 1**



On the hanger frames have the pre-attached deco hanger chain designed for the glass deco hanging. Hang the glass deco on each hanger chain, as per illustrated in FIGURE 1.

**NOTE:** There are 3 sizes of glass deco. Make sure each piece will be hook on correct position. Refer to Figure 2

**FIGURE 2**



- E. 1.1: + All glass (4): 32pcs have no chain only hook
- E. 2.2: + All glass (4): 2pcs have the same length of chain: 20mm
- E. 3.3: + All glass (2): 12pcs have no chain only hook  
+ All glass (3): 12pcs have the same length of chain: 20mm
- E. 4.4: + All glass (3): 2pcs have the same length of chain: 30mm
- E. 5.5: + All glass (3): 8pcs have the same length of chain: 20mm  
+ All glass (2): 8pcs have no chain only hook
- E. 6.6: + All glass (3): 4pcs have the same length of chain: 215mm  
+ All glass (3): 2pcs have the same length of chain: 200mm

After assembling the glasses , be sure match with the attached photo

