



## CASTLITE™ CERAMIC NONSTICK CAST IRON

---

### GETTING STARTED

- **Wash Before First Use:** Clean with warm, soapy water; rinse and dry thoroughly.
- **Preheat for Best Results:** Use low to medium heat for most cooking. Medium high heat is sufficient for boiling water. Always coat the cooking surface with oil, butter, or a liquid cooking fat before heating.
- **Note:** We do not recommend using cooking spray on nonstick interiors.
- **Heat Guidelines:** Oven-safe up to 500°F.
- **Always** use potholders — handles, knobs, and pans get hot.
- **Do not** use under the broiler.

### CLEANING & CARE

- Allow cast iron to cool before washing. Avoid exposing a hot pan to cold water or placing it on cold surfaces.
- Handwash recommended to preserve finish. Use warm, soapy water, a nonabrasive sponge, and non-citrus dish soap.
- Dry thoroughly to prevent water spots.

### UTENSILS

- Safe for silicone, nylon, wood, and coated utensils.
- Avoid sharp tools like knives or forks on the cooking surface.

### COOKING TIPS

- **Induction:** Center pan on burner.
- **Glass Cooktops:** Lift, don't slide.
- **Gas Burners:** Keep flames under pan bottom only.
- **Oven Safe:** Always place the pan on an oven rack, not on the oven floor.
- **Serving:** Place cookware on a trivet or wooden board when serving. Avoid placing directly on an unprotected surface.
- **Never** leave pans unattended while cooking. Heating an empty pan can damage both the cookware and the stovetop.
- **Do not** use in the microwave.

### STORAGE

- Do not store cookware while damp.
- Store in a dry area and avoid overcrowding.
- If stacking pieces, use soft protectors to prevent scratches or chipping.
- If your cookware has any exposed cast iron rims, lightly oil them before long-term storage to prevent rust.

### LIFETIME WARRANTY

Subject to the exclusions and limitations contained herein, Conair LLC dba Cuisinart (“Cuisinart”) warrants that the Cuisinart® Cookware will be free from material defects in materials and workmanship under normal home use conditions throughout the original purchaser’s lifetime, beginning on the date this CastLite™ Ceramic Nonstick Cast Iron Cookware was purchased in its original, sealed packaging, unless otherwise specified in this Lifetime Warranty. This Lifetime Warranty is only for U.S. consumers (defined herein as purchasers at retail for personal, family, or household use) who originally purchase the CastLite™ Ceramic Nonstick Cast Iron Cookware from Cuisinart or an authorized Cuisinart® reseller (if you are unsure whether a retailer or other point of sale is an authorized or unauthorized Cuisinart reseller, contact Cuisinart).

This Lifetime Warranty does NOT cover:

- Normal wear and tear;
- Any CastLite™ Ceramic Nonstick Cast Iron Cookware purchased by commercial purchasers or for commercial or non-household uses;
- Accessories, parts, or software added to the CastLite™ Ceramic Nonstick Cast Iron Cookware after the system is shipped from Cuisinart;
- Any costs associated with the replacement or repair of the CastLite™ Ceramic Nonstick Cast Iron Cookware, including labor, installation, or other costs incurred by you without prior Cuisinart approval;
- Damage to the CastLite™ Ceramic Nonstick Cast Iron Cookware, defective conditions, or nonconformities due to: (1) external causes, including shipping, accidents, abnormal conditions (such as mechanical or environmental); (2) usage not in accordance with CastLite™ Ceramic Nonstick Cast Iron Cookware instructions; (3) misuse, neglect, unauthorized alteration, unauthorized repair; and (4) acts of God or other events beyond Cuisinart’s control;
- Though necessary repairs and maintenance might be performed by any company, damage caused by you or any nonauthorized third party may void this Lifetime Warranty;
- Damage caused by accessories or replacement parts not specifically authorized by Cuisinart may void this Lifetime Warranty; and
- Any CastLite™ Ceramic Nonstick Cast Iron Cookware where the original CastLite™ Ceramic Nonstick Cast Iron Cookware identification markings (trademark or serial number) have been removed, altered, or obliterated from the CastLite™ Ceramic Nonstick Cast Iron Cookware.

It is recommended that you visit the website, <https://www.cuisinart.com/register-your-product.html>, for a fast, efficient way to complete your CastLite™ Ceramic Nonstick Cast Iron Cookware registration. However, Cookware registration does not eliminate the need for the consumer to maintain the original proof of purchase in order to obtain the warranty benefits. In the event that you do not have proof of purchase date, the purchase date for purposes of this Lifetime Warranty will be the date of manufacture.

If the CastLite™ Ceramic Nonstick Cast Iron Cookware that is the subject of this Lifetime Warranty fails during the warranty period for reasons covered by this Lifetime Warranty, Cuisinart will, at its option, repair the CastLite™ Ceramic Nonstick Cast Iron Cookware, replace the CastLite™ Ceramic Nonstick Cast Iron Cookware with another identical or reasonably equivalent CastLite™ Ceramic Nonstick Cast Iron Cookware, or if Cuisinart is unable to repair or replace the CastLite™ Ceramic Nonstick Cast Iron Cookware, refund the purchase price, less the amount directly attributable to the consumer's prior usage of the CastLite™ Ceramic Nonstick Cast Iron Cookware. To obtain a return shipping label, visit us at <https://www.cuisinart.com/customer-care/product-as-sistance/product-inquiry/>, or call our Consumer Service Center toll-free at **1-800-726-0190** to speak with a representative.

Upon receipt of the CastLite™ Ceramic Nonstick Cast Iron Cookware, Cuisinart will inspect the CastLite™ Ceramic Nonstick Cast Iron Cookware and, if required under this Lifetime Warranty, attempt to repair, replace, or refund the CastLite™ Ceramic Nonstick Cast Iron Cookware within thirty (30) days. However, there may be delays beyond Cuisinart's control, in which case that time period may be extended as reasonably necessary.

**IMPORTANT:** If the nonconforming CastLite™ Ceramic Nonstick Cast Iron Cookware is to be serviced by someone other than Cuisinart's Authorized Service Center, please remind the servicer to call our Consumer Service Center at 1-800-726-0190 to ensure that the problem is properly diagnosed, the CastLite™ Ceramic Nonstick Cast Iron Cookware is serviced with the correct parts, and the CastLite™ Ceramic Nonstick Cast Iron Cookware is still under warranty.

The Lifetime Warranty period begins on the date the CastLite™ Ceramic Nonstick Cast Iron Cookware was delivered, which may be different than the date the CastLite™ Ceramic Nonstick Cast Iron Cookware was purchased. California residents also have the option of obtaining the benefits of this Lifetime Warranty by bringing the CastLite™ Ceramic Nonstick Cast Iron Cookware to (A) the store where it was purchased or (B) another retail store that sells Cuisinart CastLite™ Ceramic Nonstick Cast Iron Cookware of the same type. The retail store shall then, according to its preference, either repair the CastLite™ Ceramic Nonstick Cast Iron Cookware, refer the consumer to an independent repair facility, replace the CastLite™ Ceramic Nonstick Cast Iron Cookware with another identical or reasonably equivalent CastLite™ Ceramic Nonstick Cast Iron Cookware, or refund the purchase price less the amount directly attributable to the consumer's prior usage of the CastLite™ Ceramic Nonstick Cast Iron Cookware. California residents may also, according to their preference, return nonconforming CastLite™ Ceramic Nonstick Cast Iron Cookware directly to Cuisinart for repair or, if necessary, replacement with another identical or reasonably equivalent CastLite™ Ceramic Nonstick Cast Iron Cookware by calling our Consumer Service Center toll-free at 1-800-726-0190. Cuisinart will be responsible for the cost of such repair, replacement, and/or shipping and handling for such nonconforming CastLite™ Ceramic Nonstick Cast Iron Cookware under warranty.

**THIS LIFETIME WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS THAT VARY FROM STATE TO STATE OR BY JURISDICTION. IN THE EVENT THIS LIFETIME WARRANTY IS BREACHED, YOU MAY HAVE CLAIMS FOR REPLACEMENT, DAMAGES, OR OTHER PENALTIES LIMITATIONS OF LIABILITY/ADDITIONAL LIMITATIONS AND EXCLUSIONS ALL EXPRESS AND IMPLIED WARRANTIES ARE LIMITED IN DURATION TO THE LIFETIME WARRANTY PERIOD. NO WARRANTIES APPLY AFTER THAT PERIOD. SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, SO THIS LIMITATION MAY NOT APPLY TO YOU. CUISINART'S RESPONSIBILITY UNDER THIS OR ANY OTHER WARRANTY, IMPLIED OR EXPRESS, IS LIMITED TO REPAIR, REPLACEMENT, OR REFUND, AS SET FORTH ABOVE. THESE REMEDIES ARE THE SOLE AND EXCLUSIVE REMEDIES FOR ANY BREACH OF WARRANTY. TO THE MAXIMUM EXTENT PERMITTED BY LAW, CUISINART IS NOT RESPONSIBLE FOR ANY DIRECT, INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES RESULTING FROM ANY BREACH OF WARRANTY OR UNDER ANY OTHER LEGAL THEORY (INCLUDING, BUT NOT LIMITED TO, LOST PROFITS, DOWNTIME, GOODWILL, DAMAGE TO OR REPLACEMENT OF EQUIPMENT AND PROPERTY, AND ANY COSTS OF RECOVERING, REPROGRAMMING, OR REPRODUCING ANY PROGRAM OR DATA STORED IN OR USED WITH A SYSTEM CONTAINING THE CASTLITE™ CERAMIC NONSTICK CAST IRON COOKWARE), EVEN IF CUISINART HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATIONS OR EXCLUSIONS MAY NOT APPLY TO YOU. ALL EXPRESS AND IMPLIED WARRANTIES ARE LIMITED IN DURATION TO THE LIFETIME WARRANTY PERIOD. NO WARRANTIES APPLY AFTER THAT PERIOD. SOME STATES (OR JURISDICTIONS) DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, SO THIS LIMITATION MAY NOT APPLY TO YOU.**

This Lifetime Warranty is issued by:  
Conair LLC  
1 Cummings Point Road  
Stamford, CT 06902  
1-800-726-0190