

PM1115U2 Ethernet to USB Print Server

FAQs

This document contains some helpful FAQs should you run into any issues:

1. What is this devices default static IP address?

What is this devices default static IP address?

FAQ

This device's default static IP address is 192.168.0.10.

Visit www.startech.com/support for additional FAQs, videos and more!