

Quick Installation Guide

Display over Ethernet Adapter

Installation

Note: **DO NOT** connect the Ethernet adapter to your computer before completing the driver installation.

On Windows XP and Vista

1. Insert the provided driver CD into your CD-ROM drive. Locate and double-click the **Setup.exe** file under the **Driver** folder on the CD.
2. During the installation, the screen will flick black a couple of times. This is normal.
3. When finished, the installation screen will disappear and you will return to your desktop.
4. When the **Install DisplayLink Software** screen appears, select I accept the terms in the license agreement.
5. After installed, select Yes to **restart** your computer and effect the Display over Ethernet driver
6. Please **connect** the Ethernet adapter's LAN port end to a free Router.
7. Please double-click the **Launch Cat5ShareStation.exe** icon on the desktop
8. Select **Generic DoIP** and double-click the **Connect** button, Once done, you will see the **Generic DoIP** icon become **orange**.
9. Then a pop-up message for **DVI over Ethernet** will appear in the notification area indicating the installation is complete.

If your monitor is not yet connected to the adapter, make the connection and power on your monitor. After the connection, the adapter-attached monitor will soon be vivid and mirror your Windows desktop.

This Quick Installation Guide describes only the basic instructions to get your device up and working. For more information, please refer to the User's Manual on the provided CD-ROM.
