Resource Decor

CHLOE BENCH

Thank you for choosing this quality product. Be sure to check all packaging materials carefully for small parts that may have loosened inside the carton during shipment and place on a non-abrasive surface.

IMPORTANT

These parts can be cumbersome and heavy to some people, therefore, the assistance of two or more people are recommended in order to prevent personal injury and ensure the furniture is not damaged during the assembly Process.

PART LIST

A. [1] SEAT

B. [4] LEGS

INSTRUCTIONS

1. Lay the Seat (A) upside down on a soft flat surface.
2. Attach the legs (B) to the bottom of the Seat by using Allen bolts (1), lock washers (2) and flat washers (3). See **FIGURE 01**.
3. Turn the Bench to an upright on your desired location.
4. Assembly is complete.

HARDWARE LIST

NO	DESCRIPTION	QTY
1	ALLEN HEAD BOLT	12
2	LOCK WASHER	12
3	FLAT WASHER	12
4	ALLEN WRENCH	1



FIGURE 01

CARE INSTRUCTIONS

1. Dust often using a clean, soft, dry and lint-free cloth.
2. Blot spills immediately and wipe with a clean, damp, cloth.
3. We do not recommend the use of chemical cleansers, abrasives or furniture polish on our lacquered finish.

Thank you for your purchase