LA032685UFFEU7

Antibac Pvc Shower Mat

Please retain instructions for future reference.

CARE AND USE

To be eligible for the guarantee, please retain your proof of purchase.

Please retain instructions for future reference.

Remove all of the packaging.

Open out the shower mat and lay it flat for 24 hours before use.

Soak the shower mat in a shower with warm water for 10 minutes before first use.

Place the shower mat into a clean shower free of any dirt or oils.

Do not use the shower mat on a textured surface, as the suction pads will not engage properly.

Centre the shower mat in a dry shower with the suction pads on the underside.

Firmly press down the entire shower mat surface by hand whilst kneeling alongside the shower.

Carefully step onto the shower mat whilst holding a grab rail or the edge of the shower.

Tread down 8–10 areas of the shower mat to ensure that it is properly adhered to the shower surface.

If the shower mat suction pads are not fully anchored to the shower surface repeat the above instructions.

After use, lift the shower mat at one corner and peel back.

Rinse the shower mat thoroughly and hang to dry; do not dry with a hairdryer or over a radiator.

Caution Not recommended for use on textured surfaces.

Not suitable for use with bleach.

Always keep the shower surface clean.

Always remove the shower mat before cleaning the shower surface.

Bath oils may reduce the safety of the shower mat.

Use all safety precautions when entering/exiting the shower.

This shower mat is designed to help prevent slipping, its effectiveness depends upon care and use.

Made in China

Manufactured by: UP Global Sourcing UK Ltd, Victoria Street, Oldham, Manchester OL9 0DD. UK
Ultimate Products Europe Ltd, 19 Baggot Street Lower, Dublin, D02 X658. ROI