perfect aire

THROUGH-THE-WALL AIR CONDITIONER

WITH HEAT | 10,000 BTU | ELECTRONIC



	4PATWH10002
UPC CODE	842149000639
COOLING CAPACITY (BTU)	10000
HEATING CAPACITY (BTU)	10600
ENERGY STAR	No
COVERAGE AREA (sq. ft.)	450
CEER	9.6
VOLTAGE	208/230V
AMPS	5.4/6.0
WATTS	1000/980
FAN SPEEDS (cool/fan/heat)	3/3/1
UNIT DIMENSIONS (W×H×D) (in.)	24.25×14.5×20.5
PKG. DIMENSIONS (W×H×D) (in.)	28×17×26.75
WEIGHT (Net/Gross) (lbs.)	68.5/78.5
CONTAINER QTY. (40HQ)	306
REFRIGERANT	R32
OUTLET CONFIGURATION	20A – 230V

CHOOSING THE RIGHT AIR CONDITIONER

1 MEASURE AREA OF THE ROOM



CALCULATE ROOM SIZE
room length × room width = sq. ft.

2 MATCH ROOM SIZE WITH CORRECT BTUs

SQ. FT.	ROOM SIZE	BTUs
150	10' × 15'	5,000
250	10' × 25'	6,000
350	17' × 20'	8,000
450	15' × 30'	10,000
550	20' × 27'	12,000
700	20' × 35'	15,000
1,000	25' × 40'	18,000
1,500	30' × 50'	25,000

3 MAKE ANY ADJUSTMENTS

INCREASE BTU 10%
FOR SUNNY ROOMS. DECREASE BTU 10% FOR SHADED ROOMS.

ADD 600 BTUs
FOR EACH ADDITIONAL PERSON OVER TWO.

ADD 4,000 BTUs
IF UNIT IS USED IN A KITCHEN.

FEATURES

- Fits most standard through-the-wall AC sleeves
- 3 cooling and fan speeds & 1 heat speed
- 4-way adjustable air vents
- Cool, Heat, Fan, Eco, and Sleep modes
- Quick & easy installation
- Mounting kit included
- Electronic controls
- Follow-me remote control acts as portable thermostat
- 24-hour timer
- Auto-restart
- Adjustable thermostat (62-86°F)
- Easy clean slide out filter

C US

1 YEAR FULL REPLACEMENT WARRANTY

PERFECT AIRE, LLC 5401 Dansher Road; Countryside, IL 60525 | 888.752.7995 | perfectaire.us | orders@perfectaire.us