CW11431

Russell Hob Vit Enamel 42Cm Deep Roaster

Please retain instructions for future reference.

CARE AND USE

Please retain instructions for future reference.

BEFORE FIRST USE Hand-wash thoroughly.

Suitable for domestic oven use only, up to 220 °C/Gas Mark 7.

Not suitable for use on a hob, in a microwave, under a grill, over a naked flame, on an open fire or barbeque.

Lightly coat the inner surface of the ovenware with grease to prevent sticking.

To increase the longevity of the ovenware, it is recommended to use silicone, wooden or nylon utensils.

Do not overheat the ovenware.

Never leave unattended whilst in use.

CLEANING AND STORING THE OVENWARE Always allow to cool before cleaning.

The ovenware is safe for dishwasher use with mild detergents.

Hand-wash using a mild detergent and non-abrasive sponge, rinse and dry thoroughly.

Do not store wet ovenware.

CAUTION Always use heat-resistant oven gloves to move the ovenware.

Never expose hot ovenware to cold liquid.

If there is any evidence of damage to the ovenware, dispose of it carefully.

Made in Romania

Manufactured by: UP Global Sourcing UK Ltd, Victoria Street, Oldham, Manchester OL9 0DD. UK

Ultimate Products Europe Ltd, 19 Baggot Street Lower, Dublin, D02 X658. ROI