



CRC Industries NZ, Auckland NZ

## ***I. Product Description***

*CRC Headlight Doctor* restores clarity to dull and yellowing headlight lenses. It quickly and easily cleans, shines and protects all vehicle lenses, improving driving visibility.

*CRC Headlight Doctor* restores cloudy and dull headlights, removes surface oxidation, discolouration, stains, light scratches, contamination and hazing. *CRC Headlight Doctor* provides a water resistant protective coating, delaying future oxidation and discolouration.

*CRC Headlight Doctor* is suitable for cleaning and restoring most plastic surfaces including – headlight and tail light lenses, bug shields, auto and marine windshields, instrument clusters, helmet visors, safety goggles, plastic convertible windows.

Suitability in each case should be determined by first testing on an inconspicuous area. Cracked, micro-cracked, severely pitted, water fogged from the inside, or severely weathered lenses may not return to the original condition.

## ***II. Features & Benefits***

- Convenient – Quick & Easy
- Safety – Improves driving visibility
- Cleans, shines and protects
- Restores clarity to headlights and most plastic surfaces.
- Removes surface oxidation, discolouration, stains, light scratches, contamination and hazing
- Delays future oxidation & discolouration – Polymers provide water resistant, long lasting protection
- Made in NZ

## ***III. Application and Directions***

- Wash headlight lens with *CRC Ultra Gloss* or *CRC Tough Wash* to remove surface dirt.
- Firmly rub a small amount of *CRC Headlight Doctor* onto the entire lens with a clean cloth.
- Buff off with a clean cloth.
- Avoid contact with black headlight surrounds
- For heavily oxidised lenses, multiple applications maybe necessary to achieve best results.
- For ultimate results repeat directions above until no brown residue remains on the polishing cloth.

**Note: Cracked, micro-cracked, severely pitted, water fogged from the inside or severely weathered lenses may not return to the original condition.**

## ***IV. Package Description***

Part Number	Size
9230	220ml Tottle

## ***V. Special Precautions***

### **First Aid:**

If in Eyes – Immediately hold the eyelids apart and flush the eye continuously for at least 15 minutes with fresh running water. Ensure complete irrigation of the eye by keeping eyelids apart and away from eye and moving the eyelids by occasionally lifting the upper and lower lids. Refer to Material Safety Data Sheet for more details.

**TECHNICAL DATA SHEET** Version 06/2014

**PRODUCT WARRANTY:** CRC offers a conditional warranty of this product for the period of 2 years from the date of manufacture.

**DISCLAIMER:** All information on this data sheet is based on testing by CRC Industries NZ. All products should be tested for suitability on a particular application prior to actual use. CRC Industries makes no representations or warranties of any kind concerning this data.