



Southwire™

TOOLS & EQUIPMENT

QWIKrope® LINK SOFT SHACKLES

Southwire's new QWIKrope® LINK allow for a safe and efficient way to connect two eyed ropes together and allow for flexibility around difficult pulling points! Available in two sizes, 1/8" and 1/4". Made of High Molecular Weight Polyethylene Fiber, allowing for a working load of 1,650lbs. for the 1/8" shackle and 11,250lbs. for the 1/4" version.

LIGHT WEIGHT

WATER RESISTANT

ONE PIECE CONSTRUCTION



MODEL #	UPC	STOCK	PRODUCT NAME	DESCRIPTION	WORKING LOAD LBS.
SS-18	0-32886-69952-8	65030501	QWIKrope® Link 1/8" Soft Shackle	1/8" Soft Shackle	1,650 lbs.
SS-14	0-32886-69953-5	65030601	QWIKrope® Link 1/4" Soft Shackle	1/4" Soft Shackle	11,250 lbs.

**[BUILT FOR DURABILITY.
BUILT FOR RELIABILITY.
BUILT FOR WORK.™]**

1-855-798-6657 | SOUTHWIRETOOLS.COM

©2019 Southwire Company, LLC. All rights reserved.
*Registered Trademark & ™Trademark of Southwire Company, LLC.



QWIKrope® LINK FAQs

Q: *What is the smallest size conduit the QWIKrope® Link Soft Shackle will fit into?*

A: The 1/8" QWIKrope® Link Soft Shackle will fit into a 3/4" conduit and the 1/4" QWIKrope® Link Soft Shackle will fit onto a 1-1/2" conduit.

Q: *What is the load rating for the QWIKrope® Link Soft Shackles?*

A: The load rating for the QWIKrope® Link Soft Shackles is- 1/8" (1650lbs) and 1/4" (11,250lbs). When using more than one QWIKrope® Link Soft Shackle the load rating is doubled or tripled based on how many shackles are used. Note: When using the QWIKrope® Link Soft Shackles, the load rating of the system now becomes the combined rating of the QWIKrope® Link Soft Shackles being used.

Q: *How do you position the ball of the QWIKrope® Link Soft Shackle?*

A: The ball of the QWIKrope® Link Soft Shackle should always be positioned in the trailing end position closest to the wire being pulled.

Q: *Do you need to tape the QWIKrope® Link Soft Shackle after it is installed?*

A: No, taping of the QWIKrope® Link Soft Shackle is not required. If using more than one QWIKrope® Link Soft Shackle, stagger the knots of the soft shackles to ensure minimum diameter is achieved. You may tape them together to keep the soft shackles from moving.

Q: *What is the small string on the eye end used for?*

A: The small string on the QWIKrope® Link Soft Shackle is to allow the user to pull additional material from inside of the soft shackle to allow enough room for the knot end of the soft shackle to fit into the eye of the shackle.