




# Hydrion® Hydrogen Peroxide Test Strips

0-750 and 0-5000 ppm

The use of antimicrobial and disinfectant chemicals is a critical step in keeping the public safe from pathogens. The correct concentration of these chemicals must be confirmed to ensure efficacy and can be easily tested via our simple dip and read test strips.

Hydrion® Hydrogen Peroxide test strips A quick, reliable, and easy way to test the strength and efficacy of Hydrogen Peroxide disinfectants commonly used in food manufacturing, schools, nursing homes, hospitals and other healthcare facilities.

 US Concentrates		PPM	PPM	PPM
<b>Alpha-HP Disinfectant Cleaner</b>	Dilution	1:64	1:128	–
	PPM	654	329	–
	Test Kit	AHP100	AHP100	–
<b>Oxivir Five 16</b>	Dilution	1:16	1:128	1:256
	PPM	2500	329	165
	Test Kit	HP-5000	HP-750	HP-750



## How to Measure Hydrogen Peroxide Concentration with HP-750

1. Dip the strip into the test solution for 1 second
2. Remove the strip and shake off excess
3. Match at 90 seconds to color chart for accurate Hydrogen Peroxide measurement

## How to Measure Hydrogen Peroxide Concentration with HP-5000

1. Dip the strip into the test solution for 1 second
2. Remove the strip and shake off excess
3. Match at 60 seconds to color chart for accurate Hydrogen Peroxide measurement



# Hydrion® Hydrogen Peroxide Test Strips

## 0-750 and 0-5000 ppm

### Storage

Store the AHP Indicator Strips at room temperature between 59°F and 86°F (15°C and 30°C). Do not expose to direct sunlight.

### Important Precautions

Keep the strips in their original container. Remove only one strip for testing and immediately replace the cap tightly. Do not touch reagent pad with finger or any other surface. Exposure of the uncovered strip to light and moisture may cause discoloration of the strip. Once opened the indicator strips have a 6 month shelf life. Unopened test kits have a 1 year shelf life. Do not use the strip after the expiration date, open or unopened.

### Product Availability

Hydrion® Hydrogen Peroxide test strips are packaged with 100 strips in a bottle. Strip dimensions: 2 1/2 in. x 3/16 in.

To order contact PBI at 1-800-492-4422

#### Hydrion® Hydrogen Peroxide Test Strips 0-750

Order No. HP-750      Pack Size: 6 vials per case  
pH Range: 0-750 ppm      Color Matching Points: 0-100-250-500-750 ppm

#### Hydrion® Hydrogen Peroxide Test Strips 0-5000

Order No. HP-5000      Pack Size: 6 vials per case  
pH Range: 0-5000 ppm      Color Matching Points: 0-500-1000-2000-3000-5000 ppm

If you require additional information contact  
Diversey Customer Technical Support at 1-800-558-2332

