



3M™ Formaldehyde Monitors 3720, 3721

Thank you for choosing a 3M™ Diffusion Monitor. During this short review we will cover preparation and use of your monitor. For additional information, please consult your user instructions or contact 3M Technical Service at 1-800-243-4630.

The 3M™ 3720 is a formaldehyde monitor with pre paid analysis. The 3M™ 3721 is a formaldehyde monitor without analysis included.

NOTE the 3720 is not sold in Canada.

The diffusion monitor is a sampling device designed to measure average concentrations of certain contaminants over time. The 3720/3721 monitor meets OSHA accuracy requirements for 8 hour sampling of +/- 25% at 0.75 ppm and +/- 35% at 0.5ppm. It is not recommended for 15 minute sampling as it may not collect enough material to accurately compare against the short term exposure limit (STEL).

The shelf life of the monitor is 18 months if stored in an area free of formaldehyde. The expiration date is printed on a sticker on the can. It is a two digit month followed by a two digit year.



Click picture to start video. Click button to view video text

- ◆ This document has been encoded for a Windows operating system
- ◆ This version of the interactive document requires at minimum an internet connection with (256Kbs) minimum connection speed and Acrobat Reader 6.0 or higher for proper operation
- ◆ If there is no video, reaffirm that you are running Acrobat Reader 6.0 (minimum requirement)
- ◆ If video problems persist, try closing other applications that may be consuming the required memory
- ◆ If there is no audio or the volume is too low, right-click the audio setting icon and adjust accordingly
- ◆ Sound but no video, click NEXT

NEXT ▶

Click picture to start video.

Click button to view video text

3M™ Formaldehyde Monitors
3720 and 3721

-Preparation and Use



Formaldehyde Monitor

A purple, teardrop-shaped formaldehyde monitor with a silver metal clip at the top and a white circular sensor in the center. The number '3721' is printed on the purple plastic.



3M™ Formaldehyde Monitors
3720 and 3721

-Preparation for Shipment



Formaldehyde Monitor

A purple, teardrop-shaped formaldehyde monitor with a silver metal clip at the top and a white circular sensor in the center. The number '3721' is printed on the purple plastic.



3M™ Formaldehyde Monitors
3720 and 3721

-Reading Report



Formaldehyde Monitor

A purple, teardrop-shaped formaldehyde monitor with a silver metal clip at the top and a white circular sensor in the center. The number '3721' is printed on the purple plastic.





WARNING

Use of these products by untrained or unqualified persons, or use not in accordance with the instructions, may adversely affect product performance and **result in sickness or death**. These products are to be used only by qualified persons who are properly trained in their use and maintenance, and only in accordance with their operating and maintenance manuals. Each person using these products must first read and understand the operators manual.

For proper use, see your supervisor, product instructions and warnings or call 3M OH &ESD Technical Service at 1-800-243-4630. In Canada call 1-800-265-1840 extension # 613 .

3M Occupational Health and Environmental Safety Division (OHESD)

In the U.S. , contact:

Customer Service

1-800-328-1667

Technical Assistance

1-800-243-4630

Fax On Demand

1-800-646-1655

Internet

<http://www.3M.com/occsafety>

For other 3M Products

1-800-3M-HELPS

In Canada, contact:

3M Canada Company, OH & ESD

P.O. Box 5757

London, Ontario N6A 4T1

Customer Service

1-800-265-1840

Technical Assistance (Canada Only)

1-800-267-4414

Fax On Demand

1-800-646-1655

Technical Assistance In Mexico

01-800-712-0646

5270-2255, 5270-2119 (Mexico City only)

Technical Assistance in Brazil

0800-132333

Fax On Demand O.U.S Locations

1-651-732-6530

**3M Occupational Health and Environmental Safety Division
3M Center, Building 235-2W-70
St. Paul, MN 55144-1000**

© 3M April, 2008. All rights reserved.