

## **ADOS Universal Silicone**

CRC Industries NZ, Auckland NZ

# I. Product Description

ADOS Universal Silicone is a weather resistant sealant that is translucent allowing it to blend into its surrounding surfaces. The mould and mildew resistant properties make the sealant ideal for kitchen, bathroom and other plumbing applications.

ADOS Universal Silicone can be used for general purpose adhering and sealing on most building materials and on many damp surfaces such as timber, cement, many plastics, roofs and guttering, window frames and glazing, masonry, ceramics, sheet metal, block or brickwork etc. It can be used where high humidity and temperatures may be encountered.

# II. Features & Benefits

- 100% Silicone
- Waterproof sealant
- Mould and mildew resistant
- Indoor and outdoor use
- Low odour
- UV Resistant
- Flexible
- A general purpose, neutral cure RTV silicone
- Widely used by plumbers, roofing contractors, builders, general industry and the home handyman

# III. Application and Directions

#### Preparation:

- Surfaces must be clean from any contamination, and dry before application.
- Use mechanical or solvent cleaning. Do no use soap or detergent.
- Use masking tape to cover surfaces and joints to simplify cleaning.
- If surface requires a primer, the primer must be dry before applying sealant

#### Application:

- Before placing cartridge in application gun, slice nozzle at a 45 degree angle at desired bead size.
- Press nozzle against surface and apply sealant.
- Tool to eliminate all voids within 5 minutes of applying sealant. Tack-free time is 1 hour. Sealant will fully cure in 72 hours.
- Immediately after completion, clean excess sealant off surfaces, tools and hands with a clean, dry cloth.
- Remove masking tape within 1 hour.

#### **Clean Up:**

- ADOS Solvent N to clean uncured product off equipment and surfaces.
- ADOS Silicone Remover to remove cured product.
- ADOS Solvent PS is suitable for removing stains from sealant.

**Note:** Not recommended for use on submerged joints, especially where porous substrates permit water to the bond interface



**IR**@

# ADOS Universal Silicone

CRC Industries NZ, Auckland NZ

Depth mm	Width mm						
	3.3	6.4	9.7	12.7	16.0	19.2	25.4
3.3	29.7	14.88	9.93	7.44	5.94	4.97	3.72
4.9		9.93	6.64	4.97	3.96	3.31	2.48
6.4		7.42	4.97	3.72	2.97	2.49	1.86
9.7			3.31	2.48	1.98	1.64	1.23

#### Estimating Requirements - linear metres per cartridge for various joint dimensions:

# *IV.* Typical Properties and Characteristics

**Physical Properties & Performance Characteristics:** 

Composition	Silicone polymer		
Curing Method	Neutral (Oxime)		
Colour	Translucent		
Service Temperatures	-60 ℃ to +150 ℃		
Peel Strength (ASTM C794)	2.9 kN/m		
Hardness (Shore A)	20-35		
Sag / slump (w = 20mm)	< 1mm		
Tensile Strength	≥ 1.0 MPa		
Dynamic Joint Movement	± 25%		
Density	1.04		
Tooling Time	6-20 minutes		
Toxicity	Not suitable for fish tanks		
Tack Free Time	20 minutes		
Cure Time (5mm, 20 °C / 55%RH)	2 days		

## V. Package Description

Part Number Size

8358 310ml Cartridge

## VI. Special Precautions

#### General:

Keep locked up. Store in cool, dry, protected area. Use with adequate ventilation. Do not eat, drink or smoke while using. Dispose of empty containers safely. All unused product should be disposed of in conformance with local and HSNO regulations, do not contaminate water supply.

#### First Aid:

Swallowed – Do not induce vomiting. Give water to rinse out mouth, then provide liquid slowly and as much as casualty can comfortably drink. Transport to hospital or doctor without delay. Skin – Wipe off excess with absorbent tissue or towel. Wash affected areas with warm water and soap. Seek medical attention if swelling/redness/blistering or irritation occurs.





## **ADOS Universal Silicone**

CRC Industries NZ, Auckland NZ

Eyes – Hold open and flush eye continuously with running water. Continue flushing until advised to stop by the Poisons Information Centre or a doctor, or for at least 15 minutes. Transport to hospital or doctor without delay.

Inhalation – Remove from contaminated area. Lay patient down. Keep warm and rested. Transport to hospital or doctor.

Refer to Material Safety Data Sheet for more details.

TECHNICAL DATA SHEET Version 08/2012

**PRODUCT WARRANTY:** CRC offers a conditional warranty of this product for the period of 2 years from the date of manufacture.

**DISCLAIMER:** All information on this data sheet is based on testing by CRC Industries NZ. All products should be tested for suitability on a particular application prior to actual use. CRC Industries makes no representations or warranties of any kind concerning this data.