



Dry Wipes Charging Bucket

Dry Wipes Charging Bucket and Lid

The Dry Wipes Charging Bucket and optional lid give you the flexibility to use the cleaner, disinfectant or sanitizer of your choice, paired with Diversey Dry Wipes, to have a ready-to-use, convenient and on-demand solution for any facility.

Features & Benefits

- Portable and rigid bucket for cleaning and disinfection, to preserve product contents
- Optional hinged lid for containing cleaning wipes, protecting them from contaminants and preventing splash and spills
- Size allows flexibility in contents, enabling a variety of cleaning tool sizes
- Convenient packs of 12 for multiple use settings throughout the facility
- Holds 250 of the Diversey 6"x8" Dry Wipes or 50 of the Diversey 12"x12" Dry Wipes, enabling wipes-on-demand applications
- Contact your Diversey rep for optimal usage with your desired cleaning tool

Applications

- For use with Dry Wipes charging and the cleaner/disinfectant of choice





Dry Wipes Charging Bucket

Dry Wipes are the perfect choice for dust and dirt removal in facilities with no laundering capabilities, and recommended for traditional spray-and-wipe cleaning.

Both ready-to-use (RTU) and concentrated cleaners, sanitizers and disinfectants that have been properly diluted, may be used with Dry Wipes to clean, sanitize and disinfect hard nonporous surfaces.

Dry Wipes may be pre-wetted for up to 24 hours. If using an Improved or Accelerated Hydrogen Peroxide® product with Dry Wipes, the shelf life is 28 days (when pre-wetted onsite). Refer to the Diversey Disposable Wiping System Pre-wetting Instructions. Some quaternary-based chemicals may bind with the wipes and testing is recommended prior to pre-wetting, or use in a spray and wipe application. Please refer to the original product label for directions for use and surface contact times.

Use Instructions

- Gather a charging bucket and lid for preparation
- Select the cleaning tool and compatible cleaner/disinfectant of choice
- Follow the instructions for dispensing chemistry in bucket and charging the cleaning tool
- Place hinge lid on the container and secure closure (optional)
- Label the bucket with the product information and document expiry information clearly on the container
- Dispose of contents after shelf life expires
- Clean and disinfect container and lid as appropriate. Contact your Diversey representative for instructions.

Disposal Instructions

- Dispose of wipe in trash after use. Do not flush.

Technical data	Dry Wipes
Color/Material	White, Polypropylene
Size	1 Gallon, 8" x 11.3" x 4.8", Pack 12

Product	Description	Product code	
Dry Wipes Charging Bucket	Bucket	D1229129	
Dry Wipes Charging Bucket Lid	Hinged Lid	D1229130	