CLAIRITY™ Application Quick Start

JOT "Just One Touch"

Table of Contents

Welcome

The CLAIRITY mobile app Sensor Switch" JOT path allows users to start up, configure and troubleshoot from a compatible smartphone or tablet. The CLAIRITY mobile app is optimized for efficient onsite startup and maintenance activities. It allows you to easily modify the settings and operation of the fixtures, sensors and wall switches, aiding in meeting energy code requirements. For larger installations, multiple users may use the CLAIRITY mobile app simultaneously to reduce onsite time.

UPDATE FIRMWARE

Step 1

Download latest Firmware Image

Push Firmware Update to each Device

These firmware updates must be made to each device individually

Join an Existing Provisioned Network

Step 1

Insert JOT tool inside secure previsioning button.

Step 2

Press front button 8 times, which will enable Acuity Config-GATT which will allow mobile device to join provisioned network.

JOT Entry

Enter Group Sorted by RSSI

Set PIN

Create a New Group

Typically a group is created for each room. For the JOT system, a group can not contain more than 64 devices. To create a new group, follow these steps:

Step 1: Tap on the + icon on the Groups screen
Step 2: Enter a name for the group. The group name is typically going to be the name of the room.
Step 3: Tap the Create button
Step 4: You will then be taken to the Group Overview screen for the group that you created.
Step 5: If you wish to edit a different group, simply select the Group icon in the top left to navigate back to the Groups screen

Create Group

Enter Group Name

Enter Password

Use Identify to find devices
List Sorted by RSSI

Intuitive Individual Device Settings

1. **High and Low Trim**
   - High Trim adjust the maximum light level an output device can achieve
   - Low Trim adjust the minimum light level an output device can achieve
2. **Photocell Set-point**
   - Sets the light level the fixture will maintain under daylight harvesting
     a) If daylight illumination increases above set-point the fixture will automatically dim
     b) If the daylight illumination decreases below set-point, the fixture will return to maximum light output
   - WSXA JOT will operate in inhibit mode only
     a) The ambient light level at the sensor prevents the lights from initially turning on. Once lights are on they will remain on until the space becomes unoccupied (occupancy time delay expires and turns lights off)
3. **Microphonics Sensitivity**
   - Only available in WSXA JOT PDT option
   - Alters occupancy detection sensitivity

Create Behavior Zone

Initiate behavior zone

1. **On / Off / Dim by switch**
   o Can be applied to any group that has at least one fixture and one switch.
   o You may select if the light comes on to full bright or if it turns on to the prior dim level when the on button is pressed.
   o If combined with daylighting turning the lights on will make the fixtures go to their day lighting level. If the switch has raise and lower buttons, the user may raise the light level above the daylighting level.
   o If combined with occupancy the switch will override the occupancy behavior for 1 minute.

2. **Occupancy**
   o Can be applied to any group with at least 1 sensor.
   o Configurable parameters include:
      a) On Mode:
         • Occupancy (Auto on) - lights will turn on when at least 1 sensor in the zone sees motion. Lights will dim down after "X" minutes of no activity.
         • Switch (Manual On) - Lights must be turned on via a switch. Lights will dim down after "X" minutes of no activity.
         • Turn on to xx% when occupied
      b) Dim to % - The level the lights will dim to after "X" minutes of no activity.
      c) After "X" minutes of no activity - The time delay between the sensors no longer sensing motion and the lights dimming to the dim to %.
      d) Turn off time - The time delay between the dim to light level and the lights turning off. Total time between no motion and the lights turning off is the sum of the turn off time and the dim after time.
         • Immediately after sending programming values to the fixtures, the fixtures require a few minutes to synchronize before following the programmed time outs.

3. **Microphonics Sensitivity**
   o Can be applied to any group with at least 1 sensor.
   o Must be calibrated after programming has been sent to the fixtures. This can be done by navigating to the group overview screen, selecting device settings, and selecting photosensor calibration.

Operating Mode

Only 1 daylighting sensor per zone
Multiple Zones Are Allowed

Daylighting	A lighting control strategy that accounts for the presence of natural light and changes the artificial light to achieve a desired light level
Account	One or more sites that are all affiliated with one end user.
Area	A descriptor for a physical geographical area, within a customer site, that has some common use or purpose
Group	All the devices within one area
Identify	A process by which a device provides some visual feedback (e.g. - the flashing of a fixture) so it's location can be determined.
Behavior Zone	A collection of devices expected to work together, defined by a specific behavior type. This is also referred to as the sequence of operation.
Fixture	A piece of equipment that outputs light
Switch	A piece of equipment that, is typically mounted on a wall, that a user may interact with to control lights in their vicinity
Device	A generic term used to describe the individual units that comprise a system.
Mobile Device	A personal handheld communication device that provides connectivity to wifi, cellular, or bluetooth
Startup	The act of troubleshooting and programming a new installation of equipment
Photosensor	A device that detects the presence of light.
Occupancy Sensor	A control device that detects motion