american drew
• inspired design •

Tel: 828-728-3261
www.americandrew.com

ASSEMBLY INSTRUCTIONS

750-858



BEFORE YOU START:

1. Check the parts against the parts list to make sure all items are present.
2. Assemble your furniture on a soft, flat surface to avoid scratching the finish.
3. **CAUTION:** Do not over tighten screws, nuts or bolts during assembly.
4. Your furniture may require occasional tightening.

INSTRUCTIONS:

1. Turn the case top upside down on a clean soft surface .

2. Screw hanger bolt on Bun foot into spring insert on bottom base. Secure all bun feet and make sure they align together. see Figure 1

NOTE: The insert has a spring which allows up to a 3/4 turn to align the square Bun Foot with the base shape.

3. Attach the bar to the top cabinet, using Bolt (A), Flat Washer (C), Lock Washer (B) and tighten all nuts with Wrench (D). (See Figure 2)




Figure 1




Figure 2

No.	Hardware List		Q'ty
A		Bolt Ø1/4"x1-1/2"	4
B		Lock Washer Ø1/4"	4
C		Flat Washer Ø1/4"	4
D		Allen Wrench 4mm	1

Thank you for purchasing furniture from american drew!