


MONTBURN


ANZZI™

- Please check your product packaging to make sure the included accessories are in the “list of standard accessories”. If any parts are missing, please contact your local dealer immediately.
- Do not allow any sharp objects to come in contact with the cabinet, as it will scratch the surface.
- Continuous and prolonged exposure to direct sunlight may cause discoloration to the wood.
- Do not put any hot appliances directly on or near the cabinet.
- Please avoid using cleaning products that contain bleach or ammonia.
- Wood surfaces should only be cleaned with wood care products such as soapy water or furniture polish.





NOTE: Mirror(s) not included with all SKU builds. Check listing for details.

INSTALLATION



MAIN BODY PARTS



INSTALLATION PARTS






Tape




Pencil




Impact Drill



Levelling Instrument




Screw driver




Glass Glue Gun


INSTALL,REMOVE,ADJUST OF TOP FAST LOADING HINGE




install




remove



adjust the height




adjust the lateral



adjust the deep


INSTALLATION INSTRUCTIONS




① Attached Gasket



② Install Counter Top.



③ Fix the mirror



④ Hang the mirror