

88 5100 007 Buffet

IMPORTANT NOTE


Carefully remove all the parts from the carton and put them individually on a soft cloth to prevent scratches or other damage occurring to the parts.

We have taken great care in the design of this product and request that you carefully and strictly follow our assembly instructions to ensure a completed product as it was designed.


Home Styles



Part List



Hardware List



Tools required for assembly : Phillips screwdriver, Drill, 3/8" Drill Bit, Level


Home Styles Consumer Assistance : www.homestyles-furniture.com,
servicedesk@homestyles-furniture.com, 888-680-7460, 877-831-0319

IMPORTANT

- * Please keep Hex Wrench in a safe place as you may need to tighten up the Head Cap Bolts in the future.
- * Do not tighten up all the bolts until each part is properly assembled.
- * Use a soft cloth between these parts and the floor.
- * After assembly, item must be level to work properly. Use the included adjustable levelers to level.


STEP 1

Insert Cam Lock Screws into pre-drilled holes of Side Panel (A), Side Panel (B), Middle Panel (C) and Middle Panel (D) and then tighten. (See Figure 1)




STEP 2


Attach Middle Panels (C) and (D) to Fixed Shelf (L) with Cam Locks. (See Figure 2)



STEP 3

Attach Front Stretcher (I) and Front Stretcher (J) to Front Uprights (K).





STEP 4

Attach Back Uprights (F) to Back Stretcher (H).

Slide Back Panels (E) into place.

Attach Back Stretcher (G) to Front Uprights (F).

STEP 5

Attach unit from Step 2 to unit from Step 4 with Cross Dowels and Head Cap Bolts (long). (See Figure 3)

Attach unit from Step 3 to unit .

Attach Side Panels (A) and (B) to unit with Cam Locks.






Figure 3




STEP 6

Attach Base (M) to unit with Cross Dowels and Head Cap Bolts (long).

Attach Legs (N) to Base (M) with Head Cap Bolts.

STEP 7

Insert Cam Lock Screws into the pre-drilled holes of Top.



STEP 8

Turn the unit to its' upright position.

Place Top onto unit with Cam Locks.

Slide Drawers (T) into position.

Insert Adjustable Pins into side panels and middle panels at the desired level.

Place Shelves (Q) into position.

Attach Knobs to Door (R) and (S) with Machine Screws. (See Figure 4)

Attach Door (R) and (S) to side panels by sliding the door lift hinges into the side panel lift hinges. (See Figure 5)

Assemble Wine Grids (O) and Wine Grids (P). (See Figure 6)

Slide Wine Grid into place.

To level the unit, adjust the adjustable levelers on the bottom of unit. (See Figure 7)





Figure 4




Figure 5




Figure 6





Figure 7



STEP 9

Insert 12X Wood Screws for back panel into pre-drilled holes of back panel.

Attention!

To help reduce the risk of the unit tipping over, the Tipover Restraint must be installed following these instructions exactly!

Place unit at desired location.

Drill a 3/8" hole in wall at the appropriate location.

Insert Anchor into the wall hole and attach Bracket with Wall Screw.

Attach Bracket at pre-drilled hole at top of unit with Wood Screw.

Use Tipover Restraint to secure Bracket on unit to Bracket on wall.
(See Figure X)

Put tie end of Tipover Restraint into loop end of Tipover Restraint and pull until tight.







Figure X




Hardware List



Anchor
1 pc.(+1 extra)



Bracket
2 pcs.(+1 extra)



Tipover Restraint
1 pc.(+1 extra)




**M3.5x40
Wall Screw**
1 pc.(+1 extra)



**M3.5x13
Wood Screw**
1 pc.(+1 extra)

Drawer



STEP 2

Slide T5 into grooves in T3 and T4. Be sure to push T5 all the way forward so it meets T1. (See Figure 2)





Figure 3

STEP 4

Attach Pull Handle with Machine Screws. (See Figure 4)

Tighten all screws used in drawer assembly.



STEP 1

Attach T1, T3 and T4 using a Phillips screwdriver and long Wood Screws (4X), tighten halfway.

Attach T2 to T3 and T4 using long Wood Screws (4X), tighten halfway. (See Figure 1)




Figure 2

STEP 3

Insert short Wood Screws (4X) into pre-drilled holes in T5, tighten screws. (See Figure 3)






Figure 4


Part List



T1.
Front Part
3 Pcs.




T2.
Back Part
3 Pcs.



T3.
Side Part
3 Pcs.



T4.
Side Part
3 Pcs.



T5.
Base Part
3 Pcs.