











# ASSEMBLY INSTRUCTION

## E355 (3A) SMALL X-BASE STOOL


<b>A</b> Side Panel	<b>B</b> Metal Frame	<b>C</b> Stretcher
		
2pcs	1pc	1pc
<b>D</b> Round Finial	<b>E</b> Cushion	<b>F</b> Screw 1/4"x3/4"
		
2pcs	1pc	6pcs
<b>G</b> Screw	<b>H</b> Wood Screw	<b>I</b> Allen Wrench
		
2pcs	4pcs	1pc




This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.

**\*\*\* Do not tighten screws & bolts until the entire unit is completely assembled.**


**1** Attach Metal Frame (B) to Side Panel (A) by using Screw (F) and Allen Wrench (I).



**2** Attach the Stretcher (C) to the hole between the middle of the Side Panel (A) by using Screw (G), and then attach Round Finial (D) as shown.



**3** Fix the assembled metal base on Cushion (E) by using Wood Screw (H) as shown below.



### Cleaning & Care

Treat surface with care. Surface is resistant to scratches but is not scratch resistant. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.