SONDER

LIVING

ALICE PANEL UPHOLSTERED USKING BED

Thank you for choosing this quality product. Be sure to check all packaging materials carefully for small parts that may have become loose during shipment and place all parts on a non-abrasive surface.

<u>IMPORTANT</u>: These parts can be cumbersome and heavy to some people, therefore the assistance of two or more people is recommended in order to prevent personal injury and ensure the furniture is not damaged during the assembly Process.

CARE INSTRUCTIONS


- Dust often using a clean, soft, dry and lint-free cloth.
- 2. Blot spills immediately and wipe with a clean, damp, cloth.
- We do not recommend the use of chemical cleansers, abrasives or furniture polish on our lacquered finish.

IMPORTANT SAFETY INSTRUCTIONS

- 1. Please read all instructions carefully before assembling.
- 2. Keep instructions for future use.
- 3. Use only vendor supplied hardware to assemble. Using unauthorized hardware could jeopardize the structural integrity of the item.


PART LIST

- A [1] HEADBOARD
- B1 [1] LEFT SIDE RAIL
- B2 [1] RIGHT SIDERAIL
- C [1] FOOTBOARD
- D [13] BED SLATS
- E [1] SUPPORT SLATS
- F [3] SUPPORT LEGS



HARDWARE LIST

NO.	DESCRIPTION		QTY
1		ALLEN HEAD BOLT M8X20MM	12 PCS
2	C	LOCKWASHER (Ø14MM)	12 PCS
3		FLAT WASHER (Ø19MM)	12 PCS
4		ALLEN HEAD BOLT M6X15MM	4 PCS
5		LOCK WASHER (Ø10MM)	4 PCS
6	0	FLAT WASHER (Ø12MM)	4 PCS
7		ALLEN WRENCH	1PC



ASSEMBLY INSTRUCTION

The bed is composed of several components: The headboard, foot board, side rails, bed slats, support slats and support legs. Determine the intended location and ensure there is enough space to work with and fully read these instructions before physically doing the entire assembly.

STEP #1:

Place the headboard upright in the position you wish the bed to be in when fully assembled. The headboard bed fast hardware should be facing inside, toward the mattress. Raise the left side rail (B1) up and attach the left side rail (B1) to the headboard (A) by using Allen bolt (1), lock washer (2) and flat washer (3) as per illustrated on **FIGURE 01**.

STFP #2


Repeat the above procedure with the right side rail (B2) to attach it to the headboard (A), and then repeat to connect side rails (B1/B2) to the footboard (C).

STEP #3:

Insert set of the Allen bolt (4) together with Lock washer (5) and Flat washer (6) into the holes of the metal plate installed on the bottom of the side rail as in **FIGURE 02**.

STEP #4:

Attach the short support leg (F) to the slat support (E) by turning it manually, as illustrated in **FIGURE 03**.







FIGURE 03




STEP #5:

On inside face of both headboard (A) and footboard (C) are pre-installed metal brackets for the support slat (E). Set the support slat (E) on the metal brackets, as illustrated in **FIGURE 04**.

STEP #6:

Check the center leg leveling, if it does not seat level, adjust the leveler on the bottom of the support leg, as per illustrated in **FIGURE 05**.



Thank you for your purchase