



# SOLAR GARDEN STAKE

Assembly Instructions



# Step 1:


Attach torch (A) to middle pole (B) by inserting torch into middle pole.





## Step 2:

Attach base (C) to middle pole (B) by inserting stake base into middle pole.





### OPERATION

ON/OFF: The unit is shipped in the OFF position. Remove solar unit from torch by twisting off the solar unit (Photo #1). Locate the switch on the bottom of the unit and slide it from left (OFF position) to right (ON position)(Photo #2). In the ON position, the solar cell will light up automatically at dusk and will shut OFF automatically when the solar panel is exposed to daylight.

Location: Select a sunny location. Place the unit in direct sunlight for at least one day to fully charge the battery. The more direct sunlight your new solar light is exposed to during the day, the longer the light will operate in the evening.

### MAINTENANCE

Cleaning: The solar panel has an epoxy cover that will need to be kept free of dirt and debris, and snow, all the time. Wipe the panel periodically with a damp cloth. Failure to do so will prevent the battery from charging properly, reducing operating time and the life of the battery. Check the battery periodically, especially after winter months, and replace when necessary.


The battery may need to be replaced after a year of continuous use. To replace, remove the white plastic cover by twisting off (Photo #3).

WARNING: For the following step DO NOT fully pull off the cover or the wires will detach. Open the battery compartment by unscrewing the two screws and carefully pulling the battery cover off the unit. (Photo #4 and #5). Replace the battery with a 150mAh Ni-MH 2/3 AAA 1.2V rechargeable battery (Photo #6). The capacity of the replacement battery shall not be less than the recommended capacity. Replace the battery cover and screw two screws in firmly to seal the unit. To replace the white plastic cover, align openings on the cover with tabs on the solar unit and twist the cover to the right. Then replace the solar unit on top of the torch by twisting to the right.

#### Warning:

- Only use rechargeable Ni-MH 2/3 AAA 150mAh 1.2V battery.
- Failure to insert the battery in the correct polarity, as indicated in the battery compartment, may shorten the life of the battery or cause the battery to leak.
- Do not dispose of batteries in fire, or heat, as battery may explode.
- Do not open, short circuit, or mutilate battery, as injury may occur.
- Batteries should be recycled, or disposed of, in accordance with Federal, state and local regulations.
- Electrical rating is 0.05W.




















FOR DECORATIVE USE IN THE GARDEN. NOT TO BE GIVEN TO CHILDREN AS TOY. © 2020 Exhart - Chatsworth, CA 91311. Made in China / Fabrique en Chine. All Rights Reserved. For help please call 1-(800) 775-5503 www.exhart.com