

	Purchase Date:_	1 1	Order/Customer Reference Nu	mbe
--	-----------------	-----	-----------------------------	-----


Thank you for choosing Sunnydaze Decor. We stand behind our brand and the quality of the items we sell. Replacement parts or products can be requested within the 1-year warranty period. Proof of purchase must be provided. This includes the date of the purchase as well as photos of the product defect. Photos are used to determine the cause of the defect and to provide future quality control. The request will be reviewed, and replacement pieces will be sent at our discretion. For warranty information, visit https://tiny.cc/SunnydazeWarranty

If you have any questions, comments or concerns, feel free to contact us by phone at 833-982-1977, by email: customerservice@sunnydazedecor.com, or via our contact us page at https://tiny.cc/SunnydazeContact

DECORATIVE LOG HOLDER QX-2DLH

Review all assembly and care information before using this product. Save this manual for future reference.

Assemble components on a soft, clean surface to avoid damaging the finish.



Inspect packaging to ensure all parts are accounted for before disposing of packing materials.

No.	Parts		QTY.
A		Side Panel	2
В		Base	1
С		M6x40mm Bolt	8
D		Washer	8
Е		M6 Lock Nut	8
F		Spanner	1
G		Phillips Hex Key	1

⚠ WARNING **⚠**

CHOKING HAZARD — This item contains small parts that can be swallowed. Keep children and pets away during assembly.




ASSEMBLY

Review all information and understand assembly before beginning.



IMPORTANT: Lock nuts must be installed with the nylon insert on the outside. Tools are required to fully tighten lock nuts, failure to properly tighten the lock nuts may result in product malfunction or personal injury.



- 1. Align one Side Panel (A) with Base (B) and loosely secure by hand-tightening four M6x40mm Bolts (C), four Washers (D), and four M6 Lock Nuts (E).
- 2. Repeat this process to secure the remaining side panel.
- 3. Fully tighten all hardware using included Spanner (F) and Phillips Hex Key (G).

TIP: To tighten the hardware more quickly, turn the screwdriver in the bolt head clockwise while simultaneously turning the spanner on the lock nut counterclockwise.

🛕 SAFETY STATEMENTS & WARNINGS 🛕

- Place log rack on a hard, dry surface.
- Do not overload the log rack holds approximately 1/8 face-cord of firewood.
- · Ensure fittings are tight before use. Periodically check and tighten hardware as necessary.
- Protect the unit from outdoor elements with a cover. Cover not included.
- Do not allow children to play with or around the log rack.

Any modification to the product or failure to follow recommended care will void the product warranty.

≜WARNING!

Manufacturer and seller expressly disclaim any and all liability from personal injury, property damage or loss, whether direct or indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, or neglect of this product.