


IMPORTANT SAFETY INSTRUCTIONS AND INSTALLATION GUIDE

Work Cage Light



READ BEFORE INSTALLATION
SAVE THESE INSTRUCTIONS

Questions, problems, missing parts? Before returning to the store,
call Feit Electric Customer Service
8 a.m. - 5 p.m., PST, Monday - Friday

1-866-326-BULB (2852)

FEIT.COM

We appreciate the trust and confidence you have placed in Feit Electric through the purchase of this Work Cage Light. We strive to continually create quality products designed to enhance your home. Visit us online to see our full line of products available for your home improvement needs.

Thank you for choosing Feit Electric.

Table of Contents

Table of Contents	2
Safety Information	2
FCC Statement	2
Warranty	2
Pre-Assembly	3
Single Work Cage Light Installation	4
Two or More Work Cage Light Installation	5
Item Settings / Other Information	6

Important Safety Information

READ ALL INSTRUCTIONS

- All Safety and Operating instructions in this manual must be followed before using this product.
- Follow all safe guards stated in the manual, in addition to normal safety precautions in working with electrical devices. Always follow basic safety precautions to reduce the risk of fire, electric shock and personal injury.
- Ground Fault Circuit Interrupter (GFCI) protection is to be provided on the circuit(s) or for the wet location portable luminaire. Receptacles are available having built-in GFCI protection and are able to be used for this measure of safety
- Use only with an extension cord for outdoor use, such as an extension cord of cord type SEW, SEOW, SE00W, SOW, SO0W, STW, STOW, ST00W, SJEW, SJEOW, SJE00W, SJW, SJOW, SJ00W, SJTW, SJTOW, or SJT00W.
- To disconnect, turn off the switch, then remove the plug from the outlet. Do not turn off by pulling on the cord.
- To reduce the risk of fire, keep away from combustible materials while in operation.
- To reduce the risk of injury, close supervision is necessary when this product is used near children.
- This unit is intended to be installed directly beneath a ceiling-mounted receptacle.
- SUITABLE FOR DAMP LOCATIONS

SAVE THESE INSTRUCTIONS



WARNING: RISK OF SHOCK. House electric current can cause painful shock or serious injury unless handled properly.



WARNING: When using outdoor use portable luminaires, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and personal injury.



WARNING: Use only three-wire extension cords that have three-prong grounding plugs and grounding receptacles that accept the appliance's plug. Do not use an extension cord near water or in areas where water may accumulate. Keep away from pools or spas. Keep plugs dry.



CAUTION: This portable light-emitting diode (LED) luminaire has a polarized plug (one blade is wider than the other) as a feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fully fit in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not alter the plug.

Rating: 120V, 60Hz, 100w.

6 Units Maximum to be connected.

Supplier's Declaration of Conformity

47 CFR § 2.1077 Compliance Information

Unique Identifier: WORKCAGE12000PLUG
Responsible Party - U.S Contact Information
FEIT ELECTRIC Co.
4901 GREGG RD. PICO RIVERA, CA, USA 90660-2108
TEL: (562) 463-2852, www.feit.com

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help. Any changes or modifications not expressly approved by the manufacturer could void the user's authority to operate the equipment.


Maintenance and Care

Maintenance of this work light is very minimal. Regularly clean the lens with a non-abrasive cleaning cloth.

Limited Warranty


This product is warranted to be free from defects in workmanship and materials for up to 3 years from date of purchase. If the product fails within the warranty period, please contact Feit Electric at info@feit.com, visit feit.com/contact-us or call 1-866 326-BULB (2852) for instructions on replacement or refund. REPLACEMENT OR REFUND IS YOUR SOLE REMEDY. EXCEPT TO THE EXTENT PROHIBITED BY APPLICABLE LAW, ANY IMPLIED WARRANTIES ARE LIMITED IN DURATION TO THE DURATION OF THIS WARRANTY. LIABILITY FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES IS HEREBY EXPRESSLY EXCLUDED. Some states and provinces do not allow the exclusion of incidental or consequential damages, so the above limitation or exclusion may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state or province to province.

TOOLS REQUIRED




PARTS INCLUDED

NOTE: Parts not shown to actual size.



Part	Description	Quantity
AA	Work Light Body	1
BB	Carabiner Clip (with L-Clamp)	1

PARTS OF THE CAGE WORK LIGHT



Single Work Cage Light Installation

- 1 Find a ceiling where you want to hang the Work Cage fixture (AA). Use a pencil to mark the desired location of your screw hook (not provided) (see Fig. 1). Drill a pilot hole on the marked location (see Fig. 2). Then screw in the screw hook (see Fig. 3).

Fig. 1




Fig. 2







Fig. 3



- 2 Be sure the Carabiner (BB) is in the upright position with the carabiner L-Clamp attached.




- 3 Lift the Work Cage (AA) up and hang the Carabiner (BB) on the screw hook (not provided) installed in the ceiling.



- 4 Tighten the L-Clamp by turning the L-Clamp knob clockwise until a secure connection is made (see Fig. 1). Plug in cord to your ceiling mounted receptacle and the work light will automatically turn on.

Fig. 1



Two or More Work Cage Light Installation

- 1 Find a ceiling where you want to hang the Work Cage fixture (AA). Use a pencil to mark the desired location of your screw hook (Not Provided) (see Fig. 1). Drill a pilot hole on the marked location (see Fig. 2). Then screw in the screw hook (see Fig. 3).

Fig. 1




Fig. 2







Fig. 3




- 2 Be sure the Carabiner (BB) is in the upright position with the carabiner L-Clamp attached.





- 3 Lift the Work Cages (AA) up and hang the Carabiner (BB) on the screw hook (not provided) installed in the ceiling.



- 4 Connect Work Cage fixture using the attached Power Cord.



- 5 Tighten the L-Clamp by turning the L-Clamp knob clockwise until a secure connection is made (see Fig. 2). Plug in cord to your ceiling mounted receptacle and the work light will automatically turn on.



NOTE: Connect a maximum of 6 units together.