

















DELUXE STEEL U-SHAPE HANGING CHAIR STAND TF-554

Read all assembly and care instructions carefully before using this product. Save this manual for future reference.

Assemble components on a soft, clean surface to avoid scratching/damaging the finish.



No.	PARTS	QTY.
1	 Top Pole	2
2	 Bottom Pole	2
3	 Support Bar	1
4	 Left Base Pole	1
5	 Right Base Pole	1
C	 Extension Spring	2
D	 Pin	2
E	 Long Bolt Set	2
F	 Short Bolt Set	10
G	 Foot	8
S	 Washer	20
U	 Bolt	2
A1	 Wrench	1
A2	 3mm Hex Key	1
A3	 4mm Hex Key	1

⚠ WARNING!

CHOKING HAZARD — This item contains small parts that can be swallowed. Keep children away during assembly.

ASSEMBLY



❗ ASSEMBLY TIP

Ensure parts align correctly before fully tightening hardware.

STEP 1

Align Left Base Pole (4) and Right Base Pole (5), as shown.

Fasten the base poles using 2x Short Bolt Set (F) and 4x Washer (S).




STEP 2

Carefully snap Foot (G) onto the base, ensuring they are evenly spaced.


Place 1x Bottom Pole (2) onto the assembled base, ensuring the holes of the pole align with the base.

Use 4x Short Bolt Set (F) and 8x Washer (S) to secure the pole to the base. Secure the second bottom pole the same way.



STEP 3

Slide 2x Top Pole (1) onto the bottom poles, ensuring the holes of the top pole align with the bottom pole. Use 1x Long Bolt Set (E) to fasten each top pole to the bottom pole.



STEP 4

Secure Support Bar (3) between the top poles using 2x Bolt (U).

Place Pin (D) into the top support pole. Insert Extension Spring (C) through the bottom of Pin (D).

USE & CARE

Under normal use, Sunnydaze hammock chair stands will last for years. It is important to follow basic use & care tips to prolong the life of your stand.


- **SAFE USE:** Do not use this chair stand for swinging, bouncing, jumping, twisting, or other excessive movements; doing so may cause serious injury, including, but not limited to, the stand tipping over.
- **CHILDREN:** Supervise children at all times. Do not allow children to play on or sleep in any hanging chair. Chair not included.
- **INSPECTION:** Ensure the stand is assembled correctly and all hardware is securely tightened before each use.
- **CLEANING:** Use a soft cloth, warm water and soap to wipe down the stand if necessary. Dry the stand after cleaning to prevent rust.
- **SCRATCHES:** The powder coating on the stand is tough and durable but, even under normal use, some scratching is inevitable. To avoid excessive rust, wipe these areas as needed to remove moisture.
- **STORAGE:** Store the stand indoors when not in use. Cool, dry locations are recommended to prevent damage and rust that may result from exposure to moisture.

TROUBLESHOOTING

- If the stand feels unstable, make sure it is on a level surface and the feet are correctly and evenly distributed.
- If the stand is making noise when in use, check to make sure all hardware is fully tightened.

! SAFETY STATEMENTS & WARNINGS !

- Do not exceed the weight capacity: 550 lbs
- Do not swing, bounce, jump, twist, or spin in any hanging chair while using this stand. This stand was designed for sitting calmly in an hanging chair. Chair not included.
- This chair stand must be used with all provided parts. Install all parts in accordance with the assembly instructions.
- Ensure all hardware is properly installed and securely tightened before each use.
- Always inspect the stand and hardware for damage before each use.
- Do not allow children to use this product without adult supervision.
- When in use, the chair (not included) should remain inside the base area at all times. A diagram of the base area is shown on the right.



Any modification to the product or failure to follow recommended care will void the product warranty.

! WARNING:

Manufacturer and seller expressly disclaim any and all liability from personal injury, property damage or loss, whether direct or indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, or neglect of this product.