



INSTRUCTION MANUAL

Metal Twin Bed Frame with Scroll Design

Ver. 2 SKY4452



As shoppers, we're always trying to find the perfect balance between quality & value. At BCP, we believe we've achieved that. Our diverse catalog of everyday essentials is tailored especially to our customers & guaranteed to hit that sweet spot of high quality & low price.

Always.

(!) NOTICE

Please retain these instructions for future reference.

- Please do not exceed the weight limitations of this item.
- Do not stand on or use any part of this product as a step ladder.
- Firmly secure all bolts, screws and knobs before use.
- Reconfirm that all bolts, screws, and knobs are secure every 90 days.
- Fasten screws loosely during assembly. Do not firmly tighten screws until item is fully assembled.
- Be aware that some parts are heavy and have sharp edges.
- If any parts are missing, broken, damaged, or worn, stop using this product until repairs are made and/or factory replacement parts are installed.
- Do not use this item in a way inconsistent with the manufacturer's instructions as this could void the product warranty.

TOOLS REQUIRED







HARDWARE













PARTS



PARTS




PRODUCT ASSEMBLY

Ex2


Attach two part C headboard legs to a part E headboard/footboard with four part 3 screws. Attach two part D footboard legs to a headboard/footboard with four part 3 screws.



Attach two part A and two part B side frames with eight part 1 screws and four part 3 screws.




Attach the sides frames together with two part O connecting plates and four part 2 screws.






Attach the part F center support with four part 2 screws. Attach two part N center legs with four part 4 screws and four part 5 nuts.






Insert two part I and two part J canopy posts. Secure the canopy posts with four part 2 screws.




Attach two part K top frames with four part 2 screws.






Attach two part L and two part M top side frames with four part 2 screws. Secure the top side frames to each other with two part 2 screws.

Screw on four part P finials.




Attach four part G bed slats with eight part 4 screws.





Insert twenty part ${\bf Q}$ brackets onto ten part ${\bf H}$ bed slats. Insert the brackets into the designated holes on the side frames.





Check out more great products: **bestchoiceproducts.com**

Earn points while you shop. Join today!

bestchoice products reward\$

Join | Earn | Redeem

Give your friends 15% off their first order! For each successful referral you'll receive 100 points.

bestchoiceproducts.com



Question about your product? We're here to help. Visit us at:

help.bestchoiceproducts.com











Chat Support

Product Inquiry

Orders FA

roduct Assembly Returns & Refunds

PRODUCT WARRANTY INFORMATION

All items can be returned for any reason within 60 days of the receipt and will receive a full refund as long as the item is returned in its original product packaging and all accessories from its original shipment are included. All returned items will receive a full refund back to the original payment method. All returned items will not be charged a re-stocking fee.

All returned items require an RA (Return Authorization) number, which can only be provided by a Best Choice Products Customer Service Representative when the return request is submitted. Items received without an RA may not be accepted or may increase your return processing time. Once an item has been received by Best Choice Products, refunds or replacements will be processed within 5 business days.

All returns must be shipped back to the Best Choice Products Return Center at the customer's expense. If the reason for return is a result of an error by Best Choice Products then Best Choice Products will provide a pre-paid shipping label via email. Boxes for return shipping will not be provided by Best Choice Products, and is the customer's responsibility to either use the original shipping boxes or purchase new boxes.

Pictures may be required for some returns to ensure an item is not damaged prior to its return. Items returned are not considered undamaged until they are received by Best Choice Products and verified as such. All damages to items are the customer's responsibility until the item has been received by and acknowledge by Best Choice Products as undamaged.

△WARNING

Manufacturer and seller expressly disclaim any and all liability for personal injury, property damage or loss, whether direct, indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, or neglect of this product.