FOREST RIDGE PLAYSET - F29065E

INSTALLATION AND OPERATING INSTRUCTIONS

29'-9" (9.08M)
16'-8" (5.08M)
27'-0" (8.23M)
7'-6" (2.29M)

⚠ WARNING

To reduce the risk of serious injury or death, you must read and follow these instructions. Keep and refer to these instructions often and give them to any future owner of this play system. Manufacturer contact information provided below.

OBSTACLE FREE SAFETY ZONE - **29'9" (9.08m) x 27' (8.2m)** area requires Protective Surfacing. See Owner's Manual.

MAXIMUM VERTICAL FALL HEIGHT - **6'9"(2.06m)**

CAPACITY - **10** Users Maximum, Ages **3** to **10**; Weight Limit **110 lbs. (49.9 kg)** per child.

RESIDENTIAL HOME USE ONLY. Not intended for public areas such as schools, churches, nurseries, day cares or parks.
Warning. Only for domestic use.

TUBE SLIDE

2-4 Hrs

Two person assembly

FORT

10-14 Hrs

TWO PERSON ASSEMBLY

For Outdoor Family Domestic Use Only

KidKraft®

KidKraft, Inc.
4630 Olin Road
Dallas, Texas 75244 USA
customerservice@kidkraft.com
canadacustomerservice@kidkraft.com
1.800.933.0771
972.385.0100
For online parts replacement visit
https://parts.kidkraft.com/

KidKraft Netherlands BV
Olympisch Stadion 29
1076DE Amsterdam
The Netherlands
europecustomerservice@kidkraft.com
+31 20 305 8620 M-F from 09:00 to 17:30 (GMT+1)
For online parts replacement visit
https://parts.kidkraft.eu/

Table of Contents

9409065E   Rev 01/14/2019

Warnings and Safe Play Instructions

⚠ **CONTINUOUS ADULT SUPERVISION REQUIRED.** Most serious injuries and deaths on playground equipment have occurred while children were unsupervised! Our products are designed to meet mandatory and voluntary safety standards. Complying with all warnings and recommendations in these instructions will reduce the risk of serious or fatal injury to children using this play system. Go over the warnings and safe play instructions regularly with your children and make certain that they understand and follow them. Remember on-site adult supervision is required for children of all ages.

⚠ WARNING

SERIOUS HEAD INJURY HAZARD
Installation over concrete, asphalt, dirt, grass, carpet and other hard surface creates a risk of serious injury or death from falls to the ground. Install and maintain shock absorbing material under and around play-set as recommended on page 3 of these instructions.

COLLISION HAZARD
Place play-set on level ground at least 2m from any obstruction such as a garage or house, fences, poles, trees, sidewalks, walls, landscape timbers, rocks, pavement, planters, garden borders, overhanging branches, laundry lines, and electrical wires. (See OBSTACLE FREE SAFETY ZONE on cover)

CHOKING HAZARD/SHARP EDGES & POINTS
Adult assembly required. This product contains small parts and parts with sharp edges and points. Keep parts away from children until fully assembled.

WARNING LABEL
Owners shall be responsible for maintaining the legibility of the warning labels.

STRANGULATION HAZARD
• NEVER allow children to play with ropes, clotheslines, pet leashes, cables, chains or cord-like items when using this play-set or to attach these items to play-set.
• NEVER allow children to wear loose fitting clothing, ponchos, hoods, scarves, capes, necklaces, items with draw-strings, cords or ties when using this play-set.
• NEVER allow children to wear bike or sport helmets when using this play-set.

Failure to prohibit these items, even helmets with chin straps, increases the risk of serious injury and death to children from entanglement and strangulation.

TIP OVER HAZARD
Choose a level location for the equipment. This can reduce the likelihood of the play set tipping over and loose-fill surfacing materials washing away during heavy rains.

DO NOT allow children to play on the play-set until the assembly is complete and the unit is properly anchored.

Never add extra length to chain or rope. The chains or ropes provided are the maximum length designed for the swinging element(s).

⚠ WARNING – Safe Play Instructions

✓ Observe capacity limitations of your play-set. See front cover.

✓ Dress children with well fitting and full foot enclosing footwear.

✓ Teach children to sit with their full weight in the center of the swing seat to prevent erratic swing motion or falling off.

✓ Check for splintered, broken or cracked wood; missing, loose, or sharp edged hardware. Replace, tighten and or sand smooth as required prior to playing.

✓ Verify that suspended climbing ropes, rope ladders, chain or cable are secured at both ends and cannot be looped back on itself as to create an entanglement hazard.

✓ On sunny and or hot days, check the slide and other plastic rides to assure that they are not very hot as to cause burns. Cool hot slide and rides with water and wipe dry prior to using.

✓ Orientate slide such that it gets the least amount of exposure to the sun.

✖ Do not allow children to wear open toe or heel footwear like sandals, flip–flops or clogs.

✖ Do not allow children to walk, in front, between, behind or close to moving rides.

✖ Do not let children twist swing chains or ropes or loop them over the top support bar. This may reduce the strength of the chain or rope and cause premature failure.

✖ Do not let children get off rides while they are in motion.

✖ Do not permit climbing on equipment when it is wet.

✖ Do not permit rough play or use of equipment in a manner for which it was not intended. Standing on or jumping from the roof, elevated platforms, swings, climbers, ladders or slide can be dangerous.

✖ Do not allow children to swing empty rides or seats.

✖ Do not allow children to go down slide head first or run up slide.

⚠️Protective Surfacing - Reducing Risk of Serious Head Injury From Falls.

One of the most important things you can do to reduce the likelihood of serious head injuries is to install shock-absorbing protective surfacing under and around your play equipment. The protective surfacing should be applied to a depth that is suitable for the equipment height in accordance with ASTM F1292. There are different types of surfacing to choose from; whichever product you select, follow these guidelines:

Loose-Fill Materials

• Maintain a minimum depth of 9 inches of loose-fill materials such as wood mulch/chips, engineered wood fiber (EWF), or shredded/recycled rubber mulch for equipment up to 8 feet high; and 9 inches of sand or pea gravel for equipment up to 5 feet high. NOTE: An initial fill level of 12 inches will compress to about a 9-inch depth of surfacing over time. The surfacing will also compact, displace, and settle, and should be periodically raked and refilled to maintain at least a 9-inch depth.

• Use a minimum of 6 inches of protective surfacing for play equipment less than 4 feet in height. If maintained properly, this should be adequate. (At depths less than 6 inches, the protective material is too easily displaced or compacted.)

> NOTE: Do not install home playground equipment over concrete, asphalt, or any other hard surface. A fall onto a hard surface can result in serious injury to the equipment user. Grass and dirt are not considered protective surfacing because wear and environmental factors can reduce their shock absorbing effectiveness. Carpeting and thin mats are not adequate protective surfacing. Ground level equipment -- such as a sandbox, activity wall, playhouse or other equipment that has no elevated play surface -- does not need any protective surfacing.

• Use containment, such as digging out around the perimeter and/or lining the perimeter with landscape edging. Don't forget to account for water drainage.

• Periodically rake, check and maintain the depth of the loose-fill surfacing material. Marking the correct depth on the play equipment support posts will help you to see when the material has settled and needs to be raked and or replenished. Be sure to rake and evenly redistribute the surfacing in heavily used areas.

• Do not install loose fill surfacing over hard surfaces such as concrete or asphalt.

## Poured-In-Place Surfaces or Pre-Manufactured Rubber Tiles

You may be interested in using surfacing other than loose-fill materials - like rubber tiles or poured-in-place surfaces.

• Installations of these surfaces generally require a professional and are not "do-it yourself" projects.

• Review surface specifications before purchasing this type of surfacing. Ask the installer/manufacturer for a report showing that the product has been tested to the following safety standard: ASTM F1292 *Standard Specification for Impact Attenuation of Surfacing Materials within the Use Zone of Playground Equipment.* This report should show the specific height for which the surface is intended to protect against serious head injury. This height should be equal to or greater than the fall height - vertical distance between a designated play surface (*elevated surface for standing, sitting, or climbing*) and the protective surfacing below - of your play equipment.

• Check the protective surfacing frequently for wear.

Placement

Proper placement and maintenance of protective surfacing is essential. Refer to diagram on front cover. Be sure to;

• Extend surfacing at least 2m from the equipment in all directions.

• For to-fro swings, extend protective surfacing in front of and behind the swing to a distance equal to twice the height of the top bar from which the swing is suspended.

• For tire swings, extend surfacing in a circle whose radius is equal to the height of the suspending chain or rope, plus 6 feet in all directions.

Denotes Use Zone with Protective Surfacing

Use Zone for Single-Axis Swings

Denotes Use Zone with Protective Surfacing

Use Zone for Multi-Axis Swings

From the CPSC Outdoor Home Playground Safety Handbook. At http://www.playgroundregs.com/resources/CPSC%20324.pdf

Instructions for Proper Maintenance

Your KidKraft Play System is designed and constructed of quality materials with your child's safety in mind. As with all outdoor products used by children, it will weather and wear. To maximize the enjoyment, safety and life of your Play Set, it is important that you, the owner, properly maintain it.

Check the following at the beginning of the play season:

HARDWARE:
- ✓ Check metal parts for rust. If found, sand and repaint using a non-lead paint complying with 16 CFR 1303.
- ✓ Inspect and tighten all hardware. On wood assemblies DO NOT OVER-TIGHTEN as to cause crushing and splintering of wood.
- ✓ Check for sharp edges or protruding screw threads, add washers if required.

If Bolt protrudes beyond T-Nut

Use an extra Flat Washer

SHOCK ABSORBING SURFACING:
- ✓ Check for foreign objects. Rake and check depth of loose fill protective surfacing materials to prevent compaction and maintain appropriate depth. Replace as necessary. (See Protective Surfacing, page 3)

GROUND STAKES (ANCHORS):
- ✓ Check for looseness, damage or deterioration. Should firmly anchor unit to ground during use. Re-secure and or replace, if necessary.

SWING HANGERS:
- ✓ Check that bolts are secure and tight. Quick clips should be completely closed and threaded clips screwed tight.
- ✓ If squeaking occurs lubricate bushings with oil or WD-40®.

SWINGS, ROPES AND RIDES:
- ✓ Reinstall if removed during cold season. Check all moving parts including swing seats, ropes, chains and attachments for wear, rust and other deterioration. Replace as needed.
- ✓ Check that ropes are tight, secure at both ends and cannot loop back as to create an entrapment.

WOOD PARTS:
- ✓ Check all wood members for deterioration, structural damage and splintering. Sand down splinters and replace deteriorated wood members. As with all wood, some checking and small cracks in grain is normal.
- ✓ Unprotected, they will appear weathered over time. Periodic application of an exterior water repellent or stain (water-based) will help improve appearance and life.

Check twice a month during play season:

HARDWARE:
- ✓ Inspect for tightness. Must be firmly against, but not crushing the wood. DO NOT OVER-TIGHTEN. This will cause splintering of wood.
- ✓ Check for sharp edges or protruding screw threads. Add washers if required.

SHOCK ABSORBING SURFACING:
- ✓ Rake and check depth of loose fill protective surfacing materials to prevent compaction and maintain appropriate depth. Replace as necessary. (See Protective Surfacing, page 3)

Check once a month during play season:

SWING HANGERS:
- ✓ Check that they are secure and orientated correctly. Hook should rotate freely and perpendicular to support beam.
- ✓ If squeaking occurs lubricate bushings with oil or WD-40®.

SWINGS AND RIDES:
- ✓ Check swing seats, all ropes, chains and attachments for fraying, wear, excessive corrosion or damage. Replace if structurally damaged or deteriorated.

Check at the end of the play season:

SWINGS AND RIDES:
- ✓ To prolong their life, remove swings and store inside when outside temperature is below 32°F/0°C. Below freezing, plastic parts may become more brittle.

SHOCK ABSORBING SURFACING:
- ✓ Rake and check depth of loose fill protective surfacing materials to prevent compaction and maintain appropriate depth. Replace as necessary. (See Protective Surfacing, page 3)

If you dispose of your play set: Please disassemble and dispose of your unit so that it does not create any unreasonable hazards at the time it is discarded. Be sure to follow your local waste ordinances.

About Our Wood

KidKraft Premium Play Systems uses only premium playset lumber, ensuring the safest product for your children's use. Although we take great care in selecting the best quality lumber available, wood is still a product of nature and susceptible to weathering which can change the appearance of your set.

What causes weathering? Does it affect the strength of my Play System?

One of the main reasons for weathering is the effects of water (moisture); the moisture content of the wood at the surface is different than the interior of the wood. As the climate changes, moisture moves in or out of the wood, causing tension which can result in checking and or warping. You can expect the following due to weathering. These changes will not affect the strength of the product:

1. **Checking** is surface cracks in the wood along the grain. A post (4" x 4") will experience more checking than a board (1" x 4") because the surface and interior moisture content will vary more widely than in thinner wood.
2. **Warping** results from any distortion (twisting, cupping) from the original plane of the board and often happens from rapid wetting and drying of the wood.
3. **Fading** happens as a natural change in the wood color as it is exposed to sun-light and will turn a grey over time.

How can I reduce the amount of weathering to my Play System?

At the factory we have coated the wood with a water repellent or stain. This coating decreases the amount of water absorption during rain or snow thus decreasing the tension in the wood. Sunlight will break down the coating, so we recommend applying a water repellent or stain on a yearly basis (see your local stain and paint supplier for a recommended product).

Most weathering is just the normal result of nature and will not affect safe play and enjoyment for your child. However if you are concerned that a part has experienced a severe weathering problem please call our consumer relations department for further assistance.

Complete and mail registration card to receive important product notifications and assure prompt warranty service.

5 Year Limited Warranty

KidKraft warrants that this product is free from defect in materials and workmanship for a period of one year from the original date of purchase. In addition, lumber is warranted for 5 years against structural failure due to rot and insect damage. All other parts, such as hardware, swings, rides, accessories, and slides carry a one-year warranty only.

This warranty applies to the original owner and registrant and is non-transferable.

Regular maintenance is required to assure the integrity of your Play System. This warranty does not cover any inspection cost.

This Limited Warranty does not cover:
  • Labor for replacement of any defective item(s);
  • Incidental or consequential damages;
  • Cosmetic defects which do not affect performance or integrity;
  • Vandalism; improper use or installation; acts of nature;
  • Minor twisting, warping, checking, or any other natural occurring properties of wood that do not affect performance or integrity.

KidKraft products have been designed for safety and quality. Any modifications made to the original product could damage the structural integrity of the unit leading to failure and possible injury. Kidkraft cannot assume any responsibility for modified products. Furthermore, modification voids any and all warranties.

This product is warranted for **RESIDENTIAL USE ONLY**. Under no circumstance should a KidKraft Play System be used in public settings such as schools, churches, playgrounds, parks, day cares and the like. Such use may lead to product failure and potential injury. Any and all public use will void this warranty.

KidKraft disclaims all other representations and warranties of any kind, express or implied.

This Warranty gives you specific legal rights. You may have other rights as well which vary from state to state or province to province. This warranty excludes all consequential damages, however, some states do not allow the limitation or exclusion of consequential damages, and therefore this limitation may not apply to you.

Keys to Assembly Success

Tools Required

• Tape Measure
• Carpenters Level
• Carpenters Square
• Claw Hammer
• Standard or Cordless Drill
	• #1, #2 & #3 Phillips
	  or Robertson Bits
	  or Screwdriver
	• Ratchet with extension
	  (1/2" & 9/16" sockets)
		• Open End Wrench
		  (7/16", 1/2" & 9/16")
		• Adjustable Wrench
		• 1/8" & 3/16" Drill Bits
		• Pencil
			• 3/16" Hex Key
			• 8' Step Ladder
			• Safety Glasses
			• Adult Helpers

Part Identification Key

On each page, you will find the parts and quantities required to complete the assembly step illustrated on that page. Here is a sample.

2X 012 **Post 2 x 4 x 83"**

Quantity — Key Number — Part Description, Part Size

Key Number: The first two digits represent the step number. The third digit represents the piece. Note that if the part is used in multiple steps then the number only reflects the first step it is used in.

Symbols

Throughout these instructions symbols are provided as important reminders for proper and safe assembly.

This identifies information that requires special attention. Improper assembly could lead to an unsafe or dangerous condition.

Use Help

Use Help

Where this is shown, 2 or 3 people are required to safely complete the step. To avoid injury or damage to the assembly make sure to get help!

Measure Distance

Check that assembly is square before tightening bolts.

Use a measuring tape to assure proper location.

Square Assembly

Check that set or assembly is properly level before proceeding.

Use Level

Pre-drill 1/8" & 3/16" Bit

1/8   3/16

Pre-drill a pilot hole before fastening screw or lag to prevent splitting of wood.

Tighten Bolts

This indicates time to tighten bolts, but not too tight! Do not crush the wood. This may create splinters and cause structural damage.

⚠ CAUTION – Protrusion Hazard

No   Yes

Once the assembly is tightened, watch for exposed threads. If a thread protrudes from the T-Nut, remove the bolt and add washers to eliminate this condition. Extra washers have been provided for this purpose.

If Bolt protrudes beyond T-Nut

Use an extra Flat Washer

Proper Hardware Assembly

Lag Assembly

Lag screws require drilling pilot holes to avoid splitting wood. Only a flat washer is required. For ease of installation liquid soap can be used on all lag-type screws.

Lag Screw

Before mounting Lag Screw, use factory drilled holes as guides to drill 1/8" pilot holes

Flat Washer

For bolts, tap T-Nut into hole with hammer. Insert the hex bolt through lock washer first then flat washer then hole. Because the assemblies need to be squared do not completely tighten until instructed. Pay close attention to diameter of the bolts. 5/16" is slightly larger than 1/4".

Note: Wafer head bolts with blue lock tight or a bolt with a Ny-Lok nut do NOT require a lock washer.

Bolt Assembly

Hex Bolt

Lock Washer

Flat Washer

T-Nut (Hammer into place) **Do not crush wood!**

Your Key To Quick Assembly

SORTING WOOD PARTS INTO EACH ASSEMBLY STEP WILL SAVE TIME!

↑ Step   ↑ Step   ↑ Step

SAVE TIME - TIP #1:

Wood parts are found in Box 2, 3, 4 & 5. Open each box with wood parts and look for the Key Number stamped on the end of the wood part (see chart below). Sort each wood part into the different assembly steps.

2X   **012**   **Post**   **2 x 4 x 83"**

↑ Part Quantity   ↑ Key Number   ↑ Part Description   ↑ Part Size

Step Number (This is Step 1)	01	2	Order Listed (The order the part is listed in step 1)

Key Number: The first two digits represent the step number. The third digit represents the order in which the part is listed in the step.

Note that if the part is used in multiple steps then the key number only reflects the first step it is used in.

SAVE TIME - TIP #2:

In addition to the key number stamp, you can also identify the wood parts by using the Parts Identification pages in the manual.

HARDWARE:

The majority of each hardware part comes packed in a separate bag so you do not need to sort the hardware. Each assembly step indicates which hardware (bolt, screw, washer etc.) you will require to complete the step.

Part Identification (Reduced Part Size)

2pc. - 2756
Siding Assembly 1¼ x 19-15/16 x 39-3/16"
(32 x 506 x 995mm) 37632756

2pc. - 649A
Short Half Wall - 1.27 x 18.8 x 20-15/16"
(32 x 477 x 532mm) 37632649A

1pc. - 2658 - 2-13/32 x 6-3/4 x 34"
(61 x 171 x 864mm) Folding Bench **37632658**

1x - KidKraft
ID Plaque
(9320370)

1pc. - 2611 - 5/4 x 5 x 39-5/8" - Table Top
(25 x 108 x 1006mm) **3632611**

1pc. - 2602 -Upper Jamb 1¼ x 3 x 35-15/16"
(32 x 76 x 913mm) **3632602**

1pc. - 2665
Half Wall Insert - 1.4 x 20¼ x 38.8"
(36 x 514 x 986mm) 37632665

1pc. - 2612 - 2 x 2 39-5/8" - Table Support
(38 x 38 x 1006mm) **3632612**

1pc. - 2601 -Lower Jamb 1¼ x 3 x 41-15/16"
(32 x 76 x 1065mm) **3632601**

1x - Hole Plug
(16pk) (3329916)

1x - Hand Grip
Yellow (9320240)

2pc. - 2717 - Clock Block 3/4 x 1-3/4 x 9-3/4"
(19 x 44 x 248mm) **3632717**

1x - Window Mesh Set
(3750188)

2pc. - 2655
Upper Window Insert
1.27 x 18.8 x 35.86"
(32 x 478 x 911mm) 37632655

3x -17 x 19"
(432 x 483mm)
Mesh (9750188)

1x - Frame (9200193)

1x - Canopy
(9754900)

1pc.
MOD 3 Pane Transom
(2Pk) 3320138

1x -15½ x 39"
(394 x 991mm)
Mesh (9750189)

1x - Cafe Canopy Set (3754900)

1x - L Beam Brkt.
(3200145) (2pk)

1x - Jamb Mount (4 Pk)
(3206302)

1x - Acro Rope
(2 pk) (3502024)

2x - Long Belt Swing
(3724947)
Yellow

1x - Clock Subset
(3320329)

1x - Quick Link
(Threaded)(4pk)
(3200020)

1x - Rebar Ground
Stake (6 Pk)
(3200318)

1x - Steel
Acro Bar
(9200131)

1x - Swing Hanger (6 Pk)
(3206106)

1x - Base Clock
(9320124)

**2x** - Acro Handle
(9320131)

1x - Rocks (5pk)
(3320386)

1pc. - 2649
Lower Window Insert 1.27 x 18.8 x 41.91"
(32 x 478 x 1065mm) 37632649

1x - Beam Brkt. Set
(3200143) (2pk)

Add On D Hardware (Actual Size)

9pc. (LW2) - 5/16" (8mm) Lock Washer - (51303300)

41pc. (LW1) - 1/4"(6mm) Lock Washer - (51303200)

24pc. (LN2) - 5/16"(8mm) Lock Nut (54303300)

5pc. (PB2) - Pan Bolt 1/4 x 1-1/4" (53433212) (6 x 32mm)

5pc. (FW0) - 3/16" (5mm) Flat Washer - (51103100)

42pc. (FW1) - 1/4"(6mm) Flat Washer - (51103200)

60pc. (FW2) - 5/16" (8mm) Flat Washer - (51103300)

62pc. (FW3) - #8 Flat Washer - (51003500)

36pc. [TN1] - 1/4" (6mm) T - Nut (54503200)

10pc. [TN2] - 5/16" (8mm) T- Nut (54503300)

5pc. [BN1] - 1/4" (6mm) Barrel Nut (54803200)

1pc. [D4] - 2 x 2 (51 x 51mm) Robertson Driver Bit (9200014)

87pc. (S0) - Truss Screw #8 x 7/8" - (52933505) (#8 x 22mm)

66pc. (S5) - Pan Screw #8 x 1/2" - (52433502) (#8 x 13mm)

5pc. (S10) - Pan Screw #8 x 1"(#12 x 25mm) (52433510)

2pc. (S6) - Pan Screw #12 x 1"(#12 x 25mm) (52433610)

13pc. (S7) - Pan Screw #12 x 2" - (52433620) (#12 x 51mm)

65pc. (S30) - Wood Screw #8 x 1-1/16" - (52043517) (#8 x 27mm)

84pc. (S20) - Wood Screw #8 x 1-3/8" - (52043516) (#8 x 35mm)

4pc. -(S2) -Wood Screw #8 x 1 1/2" - (9260512)

4pc. (S11) - Wood Screw #8 x 2" - (52043520) (#8 x 51mm)

10pc. (S3) - Wood Screw #8 x 2-1/2" - (52043522) (#8 x 64mm)

4pc. (S4) - Wood Screw #8 x 3" - (52043530) (#8 x 76mm)

Add On D Hardware (Actual Size)

2pc. ⟨WB1⟩ - Wafer Bolt 5/16 x 1" - (53613310)
(8 x 25mm)

**3pc.** ⟨WB7⟩ - Wafer Bolt 5/16 x 3" (8 x 76mm) - (53613330)

**24pc.** ⟨H9⟩ - Hex Bolt 1/4 x 1-1/4" - (53703211)
(6 x 32mm)

**2pc.** ⟨WL3⟩ - Wafer Lag 1/4 x 1-3/8"- (52613216)
(6 x 35mm)

**4pc.** ⟨H1⟩ - Hex Bolt 1/4 x 1-1/2" - (53703212)
(6 x 38mm)

16pc. ⟨WL5⟩ - Wafer Lag 1/4 x 2-1/2"- (52613222)
(6 x 64mm)

**4pc.** ⟨H10⟩ - Hex Bolt 1/4 x 2-1/4" - (53703221)
(6 x 57mm)

4pc. ⟨H11⟩ - Hex Bolt 1/4 x 2-3/4" - (53703223)
(6 x 70mm)

2pc. ⟨LS3⟩ - Lag Screw 1/4 x 3" - (9272223)
(6 x 76mm)

**4pc.** ⟨G8⟩ - Hex Bolt 5/16 x 2"- (53703320)
(8 x 51mm)

7pc. ⟨G21⟩ - Hex Bolt 5/16 x 3-3/4" - (53703333)
(8 x 95mm)

3pc. ⟨G4⟩ - Hex Bolt 5/16 x 4" - (53703340)
(8 x 102mm)

14pc. ⟨G7⟩ - Hex Bolt 5/16 x 5-1/2" - (53703352)
(8 x 140mm)

Part Identification (Reduced Part Size)

1pc. - 2648 - 1 x 4 x 40-5/8 (16 x 86 x 1032mm)- Floor Board **3632648**

8pc. - 2609 - 1 x 5 x 40-5/8"(16 x 114 x 1032mm) - Floor Board **3632609**

2pc. - 2780 - 1 x 6 x 19" (16 x 137 x 483mm) RK Board A **3632780**

2pc. - 2779 - 1 x 6 x 19"(16 x 137 x 483mm) Access Board **3632779**

3pc. - 2781 - 1 x 6 x 19" (16 x 137 x 483mm) RK Board B **3632781**

2pc. - 2778 - 5/4 x 4 x 14¼" (25 x 89 x 362) SW Ground MOD **3632778**

**1pc. - 2616** - 5/4 x 4 x 46-1/2" (25 x 89 x 1181mm) SW Support **3632616**

2pc. - 2777 - 2 x 2 x 40-1/4" (38 x 38 x 1022mm) - Side Joist MOD **3632777**

2pc. - 2607 - 1-1/4 x 3 x 22" (32 x 76 x 559mm) - Diagonal **3632607**

**2pc. - 2776** - Rock Rail 1¼ x 2½ x 51" (32 x 64 x 1295mm) **3632776**

1pc. - 2608 - 1-1/4 x 3 x 40-3/4" (32 x 76 x 1035mm) - Floor Joist **3632608**

3pc. - 2770 - End Post Left 1¼ x 2½ x 87" (32 x 64 x 2210mm) **3632770**

3pc. - 2771 - End Post 1¼ x 2½ x 87" (32 x 64 x 2210mm) **3632771**

2pc. - 2772 - Panel Floor Support 1¼ x 3 x 42" (32 x 76 x 1067mm) **3632772**

2pc. 2775 Panel Cross Support 1¼ x 3 x 42" (32 x 76 x 1067mm) **3632775**

5pc. - 2769 - Panel BT Frame 1¼ x 3 x 42" (32 x 76 x 1067mm) **3632769**

2pc. - 2768 - Panel Floor 1¼ x 3 x 42" (32 x 76 x 1067mm) **3632768**

2pc. - 2774 - Upright 1¼ x 3 x 42" (32 x 76 x 1067mm) **3632774**

1pc. - 2630 - SW Top 1¼ x 5½ x 42" (32 x 140 x 1067mm) **39632630**

2pc. - 2613 - 2 x 3 x 86-11/16" (51 x 76 x 2202mm) - Heavy SW Post **3632613**

1pc. - 2615 - 4 x 4 x 50-15/16" - (76 x 76 x 1294mm) SW Upright **3632615**

1pc. - 2614 - 4 x 6 x 88" - (76 x 133 x 2235mm) Engineered Beam **3632614**

1pc. - 2757
LT Post Assembly
1¼ x 2½ x 87"
(32 x 64 x 2210mm)
37632757

1pc. - 2758
RT Post Assembly
1¼ x 2½ x 87"
(32 x 64 x 2210mm)
37632758

Part Identification (Reduced Part Size)

4pc. - 2759 Roof End 1-1/4 x 3 x 10" (32 x 76 x 254mm)
3632759

4pc. - 2760 - Roof Support 1¼ x 2¼ x 37½" (32 x 57 x 953mm)
3632760

2pc. - 2761 - Roof Sleeper C ¾ x 2 x 35" (19 x 51 x 889mm)
3632761

2pc. - 9450 - Roof Tie 1-1/4 x 2 x 7-9/16"
(31.8 x 50.8 x 192mm) **3639450**

2x - Sky Gable (3320212)

1pc. - 2752 - MOD Roof Front 1¼ x 20-7/16 x 44"
(32 x 519 x 1118mm) **37632752**

1pc. - 2753 - MOD Roof Back 1¼ x 20-13/64 x 44"
(32 x 513 x 1118mm) **37632753**

2pc. - 2751 - MOD Roof Bottom 1-3/16 x 16 25/32 x 44"
(30 x 426 x 1118mm) **37632751**

4pc. H3 - Hex Bolt 1/4 x 2-1/2"
(6 x 64mm)(53703222)

8pc. S20 - Wood Screw #8 x 1-3/8" - (52043516)
(#8 x 35mm)

32pc. S11 - Wood Screw #8 x 2" (52043520) (#8 x 51mm)

6pc. S0 - Truss Screw #8 x 7/8"
(#8 x 22mm) (52933505)

8pc. S3 - Wood Screw #8 x 2-1/2" (52043522) (#8 x 64mm)

8pc. S5 - Pan Screw #8 x 1/2"
(#8 x 13mm) (52433502)

1x - Narrow Angle Bracket (3 Pk)
(3200640)

2pc. S4 - Wood Screw #8 x 3" (52043530) (#8 x 76mm)

TNR3 (Reduced Part Size)

(1) SL Gusset 1¼ x 3 x 15¾" (32 x 76 x 400mm)

| 8934 | 3638934 |

(1) Lower SL Insert 1.36 x 8-1/8 x 26¼"
(34 x 206 x 667mm)

37638935

8935

(1) TNR Upright 1¼ x 3 x 20¼" (32 x 76 x 514mm)

| 8965 | 3638965 |

(1) TNR Ground Brace 1¼ x 3 x 32¼" (32 x 76 x 819mm)

| 8963 | 3638963 |

TNR3 (Actual Size)

94pc. (PB1) - Pan Bolt 1/4 x 3/4" (6 x 19mm)
(53453203)

1pc. (PB6) - Pan Bolt 1/4 x 1" (6 x 25mm)
(53413210)

1pc. (PB2) - Pan Bolt 1/4 x 1-1/4" (6 x 32mm)
(53433212)

8pc. (FW6) - #12 Screw Bezel - (9299500)

18pc. (S0) - Truss Screw #8 x 7/8"
(#8 x 22mm)
(52933505)

19pc. (S6) - Pan Screw #12 x 1"
(#12 x 25mm)
(52433610)

5pc. (S7) - Pan Screw #12 x 2"
(#12 x 51mm) (52433620)

1pc. (S4) - Wood Screw #8 x 3" (#8 x 76mm) (52043530)

WL5
(1) Wafer Lag Screw 1/4 x 2-1/2"
(6 x 64mm) (52613222)

1x D1 - Quadrex
Driver Bit (9200015)

1pc. H8 Hex Bolt 1/4 x 4¼" (6 x108mm)- (53703241)

4pc. (FW1) - 1/4" (6mm) Flat Washer (51103200)

1pc. (LW1) - 1/4" (6mm) Lock Washer
(51303200)

94pc. (LN1) - 1/4" (6mm) Lock Nut
(54303200)

1pc. TN1 - 1/4" (6mm) T - Nut
(54503200)

3pc. (S11) - Wood Screw #8 x 2" (#8 x 51mm)(52043520)

Part Identification (Reduced Part Size)

9x - TNR 2 Slide Elbow
(3310121)

1x - TNR 2 Slide Exit Top
(3310124)

1x - TNR3 Short Exit
(3310132)

1x - TNR 3 Tube Support
(9203601)

10x - TNR 2 Slide Clamp Ring
(3300120)

(1) Rebar Ground Stake
9290318

1x - TNR3 Extend Flange Rt
(3310131)

1x - TNR3 Extend Flange Lt
(3310130)

1x - TNR3 Post Mount
(9203602)

1x - MOD Side Lite
(9320116)

First Step: Inventory Parts - Read This Before Starting Assembly

STOP STOP STOP STOP

A. This is the time for you to inventory all your hardware, wood and accessories, referencing the parts identification sheets. This will assist you with your assembly.

- The wood pieces will have the four digit key number stamped on the ends of the boards. The wood pieces are referenced throughout the instructions with this number.

- Please refer to Page 6 for proper hardware assembly.

- Each step indicates which bolts and/or screws you will need for assembly, as well as any flat washers, lock washers, t-nuts or lock nuts.

B. If there are any missing or damaged pieces or you need assistance with assembly please contact the consumer relations department directly. Call us before going back to the store.

1.800.933.0771 or 972.385.0100
customerservice@kidkraft.com
canadacustomerservice@kidkraft.com
For online parts replacement visit
https://parts.kidkraft.com/

+31 20 305 8620
europecustomerservice@KidKraft.com
For online parts replacement visit
https://parts.kidkraft.eu/

C. Read the assembly manual completely, paying special attention to ANSI warnings; notes; and safety/maintenance information.

D. Before you discard your cartons fill out the form below.

- The carton I.D. stamp is located on the end of each carton.The tracking number is located on the KidKraft ID Plaque (9320370).

- Please retain this information for future reference. You will need this information if you contact the Consumer Relations Department.

MODEL NUMBER: **F29065E**	
CARTON I.D. STAMP: __ __ __ __ __ 14459 ___ (Box 1)	CARTON I.D. STAMP: __ __ __ __ __ 14459 ___ (Box 4)
CARTON I.D. STAMP: __ __ __ __ __ 14459 ___ (Box 2)	CARTON I.D. STAMP: __ __ __ __ __ 14459 ___ (Box 5)
CARTON I.D. STAMP: __ __ __ __ __ 14459 ___ (Box 3)	CARTON I.D. STAMP: __ __ __ __ __ 14459 ___ (Box 6)

TRACKING NUMBER (from ID Plaque): _____

Step 1: Front and Back Wall Prep
Part 1

It is important to assemble the frame on a flat, smooth surface.

A: Place (2771) End Post and (2770) End Post Left side by side with the grooves facing up and in. Put (2770) End Post Left on the right hand side. Place (2775) Panel Cross Support in the top grooves, (2772) Panel Floor Support in the middle grooves and (2769) Panel BT Frame in the bottom grooves. (fig. 1.1).

B: Make sure assembly is square then attach with 4 (S30) #8 x 1-1/16" Wood Screws per board. (fig. 1.1)

C: Tap 3 (TN1) 1/4" T-nuts in (2775) Panel Cross Support and (2772) Panel Floor Support and 2 in (2769) Panel BT Frame. (fig. 1.1 and 1.2)

Fig. 1.1

S30 x 4

2770

S30 x 4 per board

2775

Top

2772

TN1 x 3

2769

Bottom

Flush

TN1 x 3

Flush

2771

TN1 x 2

Fig. 1.2

TN1

Wood Parts
2 x `2771` **End Post 1-1/4 x 2-1/2 x 87"**
2 x `2770` **End Post Left 1-1/4 x 2-1/2 x 87"**
2 x `2775` **Panel Cross Support 1-1/4 x 3 x 42"**
2 x `2772` **Panel Floor Support 1-1/4 x 3 x 42"**
2 x `2769` **Panel BT Frame 1-1/4 x 3 x 42"**

Hardware
24 x (S30) **#8 x 1-1/16" Wood Screw**

16 x (TN1) **1/4" T-nut**

Step 1: Front and Back Wall Prep
Part 2

It is important to assemble the frame on a flat, smooth surface.

D: Turn the assembly over, place (2774) Upright in the middle groves of (2775) Panel Cross Support and (2772) Panel Floor Support then attach all boards with 8 (H9) 1/4 x 1-1/4" Hex Bolts (with lock washer and flat washer) connecting to the previously installed t-nuts. (fig. 1.3 and 1.4)

E: Repeat steps A-D for a second assembly.

Fig. 1.3

H9 x 3   2771   H9 x 3   H9 x 2

2775   2772   2774   2770   Flush

Fig. 1.4

H9   LW1   FW1

Wood Parts

2 x [2774] Upright 1-1/4 x 3 x 42"

Hardware

16 x ⟨H9⟩ **1/4 x 1-1/4" Hex Bolt**
(with 1/4" lock washer & 1/4" flat washer)

Step 2: End Wall Prep
Part 1

It is important to assemble the frame on a flat, smooth surface.

A: Place (2768) Panel Floor and 2 (2769) Panel BT Frames on a hard, flat surface with the long side up. Tap in 2 (TN1) 1/4" T-nuts per board. (fig. 2.1)

B: Place (2771) End Post and (2770) End Post Left side by side with the grooves facing up and in. (2770) End Post Left on the right hand side. Place (2769) Panel BT Frames in the top and bottom grooves (2768) Panel Floor in the middle grooves. (fig. 2.2).

C: Make sure assembly is square then attach with 4 (S30) #8 x 1-1/16" Wood Screws per board. (fig. 2.2)

Fig. 2.1

Fig. 2.2

Top

Flush

Flush

2771

Flush

Bottom

Flush

Wood Parts

1 x | 2768 | Panel Floor 1-1/4 x 3 x 42"
2 x | 2769 | Panel BT Frame 1-1/4 x 3 x 42"
1 x | 2771 | End Post 1-1/4 x 2-1/2 x 87"
1 x | 2770 | End Post Left 1-1/4 x 2-1/2 x 87"

Hardware

12 x (S30) #8 x 1-1/16" Wood Screw

6 x (TN1) 1/4" T-nut

Step 2: End Wall Prep
Part 2

It is important to assemble the frame on a flat, smooth surface.

D: Turn the assembly over then attach all boards with 6 (H9) 1/4 x 1-1/4" Hex Bolts (with lock washer and flat washer) connecting to the previously installed t-nuts. (fig. 2.3 and 2.4)

Fig. 2.3

2771

2769

H9 x 2 per board

2768

2769

2770

Fig. 2.4

H9

LW1

FW1

Step 3: Swing Wall Prep
Part 1

It is important to assemble the frame on a flat, smooth surface.

A: Place (2757) LT Post Assembly and (2758) RT Post Assembly on a hard, flat surface with the notches facing down. The top of the post assemblies have the longer notches. (fig. 3.1)

B: Tap 1 (TN2) 5/16" T-nut in the top holes and 1 (TN1) 1/4" T-nut in the middle and bottom holes. (fig. 3.1).

Fig. 3.1

Top

2757

TN2

Notice longer notches at the top (both boards)

2758

TN1

Bottom

Notice shorter notches at the bottom (both boards)

Wood Parts	**Hardware**
1 x [2757] LT Post Assembly 1-1/4 x 2-1/2 x 87"	2 x (TN2) 5/16" T-nut
1 x [2758] RT Post Assembly 1-1/4 x 2-1/2 x 87"	4 x (TN1) 1/4" T-nut

Step 3: Swing Wall Prep
Part 2

It is important to assemble the frame on a flat, smooth surface.

C: Turn the (2757) LT Post Assembly and (2758) RT Post Assembly over and place 2 (2756) Siding Assemblies on top so one sits flush with the top of the middle groove and the second fits flush with the top of the bottom groove. (fig. 3.2 and 3.3)

D: Place (2630) SW Top in the top grooves, (2768) Panel Floor in the middle grooves and (2769) Panel BT Frame in the bottom grooves so they sit flush to the outside edges of (2757) LT Post Assembly and (2758) RT Post Assembly. Make sure the assembly is square then attach with 4 (S30) #8 x 1-1/16" Wood Screws per board.   (fig. 3.4)

Fig. 3.2

Top

2756

2758

2756

Bottom

2757

Flush

Fig. 3.3

Top

Notice Orientation of both (2756) Siding Assemblies.

Fig. 3.4

S30 x 4

S30 x 4

2758

S30 x 4

2630

2768

Flush

2757

2769

Flush

Wood Parts

2 x 2756 Siding Assembly 1-1/4 x 19-15/16 x 39-3/16
1 x 2630 SW Top 1-1/4 x 5-1/2 x 42"
1 x 2768 Panel Floor 1-1/4 x 3 x 42"
1 x 2769 Panel BT Frame 1-1/4 x 3 x 42"

Hardware

12 x S30 #8 x 1-1/16" Wood Screw

Step 3: Swing Wall Prep
Part 3

It is important to assemble the frame on a flat, smooth surface.

E: Attach (2630) SW Top to (2757) LT Post Assembly and (2758) RT Post Assembly with 2 (WB1) 5/16 x 1" Wafer Bolts (with flat washer) connecting to previously installed t-nuts. (fig. 3.5 and 3.6)

F: Attach (2768) Panel Floor to (2757) LT Post Assembly and (2758) RT Post Assembly with 2 (H9) 1/4 x 1-1/4" Hex Bolts (with lock washer and flat washer) connecting to previously installed t-nuts. (fig. 3.5).

G: Place 1 (2778) SW Ground MOD to each side of (2769) Panel BT Frame, notice the hole locations and attach with 1 (H10) 1/4 x 2-1/4" Hex Bolt (with lock washer and flat washer) per board connecting to previously installed t-nuts. (fig. 3.5 and 3.7).

H: Place 1 (2607) Diagonal under (2778) SW Ground MOD on the right hand side so the top sits against (2758) RT Post Assembly and loosely attach with 1 (H10) 1/4 x 2-1/4" Hex Bolt (with lock washer, flat washer and t-nut). (fig. 3.5 and 3.7).

Fig. 3.5

Fig. 3.6

Fig. 3.7

Note which bolt holes are used

Wood Parts

2 x [2778] SW Ground MOD 5/4 x 4 x 14-1/4"
1 x [2607] Diagonal 1-1/4 x 3 x 22"

Hardware

2 x (WB1) 5/16 x 1" Wafer Bolt (with 5/16" flat washer)

2 x (H9) 1/4 x 1-1/4" Hex Bolt (with 1/4" lock washer and 1/4" flat washer)

3 x (H10) 1/4 x 2-1/4" Hex Bolt (with 1/4" lock washer, 1/4" flat washer and 1 x 1/4" t-nut)

Step 3: Swing Wall Prep
Part 4

It is important to assemble the frame on a flat, smooth surface.

I: Attach the top board in each (2756) Siding Assembly to (2757) LT Post Assembly and (2758) RT Post Assembly with 4 (S30) #8 x 1-1/16" Wood Screws per board. (fig. 3.8 and 3.9)

J: Attach the remaining boards in each (2756) Siding Assembly to (2757) LT Post Assembly and (2758) RT Post Assembly with 2 (S0) #8 x 7/8" Truss Screws per board. (fig. 3.8 an 3.9)

Fig. 3.8

2756 2758 2756

S30 x 4

S0 x 10

2757

S30 x 4

S0 x 10

Fig. 3.9

Top Board

Remaining Boards

S30

S0

Hardware

8 x (S30) **#8 x 1-1/16" Wood Screw**

20 x (S0) **#8 x 7/8" Truss Screw**

Step 4: Frame Assembly
Part 1

It is important to assemble the frame on a flat, smooth surface.

A: Place Swing Wall from Step 3 between 2 Front and Back Walls from Step 1, noticing the wall orientations. The tops and bottoms of the walls should be flush. Make sure the walls are square then using the pilot holes as a guide pre-drill with a 3/16" (4.8 mm) drill bit and fasten the Front Wall to the Swing Wall and Swing Wall to the Back Wall with 4 (WL5) 1/4 x 2-1/2" Wafer Lags per side. (fig. 4.1, 4.2 and 4.3)

Fig. 4.1
Top View

Front Wall

Back Wall

Notice Front
Wall overlaps
Swing Wall

Notice Swing Wall
overlaps Back Wall

Flush

WL5

Flush

Swing Wall

WL5

Fig. 4.3

WL5
x 4 per
side

Front Wall

Flush

Fig. 4.2

Notice grooves
face inwards

Swing Wall

Notice counter sunk
holes on the outside

Flush

Back Wall

Hardware

8 x WL5 1/4 x 2-1/2" Wafer Lag

Step 4: Frame Assembly
Part 2

B: Place End Wall from Step 2 between the Front Wall and Back Wall noticing the wall orientation. The tops and bottoms of the walls should be flush. Make sure the walls are square then using the pilot holes as a guide pre-drill with a 3/16" (4.8 mm) drill bit and fasten the Back Wall to the End Wall and End Wall to the Front Wall with 4 (WL5) 1/4 x 2-1/2" Wafer Lags per side. (fig. 4.4)

Fig. 4.4

Back Wall

Swing Wall

WL5

Notice Back Wall
overlaps End Wall

Notice End Wall
overlaps Front Wall

End Wall

Front Wall

Hardware

8 x (WL5) 1/4 x 2-1/2" Wafer Lag

Step 4: Frame Assembly
Part 3

C: Loosely attach 1 (2607) Diagonal to left (2778) SW Ground MOD with 1 (H10) 1/4 x 2-1/4" Hex Bolt (with lock washer, flat washer and t-nut). (fig. 4.5)

D: Place each (2607) Diagonal tight and flush to the front of the Swing Wall then pre-drill pilot holes with a 3/16" (4.8 mm) drill bit and attach each (2607) Diagonal to the Swing Wall with 1 (LS3) 1/4 x 3" Lag Screw (with flat washer) per board, checking that they remain flush to outside edge. (fig. 4.5 and 4.6)

Fig. 4.5

Flush

Flush

2607

TN1 (hidden)

LW1

H10

FW1

2778

Swing Wall

2607

Fig. 4.6

FW1

LS3

LS3

FW1

2607

2607

Swing Wall

Wood Parts

1 x 2607 **Diagonal 1-1/4 x 3 x 22"**

Hardware

1 x H10 **1/4 x 2-1/4" Hex Bolt (1/4" lock washer, 1/4" flat washer, 1/4" t-nut)**

2 x LS3 **1/4 x 3" Lag Screw (flat washer)**

Step 5: Floor Assembly
Part 1

A: From inside of the assembly centre (2608) Floor Joist over the pilot holes in both (2768) Panel Floors in the Swing and End Walls, measure 5/8" (15.9 mm) down from the top of boards then attach (2608) Floor Joist to each board using the left and centre holes with 2 (S4) #8 x 3" Wood Screws per board. (fig.5.1, 5.2, 5.3 and 5.4)

Fig. 5.1

Swing Wall

2608

2768

2768

End Wall

Fig. 5.2

5/8" (15.9 mm)

2608

2768

Fig. 5.3

End Wall

S4

Fig. 5.4

Swing Wall

S4

Notice holes used

Wood Parts

1 x 2608 **Floor Joist 1-1/4 x 3 x 40-3/4"**

Hardware

4 x (S4) **#8 x 3" Wood Screw**

Step 5: Floor Assembly
Part 2

B: On the inside of both the Front and Back Walls loosely attach 1 (2777) Side Joist MOD to each (2772) Panel Floor Support with 2 (H11) 1/4 x 2-3/4" Hex Bolts (with lock washer, flat washer and t-nut) as shown in fig. 5.5. Make sure both (2777) Side Joist MODs are level with (2608) Floor Joist.

Back Wall

Fig. 5.5

H11

LW1

FW1

2772

TN1

2777

2777

TN1

2608

2772

FW1

LW1

H11

Front Wall

Wood Parts

2 x [2777] Side Joist MOD 2 x 2 x 40-1/4"

Hardware

4 x ⬡H11 1/4 x 2-3/4" Hex Bolt
(with 1/4" lock washer, 1/4" flat washer, 1/4" t-nut)

Step 5: Floor Assembly
Part 3

C: Fasten each (2777) Side Joist MOD to each (2772) Panel Floor Support with 4 (S3) #8 x 2-1/2" Wood Screws per board as shown in fig. 5.6.

D: Tighten all (H11) 1/4 x 2-3/4" Hex Bolts in both (2777) Side Joist MOD.

Fig. 5.6

2777

2772

S3

Hardware

8 x (S3) **#8 x 2-1/2" Wood Screw**

Step 5: Floor Assembly
Part 4

E: Starting at the Swing Wall place (2648) Floor Board followed by 8 (2609) Floor Boards. Make sure all boards are evenly spaced then attach to (2608) Floor Joist and each (2777) Side Joist MOD with 5 (S20) #8 x 1-3/8" Wood Screws per board. (fig. 5.7 and 5.8)

Swing Wall

2609

Fig. 5.7

2648

2768

Fig. 5.8

S20 x 5 per board

2777

Wall removed for clarity

2608

2777

Wood Parts

1 x | 2648 | Floor Board 1 x 4 x 40-5/8"
8 x | 2609 | Floor Board 1 x 5 x 40-5/8"

Hardware

45 x (S20) #8 x 1-3/8" Wood Screw

Step 6: Swing Beam Assembly

A: Attach 6 Swing Hangers to the (2614) Engineered Beam using 2 (G7) 5/16 x 5-1/2" Hex Bolts (with 2 flat washers and 1 lock nut) per Swing Hanger as shown in fig. 6.1.

B: Flush to the Fort End of (2614) Engineered Beam attach 2 L-Beam Brackets with 2 (G21) 5/16 x 3-3/4" Hex Bolts (with 2 flat washers and 1 lock nut). (fig. 6.1 and 6.2)

C: Install 1 (WB7) 5/16 x 3" Wafer Bolt (with flat washer and t-nut) in the middle bolt hole in (2614) Engineered Beam as shown in fig. 6.3. **IT IS IMPORTANT THAT THIS BOLT IS ATTACHED. IT WILL MINIMIZE CHECKING OF WOOD.**

Fig. 6.1

Fort End

Swing Hanger x 6

2614

G7

LN2

FW2

Swing End

Fig. 6.2

Fort End

LN2

FW2

2614

L-Beam Bracket

Flush

L-Beam Bracket

FW2

G21

Fig. 6.3

TN2

2614

FW2

WB7

Wood Parts	**Hardware**	**Other Parts**
1 x [2614] Engineered Beam 4 x 6 x 88"	12 x (G7) 5/16 x 5-1/2" Hex Bolt (5/16" flat washer x 2, 5/16" lock nut)	6 x Swing Hangers
	2 x (G21) 5/16 x 3-3/4" Hex Bolt (5/16" flat washer x 2, /16" lock nut)	2 x L-Beam Bracket
	1 x (WB7) 5/16 x 3" Wafer Bolt (5/16" flat washer & 5/16" t-nut)	

Step 7: Swing End Assembly

A: Loosely attach 2 (2613) Heavy SW Posts to (2615) SW Upright using 2 (G7) 5/16 x 5-1/2" Hex Bolts (with lock washer, flat washer and t-nut). Notice 2 bolt holes at top of (2615) SW Upright and orientation of angle. (fig. 7.1)

B: Attach (2616) SW Support to both (2613) Heavy SW Posts and (2615) SW Upright using 3 (G4) 5/16 x 4" Hex Bolts (with lock washer, flat washer and t-nut). Tighten all bolts (fig. 7.1)

C: Install 2 (WB7) 5/16 x 3" Wafer Bolts (with flat washer and t-nut) in the top bolt holes in (2615) SW Upright as shown in fig. 7.1. **IT IS IMPORTANT THAT THESE BOLTS ARE ATTACHED. THEY WILL MINIMIZE CHECKING OF WOOD.**

Fig. 7.1

Notice 2 bolt holes at top and orientation of the angle

Wood Parts

2 x [2613] Heavy SW Post 2 x 3 x 86-11/16"
1 x [2615] SW Upright 4 x 4 x 50-15/16"
1 x [2616] SW Support 5/4 x 4 x 46-1/2"

Hardware

2 x (G7) 5/16 x 5-1/2" Hex Bolt (5/16" lock washer, 5/16" flat washer, 5/16" t-nut)
3 x (G4) 5/16 x 4" Hex Bolt (5/16" lock washer, 5/16" flat washer, 5/16" t-nut)
2 x (WB7) 5/16 x 3" Wafer Bolt (5/16" flat washer & 5/16" t-nut)

Step 8: Attach Swing End to Swing Beam

A: Place Swing End Assembly against Swing Beam Assembly then place 1 Beam Bracket on each side of the assembly (they are specific for left and right side) and attach with 5 (G21) 5/16 x 3-3/4" Hex Bolts (with 2 flat washers and 1 lock nut). (fig. 8.1 and 8.2)

Fig. 8.1

Swing Beam Assembly

Swing End Assembly

Beam Bracket

Swing Beam Assembly

Fig. 8.2

LN2

FW2

G21

Swing End Assembly

Hardware	**Other Parts**
5 x ⬡G21 **5/16 x 3-3/4" Hex Bolt** **(5/16" flat washer x 2, 5/16" lock nut)**	**2 x Beam Bracket (Left/Right)**

Step 9: Attach Swing Assembly To Fort

A: Place Swing Assembly against top of (2630) SW Top, make sure assembly is level then attach from inside the fort assembly into each L-Beam Bracket with 4 (G8) 5/16 x 2" Hex Bolts (with 2 flat washers and 1 lock nut). (fig. 9.1)

Fig. 9.1

L-Beam Bracket

2630

G8

Swing Assembly

FW2

LN2

Hardware

4 x   G8   **5/16 x 2" Hex Bolt**
(5/16" flat washer x 2, 5/16" lock nut)

Step 10: Install Ground Stakes

MOVE FORT TO FINAL LOCATION PRIOR TO STAKING
FINAL LOCATION MUST BE LEVEL GROUND

A: In the 5 places shown in fig. 10.1 drive the Rebar Ground Stakes 13" (330 mm) into the ground against outside front corner of the End Wall, on both (2607) Diagonals and both (2613) Heavy SW Posts. Be careful not to hit the washer while hammering stakes into the ground as this could cause the washer to break off.

B: Attach ground stakes using 1 (S7) #12 x 2" Pan Screw per ground stake (fig. 10.2 and 10.3).

C: After driving stakes into the ground, check for sharp edges caused by the impact of the hammer. Smooth any sharp edges from impact area and touch up with outdoor paint.

⚠**Warning!** **To prevent tipping and avoid potential injury, stakes must be driven 13" (330 mm) into ground. Digging or driving stakes can be dangerous if you do not check first for under-ground wiring, cables or gas lines.**

Fig. 10.1

Front

End Wall

2607

2613

2607

Fig. 10.2

End Wall

S7

13" (330 mm) In Ground

Rebar Ground Stake

Fig. 10.3

S7

13" (330 mm) In Ground

Rebar Ground Stake

SEE FRONT COVER FOR SAFETY CLEARANCE

Hardware

5 x (S7) #12 x 2" Pan Screw

Other Parts

5 x Rebar Ground Stake

Step 11: How to Install Inserts - Upper and Lower Jambs

There is 1 (2601) Lower Jamb and 1 (2602) Upper Jamb provided. Install the (2601) Lower Jamb on the End Wall and the (2602) Upper Jamb on the End Wall using 2 Jamb Mounts and 8 (S0) #8 x 7/8" Truss Screws per board.

Use the diagrams below to show correct placement of each board.

Outside View

Inside View

Notice orientation of this bracket. Used in this variation only.

9-5/8"
244 mm

2602

17"
432 mm

17"
432 mm

Grooves to the inside

2601

End Wall - Upper

End Wall - Lower

Jamb Mount

S0 x 4 per Jamb Mount

2601 or 2602

Centred

Jamb Mount

2601 or 2602

Centred

S0 x 4 per Jamb Mount

Wood Parts

1 x 2601 **Lower Jamb 1-1/4 x 3 x 41-15/16"**
1 x 2602 **Upper Jamb 1-1/4 x 3 x 35-15/16"**

Hardware

16 x S0 **#8 x 7/8" Truss Screw**

Other Parts

4 x Jamb Mount

Step 12: How to Install Inserts - Window and Wall Inserts Part 1

There is 1 (2649) Lower Window Insert, 2 (2655) Upper Window Inserts, 1 (2665) Half Wall Insert, 2 (649A) Short Half Walls and 2 MOD 3-Pane Transoms provided. Use the Epic Fort Guide to see where each insert is installed.

When installing you will need the following:

For (2649) Lower Window Insert and (2655) Upper Window Insert - 9 x (S0) Truss Screws per insert.

For (2665) Half Wall Insert, (649A) Short Half Wall and MOD 3-Pane Transom - 4 x (S0) Truss Screws per insert.

Inside View

S0

2649
and
2655

S0

S0

Tight

2649
and
2655

Step 12: How to Install Inserts - Window and Wall Inserts Part 2

Inside Views

MOD
3-Pane
Transom

Tight

S0

649A

S0

Tight

2665

S0

Tight

Step 13: How to Install Inserts - Clock Assembly

There is 1 Clock Set provided to be installed on the Front Wall. See Epic Fort Guide for correct location. See below for how to assemble and attach the Clock Set.

When installing you will need the following:

Base Clock, Clock Subset (includes minute and hour hands, clock adapter and clock screw), 2 (2717) Clock Blocks and 4 x (S20) Wood Screws.

To assemble Clock insert the Clock Adapter from the back of the Base Clock, place the Hour Hand over the Clock Adapter making sure they are lined up properly. Press the Minute Hand over the Hour Hand and connect with Clock Screw.

Attach assembled Clock through panel and into each (2717) Clock Block with 4 (S20) Wood Screws.

Do not over tighten screws.

Side View

Outside View

Clock Adapter

Hour Hand

Clock Screw

S20

Minute Hand

Base Clock

Base Clock

2717

Panel

Inside View

2717

Step 14: Rock Wall Assembly

Fig. 14.1

2781 **2776**

2780

2779 **2780** **2781** **2781**

S20
x 4 per board

Note: The holes in the rock boards must orient to the top of the boards.

7-5/8" (193.6 mm) Approx

Note: Gaps between boards 2-1/4" (57 mm), not to exceed 2-3/8" (60.3 mm)

Fig. 14.2

A: Lay 2 (2776) Rock Rails down, side by side with angled edges facing down. (fig. 14.1)

B: Place (2779) Access Board on the bottom of each (2776) Rock Rail as shown in fig. 14.1. Make sure (2779) Access Board is flush to the outside and bottom edges of each (2776). Attach using 4 (S20) #8 x 1-3/8" Wood Screws.

C: 7-5/8" (193.6 mm) down from the top of both (2776) Rock Rails place 1 (2781) Rk Board B, making sure the sides are flush to the outside edges of each (2776) Rock Rail. Attach using 4 (S20) #8 x 1-3/8" Wood Screws. (fig. 14.1)

D: In between the (2779) Access Board and (2781) Rk Board B stagger 2 (2781) Rk Board Bs and 2 (2780) Rk Board As using 4 (S20) #8 x 1-3/8" Wood Screws per board. Placing them as shown in fig. 14.1, this will prevent rocks from forming a straight line. Make sure the boards are evenly spaced and do not exceed 2-3/8" (60.3 mm) between boards.

FW0 **LW1** **Fig. 14.3**

PB2

S10

BN1

Rock

E: Place 1 rock on each (2780) Rk Board A and (2781) Rk Board B (fig. 14.2) and attach using 1 (PB2) 1/4 x 1-1/4" Pan Bolt (with lock washer, flat washer and barrel nut) and 1 (S10) #8 x 1" Pan Screw per rock. The Screw must be in the hole directly under the Pan Bolt, it will stop the rock from spinning. (fig. 14.3)

Wood Parts	**Hardware**	**Other Parts**
1 x 2779 Access Board 1 x 6 x 19"	24 x (S20) #8 x 1-3/8" Wood Screw	5 x Rocks (3 green/2 yellow)
3 x 2781 Rk Board B 1 x 6 x 19"	5 x (S10) #8 x 1" Pan Screw	
2 x 2780 Rk Board A 1 x 6 x 19"	5 x (PB2) 1/4 x 1-1/4" Pan Bolt (1/4" lock washer, 1/4" flat washer & 1/4" barrel nut)	
2 x 2776 Rock Rail 1-1/4 x 2-1/2 x 51"		

Step 15: Attach Rock Wall Assembly to Fort
Part 1

A: Place Rock Wall Assembly centred in opening of the Back Wall as shown in the Epic Fort Guide and flush as shown below. Attach (2776) Rock Rails to the Back Wall using 4 (S11) #8 x 2" Wood Screws. (fig. 15.1 and 15.2)

B: Attach 1 (2779) Access Board to top of Rock Wall Assembly, flush to top of (2776) Rock Rails using 4 (S2) #8 x 1-1/2" Wood Screws. (fig. 15.3)

Note: Make sure (2776) Rock Rails do not cover the bolt head, move assembly over so it is tight to the bolt head. (fig. 15.1 and 15.2)

Fig. 15.1

Fig. 15.2

Panel

S11

Flush

Bolt
Head

2776

S11

S11

S11

2776

Fig. 15.3

2779

Flush

S2

2776

S2

2776

Wood Parts

1 x 2779 **Access Board 1 x 6 x 19"**

Hardware

4 x (S2) **#8 x 1 1/2" Wood Screw**

4 x (S11) **#8 x 2" Wood Screw**

Step 15: Attach Rock Wall Assembly to Fort
Part 2

C: Drive 1 Rebar Ground Stake 13" (330 mm) into the ground against outside (2776) Rock Rail then attach with 1 (S7) #12 x 2" Pan Screw. Be careful not to hit the washer while hammering stake into the ground as this could cause the washer to break off. (fig. 15.4 and 15.5)

D: After driving stake into the ground, check for sharp edges caused by the impact of the hammer. Smooth any sharp edges from impact area and touch up with outdoor paint.

⚠Warning! **To prevent tipping and avoid potential injury, stakes must be driven 13" (330 mm) into ground. Digging or driving stakes can be dangerous if you do not check first for under-ground wiring, cables or gas lines.**

Fig. 15.4

2776

Fig. 15.5

2776

13" (330 mm)
In Ground

S7

Rebar
Ground
Stake

Hardware

1 x (S7) **#12 x 2" Pan Screw**

Other Parts

1 x Rebar Ground Stake

Step 16: Attach Hand Grip to Fort

A: Measure 6" (152.4 mm) from the top of the floor boards on the left hand side of the Rock Board, pre-drill with a 1/8" (3.2 mm) drill bit then attach 1 Play Handle with 2 (WL3) 1/4 x 1-3/8" Wafer Lags to the Back Wall. (fig. 16.1)

Fig. 16.1

Play Handle

WL3

6"
(152.4
mm)

Hardware

2 x WL3 **1/4 x 1-3/8" Wafer Lag**

Other Parts

1 x Play Handle

Step 17: Cafe Table Assembly

A: Place (2612) Table Support flush to the notched out ends of (2611) Table Top and attach with 4 (S7) #12 x 2" Pan Screws as shown in fig. 17.1.

B: Place Table Top Assembly tight in the opening of Front Wall with the overhang on the outside of the assembly as shown in fig. 17.2 and in the Epic Fort Guide then attach (2612) Table Support to the End Wall posts with 2 (S3) #8 x 2-1/2" Wood Screws.

Fig. 17.1

S7

Flush

2612

2611

Flush

Fig. 17.2
Outside View

Tight

2611

Tight

Tight

2612

S3

S3

Front Wall

Wood Parts

1 x 2612 **Table Support 2 x 2 x 39-5/8"**

1 x 2611 **Table Top 5/4 x 5 x 39-5/8"**

Hardware

4 x (S7) **#12 x 2" Pan Screw**

2 x (S3) **#8 x 2-1/2" Wood Screw**

Step 18: Attach Cafe Canopy to Fort

A: Feed Cafe Canopy Frame through the pocket of the Cafe Canopy. (fig. 18.1)

B: With a helper hold the Canopy against the fort, on the Front Wall as shown on the Epic Fort Guide, measure 3-1/8" (79 mm) in from the outside edge of the (2770) End Post Left, making sure the Cafe Canopy is smooth and tight then attach to the post with 2 (S5) #8 x 1/2" Pan Screws (with #8 flat washer), measure 2-3/8" (60mm) down from the first screw then attach a third screw and washer. Follow measurements as shown in fig. 18.2 for remaining screws and washers. Measurements must be exact.

C: Hold the Cafe Canopy Frame against the panel and attach with 1 (S0) #8 x 7/8" Truss Screw per side. (fig. 18.2)

Fig. 18.1

Cafe Canopy

Cafe Canopy Frame

Fig. 18.2

31.8 mm
1-1/4"

FW3

S5 x 8

127 mm
5"

381 mm
15"

Start on this side

79 mm
3-1/8"

381 mm
15"

60 mm
2-3/8"

2770

2771

S0
x 1 per side

Cafe Canopy Frame

Cafe Canopy

Front Wall

Hardware		Other Parts
8 x (S5) **#8 x 1/2" Pan Screw (#8 flat washer)**		**1 x Cafe Canopy Frame**
2 x (S0) **#8 x 7/8" Truss Screw**		**1 x Cafe Canopy**

Step 19: Roof Support Assembly

A: Attach 1 (2760) Roof Support to a second (2760) Roof Support at peak using 1 (S4) #8 x 3" Wood Screw. Repeat this step so there are 2 Roof Support Assemblies. (fig. 19.1 and 19.2)

Fig. 19.1

Roof Support Assembly

(S4)

2760

Fig. 19.2

(S4)

2760

Wood Parts

4 x 2760 **Roof Support 1-1/4 x 2-1/4 x 37-1/2"**

Hardware

2 x (S4) **#8 x 3" Wood Screw**

Step 20: Roof Panel Assembly

A: Place 1 (2751) MOD Roof Bottom tight to the bottom of (2752) MOD Roof Front and (2753) MOD Roof Back. (fig. 20.1)

B: Place a (2761) Roof Sleeper C on the middle strip of each Roof Panel Assembly so the ends are flush and attach with 4 (S20) #8 x 1-3/8" Wood Screws per panel. (fig. 20.2)

2753
and
2752

Fig. 20.1

Make sure panels are tight to each other

Fig. 20.2

2751

2753

2752

2751

2751

2761

Flush

S20 x 4 per board

Wood Parts

2 x `2751` **MOD Roof Bottom 1-3/16 x 16-25/32 x 44"**
1 x `2752` **MOD Roof Front 1-1/4 x 20-7/16 x 44"**
1 x `2753` **MOD Roof Back 1-1/4 x 20-13/64 x 44"**
2 x `2761` **Roof Sleeper C 3/4 x 2 x 35"**

Hardware

8 x (S20) **#8 x 1-3/8" Wood Screw**

Step 21: Roof Assembly
Part 1

A: Place Front Roof Panel against Back Roof Panel so the tops form a peak then tight to the inside edge of the outside slats attach 1 Narrow Angle Bracket per slat with 2 (S0) #8 x 7/8" Truss Screws per bracket. (fig. 21.1 and 21.2)

B: Attach the third Narrow Angle Bracket centred on the middle slat with 2 (S0) #8 x 7/8" Truss Screws. (fig. 21.1 and 21.3)

Fig. 21.3

Centred

Narrow Angle
Bracket

S0 x 2

Flush

Fig. 21.1

Narrow Angle
Bracket

Fig. 21.2

Flush

S0 x 2 per bracket

Back Roof
Panel

Flush

Front Roof
Panel

Hardware	**Other Parts**
6 x (S0) **#8 x 7/8" Truss Screw**	**3 x Narrow Angle Bracket**

Step 21: Roof Assembly
Part 2

C: Place 1 Roof Support Assembly against one side so the peaks meet and the ends of the roof supports are flush with the ends of the roof panels. Attach with 8 (S11) Wood Screws. (fig. 21.4)

D: Attach the second Roof Support Assembly on the opposite side, peaks to meet and ends are flush with 8 (S11) #8 x 2" Wood Screws. (fig. 21.4)

Fig. 21.4

S11

Roof Support Assembly

Flush

Flush

Back Roof Panel

Front Roof Panel

Flush

Flush

S11

(hidden)

Roof Support Assembly

Hardware

16 x (S11) **#8 x 2" Wood Screw**

Step 22: Attach Sky Gable

A: Attach 1 Sky Gable to the inside of the (2617) Roof Supports on each side of the Roof Assembly with 4 (S5) #8 x 1/2" Pan Screws per Sky Gable. (fig. 22.1 and 22.2)

Fig. 22.1

Sky Gable

2617

2617

Roof Assembly

Sky Gable

2617

Fig. 22.2
Inside View

S5

S5

Sky Gable

2617

Hardware	Other Parts
8 x (S5) **#8 x 1/2" Pan Screw**	**2 x Sky Gable**

Step 23: Attach Roof Ends
Part 1

A: On the Front and Back Walls remove the 2 outside (H9) Hex Bolts attached at the top of the assembly from Step 1, Part 2. Leave the (TN1) T-nuts in. The (FW1) Flat Washers and (LW1) Lock Washers will be used in Step B. (fig. 23.1)

Fig. 23.1

Back Wall

Front Wall

Remove these bolts on both Front and Back Walls, keeping lock washers and flat washers for next step. Do not remove the t-nuts.

Step 23: Attach Roof Ends
Part 2

B: Loosely attach 1 (2759) Roof End to each corner, flush to the top of (2775) Panel Cross Supports, with 1 (H3) 1/4 x 2-1/2" Hex Bolt per board, using the (FW1) 1/4" Flat Washer and (LW1) 1/4" Lock Washer from Step A and connecting to the (TN1) 1/4" T-nut. Notice which bolt holes are to be used. (fig. 23.2, 23.3, 23.4 and 23.5)

Fig. 23.2

2759 · 2759

Swing Wall

Back Wall · Front Wall

End Wall

2759 · 2759

Fig. 23.3 Flush — **Left Side**

2759 · 2775

H3 *Keep bolts loose*

Fig. 23.4 Flush — **Right Side**

2775 · 2759

Fig. 23.5

2775 · 2759

Flush

2759 · FW1 · LW1 · H3

2775

FW1 · LW1 · H3

Wood Parts

4 x | 2759 | Roof End 1-1/4 x 3 x 10"

Hardware

4 x | H3 | 1/4 x 2-1/2" Hex Bolt

Step 23: Attach Roof Ends
Part 3

C: Measure overhang so it is 4-7/8" (124 mm) then attach with 2 (S11) #8 x 2" Wood Screws and 1 (S3) #8 x 2-1/2" Wood Screw per (2759) Roof End. Tighten the bolts. (fig. 23.6, 23.7 and 23.8)

Fig. 23.6
Top View

2759

$4\dfrac{7}{8}$" (124 mm)

S3

S11
x 2 per board

Swing and
End Walls

Front and
Back Walls

Fig. 23.7

Left Side

S3

2759

S11

Fig. 23.8

Right Side

S3

2759

Hardware

4 x (S3) **#8 x 2-1/2" Wood Screw**

8 x (S11) **#8 x 2" Wood Screw**

Step 24: Attach Roof Assembly to Fort
Part 1

A: With 2 people on the ground and at least 1 person in the fort, lift the Roof Assembly up and over the Back side of the fort. Guide the Roof Assembly onto the fort so all four (2760) Roof Supports sit flush to the front and outside edges of (2759) Roof Ends. (fig. 24.1)

B: Attach (2760) Roof Supports to (2759) Roof Ends with 1 (S3) #8 x 2-1/2" Wood Screw per support. (fig. 24.1)

Roof
Assembly

**Back
Wall**

Fig. 24.1

2760

2760

S3

S3

Flush

2759

S3

Flush

2759

Flush

2759

**Front
Wall**

Cafe Canopy removed for Clarity

Hardware

4 x (S3) **#8 x 2-1/2" Wood Screw**

Step 24: Attach Roof Assembly to Fort
Part 2

C: Place (9450) Roof Tie so that the angled end is flush against (2761) Roof Sleeper C and the other end is flat against (2630) SW Top, centered between the Hex Bolts. Attach using 4 (S11) #8 x 2" Wood Screws, making sure that the top 2 screws are installed on an angle as shown in fig. 24.2.

D: Repeat Step C to install a (9450) Roof Tie to (2761) Roof Sleeper C and (2769) Panel BT Frame on the opposite side of the roof.

Fig. 24.2

Wood Parts

2 x [9450] Roof Tie 1-1/4 x 2 x 7-9/16"

Hardware

8 x (S11) #8 x 2" Wood Screw

Step 25: Attach Swings

A: Attach 1 Threaded Clip to each Acro Rope EN71 and the Acro Bar. Attach another Threaded Clip to each Acro Handle and join with first Threaded Clip. Make sure to close the Threaded Clip tightly using an adjustable wrench. (fig. 25.2 and 25.3)

B: Attach the end of the swing and acro ropes to the Threaded Clips attached to the swing hangers. (fig. 25.1)

Fig. 25.1

Acro Rope EN71

Swing Belt Seat

Swing Belt Seat

Acro Rope EN71

Acro Bar

Fig. 25.2

Threaded Clip

Threaded Clip

Acro Handles

Fig. 25.3

Acro Rope EN71

Threaded Clips attach to Acro Ropes

Threaded Clip

Other Parts

2 x Belt Swings
1 x Acro Bar
2 x Acro Handle
2 x Acro Rope EN71
4 x Threaded Clips

Step 26: Bench Assembly

A: Open the (2658) Folding Bench Assembly.   (fig. 26.1, 26.2 and 26.3)

B: Make sure assembly is level then secure with 2 (H1) 1/4 x 1-1/2" Hex Bolts (with lock washer, flat washer and t-nut) per side.   (fig. 26.4)

C: Tighten the top screws in all 4 Bench Legs.   (fig. 26.4)

Fig. 26.1

2658

Fig. 26.2

Fig. 26.3

Bench Legs

Bench Legs

Fig. 26.4

Tighten these screws - all 4 legs

H1

LW1

FW1

TN1

Wood Parts

1 x 2658 **Folding Bench 2-13/32 x 6-3/4 x 34"**

Hardware

4 x H1 **1/4 x 1-1/2" Hex Bolt
(1/4" lock washer, 1/4" flat washer, 1/4" t-nut)**

Step 27: Attach Slide Wall Inserts

A: In the narrow opening of the End Wall (Upper Jamb should already be installed), place the MOD Side Lite from inside the assembly then attach to the wall and (2602) Upper Jamb with 14 (S0) #8 x 7/8" Truss Screws. (fig. 27.1 and 27.2)

B: In the wider opening of the End Wall tight to (2768) Panel Floor place (8935) Lower SL Insert from inside the assembly then attach to the wall and (2602) Upper Jamb with 4 (S0) #8 x 7/8" Truss Screws. (fig. 27.1 and 27.2)

Fig. 27.1
Inside View

Fig. 27.2
Inside View

Wood Parts	**Hardware**	**Other Parts**
1 x 8935 **Lower SL Insert 1-3/8 x 8-1/8 x 26-1/4"**	18 x (S0) **#8 x 7/8" Truss Screw**	1 x **MOD Side Lite**

Step 28: Slide Section Assemblies
Part 1

Note: When installing Pan Bolts make sure to look at holes so bolts go through the side with the round recess and the lock nuts go through the side with the hexagonal recess. (fig. 28.3)

A: Fit 2 TNR2 Slide Elbows together and attach with 8 (PB1) 1/4 x 3/4" Pan Bolts (with lock nut) as shown in fig. 28.1. It is very important to attach bolts as indicated.

B: Repeat Step A 3 more times to create 4 Elbow Sections in total.

C: Attach TNR3 Extend Flange RT and TNR3 Extend Flange LT together using 9 (PB1) 1/4 x 3/4" Pan Bolts (with lock nut) as shown in fig. 28.2. This creates the Flange Assembly.

Fig. 28.2
Flange Assembly

TNR3 Extend Flange LT

LN1

LN1

Fig. 28.1

LN1

PB1

PB1

LN1

TNR2 Slide Elbow

PB1
x 4

TNR3 Extend Flange RT

PB1

PB1

Fig. 28.3

PB1

LN1

Use a 7/16" open end wrench for nuts

Hardware

41 x (PB1) 1/4 x 3/4" Pan Bolt (1/4" lock nut)

Other Parts

1 x TNR3 Extend Flange RT
1 x TNR3 Extend Flange LT
8 x TNR2 Slide Elbow

Step 28: Slide Section Assemblies
Part 2

Note: When installing Pan Bolts make sure to look at holes so bolts go through the side with the round recess and the lock nuts go through the side with the hexagonal recess. (fig. 28.3)

D: Attach TNR2 Slide Exit Top and the remaining TNR2 Slide Elbow together using 8 (PB1) 1/4 x 3/4" Pan Bolts (with lock nut) as shown in fig. 28.4. It is very important to attach bolts as indicated. This creates the Exit Elbow Assembly.

Fig. 28.4

TNR2
Slide Exit
Top

PB1

LN1

PB1

TNR2
Slide
Elbow

LN1

PB1

Fig. 28.3

PB1

LN1

Hardware

8 x (PB1) **1/4 x 3/4" Pan Bolt (1/4" lock nut)**

Other Parts

1 x TNR2 Slide Exit Top
1 x TNR2 Slide Elbow

Step 29: Attach Flange Assembly to Fort
Part 1

A: With a helper place the Flange Assembly flush to the top opening in End Wall as shown in fig. 29.1 and the Epic Fort Guide, then pre-drill 1/8" (3.2 mm) pilot holes in (8935) Lower SL Insert for the 4 bottom mounting locations (approximate spots where circles are on figure 29.2), making sure the pre-drilled holes are a minimum of 1" (25.4 mm) deep. (fig. 29.2)

B: Attach Flange Assembly to (8935) Lower SL Insert using 4 (S7) #12 x 2" Pan Screws (with #12 Screw Bezel) in the pre-drilled holes. (fig. 29.2) Make sure the flat surfaces of the Flange Assembly are flush to the End Wall and (2602) Upper Jamb as shown in fig. 29.3.

C: Attach the Flange Assembly flush to bottom of (2769) Panel BT Frame using 4 (S6) #12 x 1" Pan Screws (with #12 Screw Bezel) and to (2602) Upper Jamb and side of End Wall using 5 (S6) Pan Screws per side. (fig. 29.2)

Fig. 29.1
Outside View

Fig. 29.2
Inside View

Flange Assembly

Top

2769

Side

Flange Assembly

2602

Side

S6
w/ #12 Screw Bezel

S6
(5 per side)

8935

2602

8935

S7 w/ #12 Screw Bezel

Fig. 29.3

Bottom of (2769) Panel BT Frame

Bottom of slide flush with (8935) Lower SL Insert

Hardware

14 x (S6) **#12 x 1" Pan Screw**

4 x (S7) **#12 x 2" Pan Screw**

8 x **#12 Screw Bezel**

Step 29: Attach Flange Assembly to Fort
Part 2

D: Place (8934) SL Gusset tight to (2768) Panel Floor, flush to the top of the bottom opening and attach to Flange Assembly with 2 (S6) #12 x 1" Pan Screws. (fig. 29.4 and 29.5)

E: Pre-drill pilot hole with a 3/16" (4.8 mm) drill bit then attach (8934) SL Gusset to (2768) Panel Floor with 1 (WL5) 1/4 x 2-1/2" Wafer Lag (with flat washer). (fig. 29.4 and 29.5)

Fig. 29.4

Flange
Assembly

8934

2768

Fig. 29.5

S6

Flange
Assembly

8934

2768

WL5

Flush

FW1

Wood Parts

1 x 8934 **SL Gusset 1-1/4 x 3 x 15-3/4"**

Hardware

2 x (S6) **#12 x 1" Pan Screw**

1 x ⬡WL5 **1/4 x 2-1/2" Wafer Lag (flat washer)**

Step 30: Attach Elbow Assembly to Flange Assembly Part 1

Note: When installing Pan Bolts make sure to look at holes so bolts go through the side with the round recess and the lock nuts go through the side with the hexagonal recess. Keep all bolts loose until further step.

A: Fit one of the Elbow Assemblies to the Flange Assembly by lining up the arrows on each assembly.   (fig. 30.2 and 30.3)

B: Attach 1 TNR2 Slide Clamp Ring to the top of the joined Assemblies using 3 (PB1) 1/4 x 3/4" Pan Bolts (with lock nut), making sure to match the arrows up with the end of the clamp ring (where a seam will be) as shown in fig. 30.2 and 30.3.

Use Quadrex Driver as a guide pin for each hole before inserting bolt. (fig. 30.3)

Quadrex Driver

Use special driver provided in locations where the curve of the elbow are difficult to reach with a standard driver.

Fig. 30.4

Fig. 30.1

Do not install bolt in Clamp Ring ends until Step 30D

Fig. 30.3

Fig. 30.2

Top Slide Bolt Holes

Flange Assembly

LN1

LN1

PB1

LN1

Align each elbow using the molded arrows with the seam of the clamp ring.

Elbow Assembly

Hardware

3 x (PB1) **1/4 x 3/4" Pan Bolt (1/4" lock nut)**

Other Parts

1 x Quadrex Driver
1 x TNR2 Slide Clamp Ring

Step 30: Attach Elbow Assembly to Flange Assembly Part 2

Note: When installing Pan Bolts make sure to look at holes so bolts go through the side with the round recess and the lock nuts go through the side with the hexagonal recess. Keep all bolts loose until further step.

Fig. 30.5

C: Attach 1 TNR2 Slide Clamp Ring to the bottom of the joined Assemblies using 2 (PB1) 1/4 x 3/4" Pan Bolts (with lock nut) on one side and 1 (PB1) Pan Bolt (with lock nut) in the other side, making sure to match the arrows up with the end of the clamp ring (where a seam will be) as shown in fig. 30.5, 30.6 and 30.7.

D: Connect the 2 TNR2 Slide Clamp Rings together in 2 spots using 1 (PB1) 1/4 x 3/4" Pan Bolt (with lock nut) per hole. Make sure seams and arrows line up and then tighten all bolts. (fig. 30.8 and 30.9).

Fig. 30.6

PB1

LN1

Fig. 30.7 (Side not shown)

Bottom Slide Bolt Holes

PB1

Fig. 30.8

Make sure arrows are aligned

PB1

LN1

Fig. 30.9

LN1

After the clamp rings are attached to the elbows, fasten them end to end with two pan bolts and lock nuts

---

Hardware

5 x (PB1) **1/4 x 3/4" Pan Bolt (1/4" lock nut)**

Other Parts

1 x TNR2 Slide Clamp Ring

Step 31: Attach Elbow Assembly to Elbow Assembly Part 1

Note: When installing Pan Bolts make sure to look at holes so bolts go through the side with the round recess and the lock nuts go through the side with the hexagonal recess. Keep all bolts loose until further step.

A: Fit a second Elbow Assembly to the first Elbow Assembly by lining up the arrows on each assembly. Notice the elbow orientation. (fig. 31.1)

B: Attach 1 TNR2 Slide Clamp Ring to the top of the joined Assemblies using 3 (PB1) 1/4 x 3/4" Pan Bolts (with lock nut), making sure to match the arrows up with the end of the clamp ring (where a seam will be) as shown in fig. 31.2 and 31.3.

Use Quadrex Driver as a guide pin for each hole before inserting bolt.

Fig. 31.1

Notice elbow orientation

Do not install bolt in Clamp Ring ends until Step 31D

Fig. 31.2
Top Slide Bolt Holes

Elbow Assembly

Fig. 31.3

Make sure arrows are aligned

PB1

LN1

Elbow Assembly

Hardware

3 x (PB1) 1/4 x 3/4" Pan Bolt (1/4" lock nut)

Other Parts

1 x TNR2 Slide Clamp Ring

Step 31: Attach Elbow Assembly to Elbow Assembly Part 2

Note: When installing Pan Bolts make sure to look at holes so bolts go through the side with the round recess and the lock nuts go through the side with the hexagonal recess. Keep all bolts loose until further step.

C: Attach 1 TNR2 Slide Clamp Ring to the bottom of the joined Assemblies using 3 (PB1) 1/4 x 3/4" Pan Bolts (with lock nut), making sure to match the arrows up with the end of the clamp ring (where a seam will be) as shown in fig. 31.3 and 31.4.

D: Connect the 2 TNR2 Slide Clamp Rings together in 2 spots using 1 (PB1) 1/4 x 3/4" Pan Bolt (with lock nut) per hole. Make sure seams and arrows line up and then tighten all bolts. (fig. 31.3 and 31.5).

Fig. 31.3

Elbow Assembly

Fig. 31.4

Bottom Slide Bolt Holes

Make sure arrows are aligned

LN1

PB1

Fig. 31.5

PB1   LN1

Elbow Assembly

After the clamp rings are attached to the elbows, fasten them end to end with two pan bolts and lock nuts

Hardware

5 x (PB1) **1/4 x 3/4" Pan Bolt (1/4" lock nut)**

Other Parts

1 x TNR2 Slide Clamp Ring

Step 32: TNR Brace Assembly

A: Attach (8965) TNR Upright to (8963) TNR Ground Brace with 1 (H8) 1/4 x 4-1/4" Hex Bolt (with lock washer, flat washer and t-nut) in the top hole. Make sure both boards are square then attach with 1 (S11) #8 x 2" Wood Screw. (fig. 32.1)

Fig. 32.1

8965

FW1

LW1

H8

S11

8963

TN1

Wood Parts

1 x `8963` **TNR Ground Brace 1-1/4 x 3 x 32-1/4"**

1 x `8965` **TNR Upright 1-1/4 x 3 x 20-1/4"**

Hardware

1 x (S11) **#8 x 2" Wood Screw**

1 x (H8) **1/4 x 4-1/4" Hex Bolt (lock washer, flat washer, t-nut)**

Step 33: Attach Elbow Assemblies and TNR2 Slide Support

Note: When installing Pan Bolts make sure to look at holes so bolts go through the side with the round recess and the lock nuts go through the side with the hexagonal recess. Keep all bolts loose until further step.

A: Attach the two remaining Elbow Assemblies as instructed in Steps 30 and 31.

B: Place TNR Brace Assembly against (2771) End Post Left so it sits under the slide. It is not attached yet. (fig. 33.1)

C: On the fourth Elbow Assembly attached remove the pan bolt and nut which is facing the fort (installed in Step 29).   (fig. 33.1) **The bolt will no longer be needed, but keep the lock nut.**

D: Loosely attach TNR3 Tube Support (at the slightly bent end) to the Clamp Ring using 1 (PB6) 1/4 x 1" Pan Bolt (with flat washer and the previously removed lock nut). (fig. 33.2)

E: Rotate TNR3 Tube Support and attach to (2771) End Post Left using 1 (S6) #12 x 1" Pan Screw as shown in fig. 33.2.

F: Fully tighten screw and bolt.

Remove PB1 (Pan Bolt) first then install PB6 Pan Bolt with flat washer)

Fig. 33.1

Fig. 33.2

TNR 3 Tube Support

2771

LN1

FW1

PB6

S6

Note: Flat end down

2771

TNR Brace Assembly

Attach 2 remaining Elbow Assemblies

Hardware

1 x (S6) **#12 x 1" Pan Screw**

1 x (PB6) **1/4 x 1" Pan Bolt**
          (1/4" flat washer & 1/4" lock nut - previously removed)

16 x (PB1) **1/4 x 3/4" Pan Bolt (1/4" lock nut)**

Other Parts

1 x TNR3 Tube Support
**4 x TNR2 Slide Clamp Ring**

Step 34: Attach TNR Brace Assembly

A: Use (8965) TNR Upright as a guide to judge the proper bolt location, remove the bottom pan bolt and nut. ***The bolt will no longer be needed, but keep the lock nut.*** (fig. 34.1 and 34.2)

B: Attach the top of the TNR3 Post Mount to TNR2 Slide Clamp Ring using 1 (PB2) 1/4 x 1-1/4" Pan Bolt (with the previously removed lock nut and 1 flat washer). (fig. 34.2)

C: Insert TNR3 Post Mount on (8965) TNR Upright, pre-drill with a 1/8" (3.2 mm) drill bit then attach with 2 (S6) #12 x 1" Pan Screws**.**   (fig. 34.2)

D: Remove (H8) Hex Bolt from bottom of (2771) End Post then attach (8963) TNR Ground Brace flush to the bottom of (2618) Front Back Panel with 2 (S11) #8 x 2" Wood Screws and 1 (S4) #8 x 3" Wood Screw.   (fig. 34.1 and 34.3)

Remove PB1 (Pan Bolt) first then install PB2 Pan Bolt with previously removed lock nut)

Fig. 34.1

Fig. 34.2

TNR2 Slide Clamp Ring

FW1 LN1

TNR3 Post Mount

PB2

S6

8965

Remove H8 (Hex Bolt) first from post then attach TNR Brace Assembly

2771

8965

TNR Brace Assembly

2771

Fig. 34.3

2771

8963

S11

S4

Hardware

1 x (PB2) **1/4 x 1-1/4" Pan Bolt (flat washer, lock nut - previously removed)**
2 x (S6) **#12 x 1" Pan Screw**
1 x (S4) **#8 x 3" Wood Screw**
2 x (S11) **#8 x 2" Wood Screw**

Other Parts
1 x TNR3 Post Mount

Step 35: Attach TNR2 Slide Exit to Exit Elbow Assembly

A: Insert flange of Exit Elbow Assembly (slide elbow) into the slots on TNR3 Short Exit. (fig. 35.1)

B: Rotate Slide Exit and use Quadrex Driver as a guide pin so the holes are aligned and attach with 5 (PB1) 1/4 x 3/4" Pan Bolts (with lock nuts) starting with the bottom middle hole and working up each side. (fig. 35.2 and 35.3)

C: At this point make sure all the slide bolts are tight. *Use a 7/16" (11.1 mm) open end wrench to hold nut and then tighten bolt with Quadrex Driver on Clamp Rings.*

Fig. 35.1

Exit Elbow Assembly

Slot of TNR3 Short Exit

TNR3 Short Exit

Fig. 35.3

LN1

PB1

PB1

Bottom of Slide Views

LN1

PB1

Fig. 35.2

Start with this bolt

PB1

Hardware

5 x (PB1) 1/4 x 3/4" Pan Bolt (1/4" lock nut)

Other Parts

1 x TNR3 Short Exit

Step 36: Attach Exit End Assembly to Fort

Note: When installing Pan Bolts make sure to look at holes so bolts go through the side with the round recess and the lock nuts go through the side with the hexagonal recess. Keep all bolts loose until further step.

A: Fit the Exit End Assembly to the last Elbow Assembly by lining up the arrows on each assembly. Notice the elbow orientation.   (fig. 36.1)

B: Place 1 TNR2 Slide Clamp Ring to the top of the joined Assemblies, rotate counter clockwise 1 hole location then attach with 3 (PB1) 1/4 x 3/4" Pan Bolts (with lock nut) as shown in fig. 36.1.

Use Quadrex Driver as a guide pin for each hole before inserting bolt.

C: Attach 1 TNR2 Slide Clamp Ring to the bottom of the joined Assemblies using 3 (PB1) 1/4 x 3/4" Pan Bolts (with lock nut) as shown in fig. 36.2.

D: Connect the 2 TNR2 Slide Clamp Rings together in 2 spots using 1 (PB1) 1/4 x 3/4" Pan Bolt (with lock nut) per hole. Make sure seams and arrows line up and then tighten all bolts. (fig. 36.3).

Fig. 36.1
Top Slide Bolt Holes

Exit Elbow Assembly

PB1

Elbow Assembly

LN1

Fig. 36.3

After the clamp rings are attached to the elbows, fasten them end to end with two pan bolts and lock nuts

PB1

LN1

Fig. 36.2
Bottom Slide Bolt Holes

LN1

PB1

Hardware

8 x (PB1) 1/4 x 3/4" Pan Bolt (1/4" lock nut)

Other Parts

2 x TNR2 Slide Clamp Ring

Step 37: Attach Ground Stake to TNR Upright

A: In the spot shown in fig. 37.1 drive 1 Rebar Ground Stake 13" (330 mm) into the ground against the (8965) TNR Upright. Be careful not to hit the washer while hammering stake into the ground as this could cause the washer to break off.

B: Attach the ground stake to (8965) TNR Upright just below the (TN1) T-nut using 1 (S7) #12 x 2" Pan Screw as shown in fig. 37.2.

C: After driving stakes into the ground, check for sharp edges caused by the impact of the hammer. Smooth any sharp edges from impact area and touch up with outdoor paint.

> ⚠ **Warning! To prevent tipping and avoid potential injury, stakes must be driven 13" (330 mm) into ground. Digging or driving stakes can be dangerous if you do not check first for underground wiring, cables or gas lines.**

Fig. 37.1

Fig. 37.2

TN1

8965

S7

13" (330 mm) In Ground

Rebar Ground Stake

Hardware		Other Parts
1 x (S7) #12 x 2" Pan Screw		1 x Rebar Ground Stakes

Step 38: Attach Window Mesh - Large
Part 1

A: From inside the assembly place the Window Mesh - Large over the upper opening in the Swing Wall, make sure the mesh is smooth and tight then attach all four corners to (2757) LT Post Assembly and (2758) RT Post Assembly with 4 (S5) #8 x 1/2" Pan Screws (with #8 flat washers). (fig. 38.1)

Fig. 38.1

Inside View

Swing Wall

FW3

S5

2758

FW3

S5

FW3

S5

FW3

S5

2757

Window Mesh - Large

Hardware	Other Parts
4 x (S5) **#8 x 1/2" Pan Screw (#8 flat washer)**	**1 x Window Mesh - Large**

Step 38: Attach Window Mesh - Large Part 2

B: Along each side measure 4-1/2" (114 mm) down from the top screws and the same dimension up from the bottom screws then attach 2 (S5) #8 x 1/2" Pan Screws (with #8 flat washer) per side to (2757) LT Post Assembly and (2758) RT Post Assembly. (fig. 38.2)

C: Along the top and bottom measure 6-3/8" (162 mm) in from the corner screws on one side then attach 5 (S5) #8 x 1/2" Pan Screws (with #8 flat washer) to (2630) SW Top and (2756) Siding Assembly. Each screw to be the same dimension apart. (fig. 38.2)

Fig. 38.2

Hardware

14 x (S5) **#8 x 1/2" Pan Screw (#8 flat washer)**

Step 39: Attach Window Mesh - Small

A: From inside the assembly place the Window Mesh - Small over the upper opening in the Back Wall over the MOD 3-Pane Transom, make sure the mesh is smooth and tight then attach all four corners to (2771) End Post, (2602) Upper Jamb and (2769) Panel BT Frame with 4 (S5) #8 x 1/2" Pan Screws (with #8 flat washers). (fig. 39.1)

**B:** Along each side measure 5-1/2" (140 mm) down from the top screws and the same dimension up from the bottom screws then attach 2 (S5) #8 x 1/2" Pan Screws (with #8 flat washer) per side to the post and (2602) Upper Jamb. (fig. 39.1)

C: Along the top and bottom measure 6" (152 mm) in from the corner screws on one side then attach 2 (S5) #8 x 1/2" Pan Screws (with #8 flat washer) to (2769) Panel BT Frame and (649A) Short Half Wall. Each screw to be the same dimension apart. (fig. 39.1)

Fig. 39.1

Start at all four corners

MOD 3-Pane Transom not shown

S5 x 12

FW3 x 12

2769

2771

2602

649A

5-1/2" (140 mm)

Window Mesh - Small

6" (152 mm)

Hardware	Other Parts
12 x (S5) #8 x 1/2" Pan Screw (#8 flat washer)	1 x Window Mesh - Small

Step 40: Attach I.D. Plaque

ATTACH THIS WARNING & I.D. PLAQUE TO THIS LOCATION ON YOUR PLAY EQUIPMENT!

This provides warnings concerning safety and important contact information. A Tracking Number is provided to allow you to get critical information or order replacement parts for this specific model.

A: Attach KK Playset Plaque to a location on your set that is easily seen and read by a supervising adult using 4 (S5) #7 x 1/2" Pan Screws as shown below.

⚠ WARNING

CONTINUOUS ADULT SUPERVISION REQUIRED!

STRANGULATION HAZARDS

Never allow children to play with ropes, clotheslines, pet leashes, cables, chains or cord-like items when using this playset or to attach these items to play-set.

Never allow children to wear loose fitting clothing, ponchos, hoods, scarves, capes, necklaces, or items with draw-strings, cords or ties when using this play-set.

Never allow children to wear bike or sport helmets when using this play-set.

Failure to prohibit these items increases the risk of serious injury and death to children from entanglement and strangulation.

SERIOUS HEAD INJURY HAZARD

Maintain shock absorbing material under and around play-set as recommended in the Installation & Operating Instructions. Installation over concrete, asphalt, dirt, grass, carpet and other hard surfaces creates a risk of serious injury or death from falls to the ground.

For children 3 to 10 years of age; weight limit of 110 lbs. per child. Maximum number of users, Installation & Operating Instructions; other information is available at:

www.KidKraft.com
Contact us at: KidKraft
Dallas, TX 75244 USA
1-800-933-0771

Tracking Number:

KK Playset Plaque

S5

Hardware

4 x (S5) **#8 x 1/2" Pan Screw**

Other Parts

1 x **KK Playset Plaque**

Step 41: Final Step

A: Inspect entire play centre and insert hole plugs into all unused holes. See fig. 40.1 and 40.2 for an example.

**B:** Check entire play centre for bolts protruding beyond t-nuts. Use extra Washers to eliminate this condition.

If Bolt protrudes beyond T-Nut

Use an extra flat washer

Fig. 41.2

Unused Hole

Fig. 41.1

Hole Plug

Hole Plug

Hardware

10 x Hole Plugs

Fort Guide

2655

Front Wall (Step 1)

2655 (Step 11)

Clock Set

Clock Set (Step 13)

Cafe Canopy (Step 18)

Cafe Table Assembly (Step 17)

2655

2665

Front Wall

2665 (Step 12)

Cafe Canopy

Cafe Table Assembly

TNR III (Step 29 -38) Tube Slide

MOD Side Lite

2602

8935

End Wall (Step 2)

2601

649A

2649

2602 (Step 11)

TNR III Tube Slide Position (Step 31)

MOD Side Lite (Step 28)

8935 (Step 28)

2601 (Step 11)

2649 (Step 12)

649A (Step 12)

End Wall

Fort Guide

Back Wall (Step 1)

MOD 3-Pane Transom

649A

Window Mesh - Small

Hand Grip

Rock Wall Assembly

MOD 3-Pane Transom (Step 12)

Window Mesh - Small (Step 40)

Hand Grip (Step 16)

649A (Step 12)

Rock Wall Assembly (Step 14 -15)

Back Wall

Roof Assembly with Sky Gables (Step 19 -24)

Swing Assembly (Step 6 -9)

Window Mesh - Large (Step 38)

Swing Assembly

Swing Wall

Maximum Number of Users: 10

29'-9" (9.08M)

16'-8" (5.08M)

27'-0" (8.23M)

7'-6" (2.29M)

NOTES

KIDKRAFT
Consumer Registration Card

First Name   Initial   Last Name

Street   Apt. No.

City   State/Province   ZIP/Postal Code

Country   Telephone Number

E-Mail Address

Model Name   Model Number   (Box Labels)

Serial Number (on ID Plaque)

Date Purchase   Purchased From

MM / DD / YY

How would you rate this product for quality?
☐ Excellent   ☐ Very Good   ☐ Average   ☐ Below Average   ☐ Poor

How would you rate this product for ease of assembly?
☐ Excellent   ☐ Very Good   ☐ Average   ☐ Below Average   ☐ Poor

How would you rate our instructions?
☐ Excellent   ☐ Very Good   ☐ Average   ☐ Below Average   ☐ Poor

How would you rate the quality of packaging?
☐ Excellent   ☐ Very Good   ☐ Average   ☐ Below Average   ☐ Poor

Would you recommend the purchase of our products to friends and family?
☐ Yes   ☐ No

Comments:

_____

_____

_____

MAIL TO:
KidKraft Netherlands BV
Olympisch Stadion 29
1076DE Amsterdam
The Netherlands
Attention: Customer Service

Fill out your registration card online at
https://prdregistration.kidkraft.com/

KidKraft would like to say Thank You for your time and feedback.

KidKraft

CUT ALONG LINE