


Storage Bench




IMPORTANT

Carefully remove all the parts from the carton and place them individually on a soft cloth to prevent scratches or other damage.


Carefully and strictly follow these assembly instructions to ensure a completed product as designed.

Do not use power tools above 8 volts to assemble.

Part List




A.
Cushion
1 pc.




D.
Front Rail
1 pc.




E.
Front Rail
1 pc.




B.
Side Panel
1 pc.



C.
Side Panel
1 pc.




F.
Base
1 pc.



G.
Back Panel
1 pc.

Hardware List



Hex Wrench
1 pc.

Small
Hex Wrench
1 pc.




Cam Lock
10 pcs. (+2 extra)



Cam Lock Screw
10 pcs. (+1 extra)



M3.5x32
Wood Screw
6 pcs. (+1 extra)



M6x32
Head Cap Bolt
4 pcs. (+1 extra)



Spring Washer
4 pcs. (+1 extra)



Flat Washer
4 pcs. (+1 extra)

Tool(s) required for assembly: Phillips screwdriver

Home Styles Customer Service: www.homestyles-furniture.com,
servicedesk@homestyles-furniture.com, 888-680-7460, 877-831-0319

Assembly Instructions 2/4

IMPORTANT

- Use a soft cloth between these parts and the floor.
- Do not use power tools above 8 volts to assemble.
- Do not tighten all the bolts until each part is properly assembled.
- Keep Hex Wrench as the bolts may need to be tightened in the future.





Figure 1



STEP 1

Insert Cam Lock Screws into pre-drilled holes in Side Panels (B), (C), Front Rail (E) and Back Panel (G), then tighten. (See Figure 1)

STEP 2

Attach Base (F) to Back Panel (G) with Cam Lock. (See Figure 2)

Attach Front Rail (E) to unit with Cam Lock.





Figure 2



Assembly Instructions 3/4

STEP 3

Attach unit and Front Rail (D) to Side Panel (C) with Cam Locks, Head Cap Bolts, Spring Washers and Flat Washers. (See Figure 3)






Figure 3



STEP 4

Attach Side Panel (B) to unit with Cam Locks, Head Cap Bolts, Spring Washers and Flat Washers.





Figure 4




STEP 5

Place Cushion (A) upside down on a soft cloth.

Attach unit to Cushion (A) with Wood Screws. (See Figure 4)

STEP 6

Turn unit over to its upright position.



CARE INSTRUCTIONS

NEVER

allow liquids to remain on furniture.
Absorption causes parts to warp
and split and finishes to delaminate.

NEVER

use glass cleaners on
finished furniture. Ammonia
chemically attacks the finish.



Do not use power tools
above 8 volts to assemble.
**PREVENT
CRACKING**



Do not place
in direct sunlight.
**PREVENT
FADING**



Do not write
directly on surface.
**PREVENT
MARKING**



Do not place hot
objects on surface.
**PREVENT
FINISH DAMAGE**



Do not use rubber
based placemats.
**PREVENT
DISCOLORING**



Do not use commercial
waxes and polishes.
**PREVENT
YELLOWING**

CLEAN

with a soft cloth moistened
in lukewarm soap and water.
Buff with a dry clean cloth.



Home Styles will provide replacements free of charge for missing or damaged hardware or parts within 30 days of purchase. Digital images of the defective parts may be required. If the product was not purchased from an authorized retail affiliate, Home Styles is under no obligation to provide replacement parts. Parts are not available for fully assembled items nor are parts available for sale. Replacements for missing or damaged hardware or parts may be requested at:

www.homestyles-furniture.com/customer-service/replacement-parts

Home Styles Customer Service: www.homestyles-furniture.com,
servicedesk@homestyles-furniture.com, 888-680-7460, 877-831-0319