



Tournament Washer Toss



Please keep this instruction manual for future reference

**If you have any problems with your new product,
please contact Triumph Sports USA at 1-866-815-4173,
or e-mail us at csr@triumphsportsusa.com
for any technical support or warranty issues.**

Limited 90-Day Triumph Sports USA, Inc. Warranty

All Triumph Sports USA, Inc. (TSU) games have a limited 90-day from date of purchase warranty. This warrants the retail purchaser for any TSU game purchased to be free from any defect in materials and construction for 90 days from the date of purchase. The only exceptions to the warranty include main frames, tabletops, playing surfaces, batteries or tools. Damaged main frames, tabletops, playing surfaces need to be returned to the store as we are unable to replace these parts. Normal play wear and usage is not covered under the warranty, nor is wear or damage due to improper use of the TSU game. This will void any and all TSU warranties.

A PURCHASE RECEIPT (or other proof of purchase date) will be required before any warranty service is initiated. All requests for warranty service can be submitted by email, in writing or by contacting our Customer Service Department at: 1-866-815-4173 or email us at csr@triumphsportsusa.com.

IMPORTANT NOTICE! Please contact us before returning the product to the store.

Warnings



WARNING: Choking Hazard--Toy contains small parts.
Not for children under 3 years of age.

Be sure to check out all the exciting games  has to offer.

Visit our web site at:

www.triumphsportsusa.com



BILLIARDS



DARTS



GAME TABLES



CASINO



OUTDOOR GAMES



DARTBOARDS

Triumph Sports USA
11327 W Lincoln Ave.
West Allis, WI 53227

www.triumphsportsusa.com

©2014 Triumph Sports USA. All Rights Reserved.

Parts List

1



Washer Box
2 pcs

2



Blue Washer
3 pcs

3



Red Washer
3 pcs

Game Rules



Tournament Washer Toss

2 to 4 players, singles (2) or partners (4)

Preparation: Set the boxes 15 feet apart on even ground.

Game Rules: Players score points by tossing washers into the box or cup (center piece): one point for a washer that lands in the box, and three points for a washer that lands in the cup. The first person or team to score 21 points wins.

Optional: Some players require the winning person or team to reach 21 without going over.

Game Play Summary:

Players always throw towards the same box. The team or player that scored points last goes first, throwing all three washers. Points are added up for all washers that land in the box.

Example:

If Player 1 throws 3 washers and gets 2 in the cup and 1 in the box, he has scored 7 points. If Player 2 then throws 3 washers and gets 1 in the cup and 2 in the box, she has scored 5 points. Play continues until a total of 21 points is reached by one player or team. The game is over when a score of 21 is reached.

Miscellaneous:

When pitching washers, the player's toe or foot must be behind the front of the box. Some variations allow 2 points for landing a washer on the box.