


# BLACK STEEL CHIMINEA

## KF-607













Review all assembly and care information before using this product. Save this manual for future reference.  
**Assemble components on a soft, clean surface to avoid damaging the finish.**









SCAN THIS CODE  
WITH YOUR  
SMARTPHONE  
TO VIEW OUR  
ASSEMBLY VIDEO




Inspect packaging to ensure all parts are accounted for before disposing of packing materials.  
Save the packing slip.

No.	PARTS		QTY.
A		Flue Cap	1
B		Flue Grill	1
C		Flue Mouth	1
D		Flue	1
E		Top Body	1
F		Mesh Screen	1
G		Log Grate	1
H		Ash Pan	1
I		Fire Bowl	1
J		Pedestal	1
K		Base	1
L		Rain Cover	1

No.	HARDWARE & TOOLS		QTY.
O		Bracket	8
T		1/4"x5/8" Bolt	28
U		Washer	28
V		Nut	28
Y		Spanner	1
Z		Poker	1

### TOOLS REQUIRED (not included)



Regular Screwdriver



**CHOKING HAZARD** — This item contains small parts that can be swallowed. Keep children and pets away during assembly.

### WARNING:


Manufacturer and seller expressly disclaim any and all liability from personal injury, property damage or loss, whether direct or indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, or neglect of this product.

# ASSEMBLY

*Review all steps and understand assembly before beginning.*

## STEP 1


J: 1  
K: 1  
T: 4  
U: 4  
V: 4



Align Pedestal (J) with Base (K) and securely fasten using four Bolts (T), Washers (U), and Nuts (V).

## STEP 2

I: 1  
T: 4  
U: 4  
V: 4




Secure Fire Bowl (I) to the pedestal using four Bolts (T), Washers (U), and Nuts (V).

## STEP 3

F: 1  
O: 4  
T: 8  
U: 8  
V: 8

**IMPORTANT:** When installing the screen, the door with the latch must be on the right and the door with the catch must be on the left.

**IMPORTANT:** Do not fully tighten fittings until these components are loosely assembled. If fittings are tightened too soon, mounting holes may not align, and parts may not easily fit together.




Ensuring the mounting holes align, place Mesh Screen (F) onto the fire bowl.

Loosely secure four Brackets (O) to the inside of the fire pit using two Bolts (T), Washers (U), and Nuts (V) for each bracket.

Finish tightening all hardware.

## STEP 4

E: 1  
O: 4  
T: 8  
U: 8  
V: 8



Ensuring the mounting holes align, place Top Body (E) onto the mesh screen.

Loosely secure four Brackets (O) on the inside of the fire pit using two Bolts (T), Washers (U), and Nuts (V) for each bracket.

Finish tightening all hardware.


## STEP 5

D: 1

T: 4

U: 4

V: 4




Securely fasten Flue (D) to the top body using four Bolts (T), Washers (U), and Nuts (V).

## STEP 6

A: 1

B: 1

C: 1




Install Flue Mouth (C) onto the Flue.  
Place Flue Screen (B) inside the flue mouth.  
When not in use, place Flue Cap (A) over the flue mouth.

## STEP 7

G: 1

H: 1



Place Ash Pan (H) in the center of the fire bowl.  
Place Log Grate (G) over the ash pan.

# CARE & MAINTENANCE

**SAFE USE:** Only use fire pits on a flat, non-combustible surface such as concrete, rock, or stone. Do not use this fire pit on a wood deck or any other combustible surfaces like dry grass, leaves, mulch, etc. Never use in an area with an overhead structure or near any unprotected combustible constructions like vinyl or wood siding. Avoid using near or under overhanging trees and shrubs.

The fire pit will become extremely hot while in use. Always use the poker tool and heat-resistant gloves when maintaining a fire.

**NO ACCELERANTS, NO PLASTICS:** Never use an accelerant, i.e. gasoline or kerosene, to start a fire; doing so is dangerous and can damage your fire pit.

Never use any plastic materials in or near a fire pit. The emissions from burning plastic are toxic. Additionally, plastic residue is very difficult to remove.

**EXTINGUISH:** Let fire die down gradually and go out on its own. DO NOT use water to put out a fire as the sudden drop in temperature may cause serious injury and/or damage the metal.

**EXPOSURE & MAINTENANCE:** Long-term exposure to high-intensity heat can cause the mesh screens to warp and the high-temperature paint to flake or burn off the steel. If the steel is exposed to moisture, it will rust. As with any outdoor steel product, periodic maintenance is required to maintain integrity and appearance. Remove rust and refinish with a suitable high-temperature paint; carefully follow the paint manufacturer instructions and ensure the paint is completely dry before using the unit again.

**CLEANING:** Remove ashes and debris before every use. Ensure the fire pit and ashes are completely cool before cleaning. Ashes can remain hot long after a fire dies down. If you feel heat when your hand is close to the metal or the ashes, the unit is too hot to clean.

**COVER AND STORE:** Ensure the unit is completely cool and clean before covering. Do not allow the fire pit to be exposed to water. Store this unit in a dry location to protect it from environmental elements. The manufacturer is not liable for damage resulting from general use and/or environmental conditions.

**WARNING: THE ONE-YEAR WARRANTY DOES NOT COVER DAMAGES OR DEFECTS CAUSED BY THE APPLICATION OF CHEMICAL TREATMENTS, PROTECTIVE COATINGS, TOUCH-UP PAINT, OR CLEANING PRODUCTS.**

## SAFETY STATEMENTS & WARNINGS

- For outdoor use only. Never use this product in an enclosed area.
- Always follow local laws and regulations when using wood-burning fire pits.
- Exercise the same care and precautions as you would with an open fire.
- Always supervise children and pets when they are in proximity of this product, whether it is in use or not in use.
- Never use any fire pit during dry or windy conditions.
- Keep unit a safe distance away from buildings, balconies, or overhangs when in use.
- Do not use on or near combustible surfaces or structures such as wood decks, dry leaves or grass, mulch, vinyl or wood siding, etc.
- Only use this unit on a level, non-combustible surface.
- Keep away from all combustible materials including gasoline and other flammable liquids and vapors.
- Never use accelerants such as, but not limited to, gasoline, alcohol, paint thinners, kerosene, as this may cause serious injury or product damage.
- Do not overfill or use this unit or use it to burn leaves or trash.
- This unit becomes very hot when in use. Ensure the unit is completely cool before cleaning or moving.
- Never leave unit unattended while hot or in use.
- Extinguish the fire properly before leaving the unit unattended. If necessary, use a fire extinguisher or sand to smother the fire. NEVER use water to extinguish hot fires or embers as doing so may cause serious injury and/or permanently damage the product.
- Ashes can remain hot for a long time after fire is extinguished. Dispose of cold ashes properly.
- Ensure the unit is completely cool before covering, failure to do so will damage the cover and the unit.
- DO NOT USE CHEMICAL-BASED CLEANERS as this may damage the product and/or ignite a flame during the next use.
- Contact local authorities regarding possible burn restrictions before using this product.

**Any modification to the product or failure to follow recommended care will void the product warranty.**

*If you experience issues with assembly or the product was damaged during transit, please contact our customer service team through one of the methods mentioned at the top of page 1.*

*Please have the item number and order information ready to expedite response time.*

## WARNING:

Manufacturer and seller expressly disclaim any and all liability from personal injury, property damage or loss, whether direct or indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, or neglect of this product.