

homestyles®

4528-95


Kitchen Cart

IMPORTANT


Carefully remove all the parts from the carton and place them individually on a soft cloth to prevent scratches or other damage.

Carefully and strictly follow these assembly instructions to ensure a completed product as designed.

Do not use power tools above 8 volts to assemble.




Part List



Refer to later page(s) of these instructions for drawer assembly.

Hardware List



Tool(s) required for assembly: Phillips screwdriver

**homestyles Customer Service: www.homestylesfurniture.com,
servicedesk@homestylesfurniture.com, 888-680-7460**

Assembly Instructions 2/7

IMPORTANT

- Use a soft cloth between these parts and the floor.
- Do not use power tools above 8 volts to assemble.
- Do not tighten all the bolts until each part is properly assembled.
- Keep Hex Wrench as the bolts may need to be tightened in the future.

STEP 1

Attach Back Rail (E1) to Side Panel (B) with Head Cap Bolt (short).
(See Figure 1)

Attach Back Uprights (F) and (G) to unit.

Slide Back Panels (H) into position.

Attach Back Rail (E2) to unit with Head Cap Bolt (short).





Figure 1



STEP 2

Attach Front Rail (I) to unit with Head Cap Bolt (short).

Attach Divider (K) to unit with Cross Dowel and Head Cap Bolt (long). (See Figure 2)

Attach Front Rail (J) to unit with Head Cap Bolt (short).





Figure 2



Assembly Instructions 3/7

STEP 3

Attach Middle Panel (C) to unit.

Attach Side Panel (D) to unit with Head Cap Bolts (short).

Head Cap Bolt (short)



STEP 4

Attach Base (L) to unit with Cross Dowels and Head Cap Bolts (long).

Note: Arrow label indicates front of Base (L).

Assembly Instructions 4/7

STEP 5

Attach Casters to unit with Wood Screws for Caster into pre-drilled holes, with Locking Casters at front. (See Figure 3)

Note: Arrow label indicates front of unit.





Figure 3



STEP 6

Turn unit over to its upright position.

Attach Side Bars (M) to unit with Head Cap Bolts (short).

Insert Adjustable Pins into side panels and middle panel at desired level. (See Figure 4)

Place Shelves (N) into position.





Figure 4

Assembly Instructions 5/7

STEP 7

Attach Doors (O) and (P) by sliding door hinges into side panel hinges. (See Figure 5)

Attach Handles to Doors (O) and (P) with Machine Screws. (See Figure 6)





Figure 5




Figure 6





Figure 7




STEP 8

Insert Cam Lock Screws into pre-drilled holes in Top (A), then tighten. (See Figure 7)

Note: Arrow label indicates front of Top (A).

Assembly Instructions 6/7

Drawer (Q)



STEP 9



Attach Drawer Front (Q1) and Drawer Back (Q2) to Drawer Side (Q3) with Wood Screws (long).

Attach Drawer Side (Q4) to unit with Wood Screws (long).

STEP 10

Slide Drawer Bottom (Q5) into groove.


Attach Drawer Bottom (Q5) to unit with Wood Screws (short).




STEP 11

Attach Handle with Machine Screws.


Part List




Q1.
Drawer Front
2 pcs.




Q2.
Drawer Back
2 pcs.



Q3.
Drawer Side
2 pcs.



Q4.
Drawer Side
2 pcs.



Q5.
Drawer Bottom
2 pcs.

Assembly Instructions 7/7

STEP 12

Attach Top (A) to unit with Cam Locks.
(See Figure 8)

Slide Drawers (Q) into position.





Figure 8



STEP 13

Cover all holes with Wood Plugs.
(See Figure 9)





Figure 9

CARE INSTRUCTIONS

NEVER

allow liquids to remain on furniture.

Absorption causes parts to warp and split and finishes to delaminate.


NEVER

use glass cleaners on finished furniture. Ammonia chemically attacks the finish.



Do not use power tools above 8 volts to assemble.

PREVENT CRACKING



Do not place in direct sunlight.

PREVENT FADING



Do not write directly on surface.

PREVENT MARKING



Do not place hot objects on surface.

PREVENT FINISH DAMAGE



Do not use rubber based placemats.

PREVENT DISCOLORING




Do not use commercial waxes and polishes.

PREVENT YELLOWING

CLEAN

with a soft cloth moistened in lukewarm soap and water.
Buff with a dry clean cloth.



homestyles will provide replacements free of charge for missing or damaged parts within 30 days of purchase. Digital images of the defective parts may be required. If the product was not purchased from an authorized retailer, **homestyles** is under no obligation to provide replacement parts. Parts are not available for fully assembled items nor are parts available for sale. Replacements for missing or damaged parts may be requested via contact info below.

homestyles Customer Service: www.homestylesfurniture.com,
servicedesk@homestylesfurniture.com, 888-680-7460