

INSTRUCTION MANUAL

INCLUDES:

- » Quickster 4-in-1 Football Trainer
- » Hi-viz target
- » Steel ground stakes (4)
- » Easy-stuff carry bag

SKLZ®

QUICKSTER® 4-IN-1 FB TRAINER

IDEA SUBMISSION

If you have an idea for a new and innovative sports training product, visit SKLZ.com to submit your concept. Some restrictions may apply.

US and foreign
patents pending

LIMITED WARRANTY

REGISTER YOUR PRODUCT AT SKLZ.COM
TO ENSURE WARRANTY
COVERAGE, GET NEW PRODUCT
INFORMATION AND SPECIAL DEALS
FROM SKLZ

Pro Performance Sports (PPS) / SKLZ warrants to the original consumer purchaser of any PPS/SKLZ product it manufactures that the product will be free of defects in materials or workmanship for 90 days (unless specified in alternate warranties) from the date of purchase. If defective and purchased from a retail store, return the product along with receipt to the retail store where the product was purchased. If the item was purchased from PPS/SKLZ, return the product along with the packing slip (proof of purchase) postage prepaid to the address below for replacement consideration. Label: Attn: Returns

This warranty does not cover damages resulting from accident, misuse, abuse or lost merchandise. Only valid in the USA. All returns sent to PPS/SKLZ require a Return Merchandise Authorization number (RMA). For returns to PPS/SKLZ and for all other Customer Service inquiries, please email customerservice@sklz.com or call toll free, 1-877-225-7275 for a return authorization number for any exchange.

Made in China. ©2013 Pro Performance Sports, LLC. All rights reserved. Manufactured and distributed by SKLZ/Pro Performance Sports: 2081 Faraday Avenue, Carlsbad, CA 92008 U.S.A. SKLZ, SKLZ Pro Grade, SKLZ Chrome and Sport-Brella are registered trademarks of Pro Performance Sports, LLC., its subsidiaries and affiliates. Product features, appearance, and specifications may be subject to change without notice. Unauthorized duplication is a violation of applicable local and international laws.

**VISIT SKLZ.COM
FOR INSTRUCTIONAL VIDEO AND CONTENT**



Training Videos & Articles: SKLZ.com
facebook.com/SKLZfans
twitter.com/SKLZ




Thank you for choosing SKLZ Quickster 4-in-1 FB Trainer. We are dedicated to providing you with the best tools and instruction possible to help you unleash your athletic potential. If there is anything else we can do to help you optimize your training, don't hesitate to send us an email (customerservice@sklz.com) or give us a call (1-877-225-7275).

BEFORE YOU BEGIN:

- » Read all setup and usage instructions carefully before using. If the setup and/or instructions are not followed correctly, it could result in injury or damage to the product.
- » Adult assembly recommended.
- » Make sure you have all of the Quickster 4-in-1 FB Trainer components. Please contact SKLZ customer service toll free at 1-877-225-7275 if you are missing anything.
- » When finished using, disassemble Quickster 4-in-1 FB Trainer and store after use. Do not leave outdoors.

⚠WARNING:

- » Quickster 4-in-1 FB Trainer is under tension when assembled. Please take the utmost care when releasing the tension during disassembly. Failure to do so may result in injury.
- » Set up Quickster 4-in-1 FB Trainer in a clear area to avoid damage to property.
- » Do not climb or hang on the Quickster 4-in-1 FB Trainer.
- » Keep away from fire and heat sources.
- » Regularly check for wear and tear. Stop using Quickster 4-in-1 FB Trainer if any part of it breaks. Failure to do so could result in injury.
- » Trainer not suitable for children under 3 years of age.




QUICKSTER 4-IN-1 FB TRAINER PARTS:


A NET WITH BALL COLLECTION SKIRT




B BASE FRAME



C TENSION-TITE™ ARM POLE (2)



D HI-VIZ TARGET TRAINER



E GROUND STAKES (4)



QUICKSTER® 4-IN-1 FB TRAINER ASSEMBLY


STEP 1 BASE FRAME & TENSION-TITE™ ARM POLE

1. Lay out one Arm Pole (C) and link together to form a straight pole. Repeat with the second Tension-Tite Arm Pole.

NOTE: Base Frame and Tension-Tite arm poles come pre-attached by elastic cords.

2. Lay out Base Frame (B) and link the frame together. Make sure to secure the poles with the push buttons.
3. Slide a Tension-Tite Arm Pole into each side of the Base Frame.

NOTE: Ensure arm poles are fully inserted. Failure to do so may result in damage to the Quickster.



STEP 2 CONNECT THE NET TO THE FRAME

1. Unfold the Net (A) and slide the pin at the top of one corner of the net into the top of the Tension-Tite Arm Pole. Make sure that the Quickster logo on the ball collection skirt is facing away from the frame. Repeat on the other side.





2. Attach bottom Net loop attachments to the plastic post hooks on each side of the Base Frame (B).

3. Attach the back of net to Arm Poles (C) by using the Velcro straps.


NOTE: Check the frame to make sure it is securely and fully assembled with the net before securing to the ground.

4. Attach the ball collection skirt to the toggle hook attachments.

NOTE: The ball collection flap should be detached and folded down during punting practice.



Webbing attachment



STEP 3 SECURE THE QUICKSTER




1. Place the Quickster in the desired location and ensure it is on level ground. Secure frame with included Ground Stakes (E). Ground Stakes can be secured with hand, foot or mallet.

NOTE: Care should be taken when pressing in the ground stakes. Pole can be bent if driven too far into the ground or hard surface.

CAUTION: Make sure the Quickster is secured into the ground before play. During play, make sure the Ground Stakes are secure as a loose Ground Stake may cause injury.

ONLY SECURE STAKES WHERE INDICATED ABOVE.

STEP 4 ATTACH HIGH-VIZ TARGET (optional)




Top Attachment


Bottom Attachment

1. Unfold the Target (D) and find the top straps (with adjustment buckles).
2. Attach hook of the top strap through the fabric loop at the top left corner of the net, repeat on the other side.
3. Take one of the bottom straps of the target and hook through fabric loop on the bottom corner of the net, repeat on the other side.

NOTE: Two of the webbing straps are shorter to adjust placement within the frame. For a lower target (ideal for snapping), attach the short straps at the bottom (1). For a higher target (ideal for passing), attach the short straps to the top (2).



snapping



passing

STORING YOUR QUICKSTER

1. Remove the Ground Stakes and place the Ground Stakes into the carry bag.
2. Hold one pin in one hand and one Tension-Tite Arm Pole in the other while pulling the pin out. Repeat on the other side. Remove the net loop attachments from each side of the frame. If needed, air dry the net before you fold and place it into the carry bag.
3. Pull the Tension-Tite Arm Poles out of each side of the base frame, unlink and fold them down to store.
4. Unlock the push button on the Base Frame to unlink the frame. Fold and store in carry bag.

NOTE: Store Tension-Tite Arm Pole in the carry bag with the round tops facing away from each other.