



# KICK-OUT

## GETTING STARTED



Thank you for choosing SKLZ Kick-Out. We are dedicated to providing you with the best tools and instruction possible to help you unleash your athletic potential. If there is anything else we can do to help you optimize your training, don't hesitate to send us an email ([customerservice@sklz.com](mailto:customerservice@sklz.com)) or give us a call (**1-877-225-7275**).

### BEFORE YOU BEGIN:

- Read all setup and usage instructions carefully.
- This product is not suitable for children under the age of 3 years of age.
- Adult assembly is required.
- When assembling the Kick-Out make sure your fingers are clear when connecting each component.
- Always check equipment for wear or damage before use. If any is found, do not use the product. If any components are missing, please contact SKLZ toll-free at 1-877-225-7275.

### ⚠️WARNING:

- If this product is used incorrectly, it can damage the product or cause harm to the user.

### CARE:

- Do not store in extremely high or low temperatures to avoid damaging or reducing the life of the product.
- Do not leave the Kick-Out outdoors for extended period of time.

### IDEA SUBMISSION


If you have an idea for a new and innovative sports training product, visit [SKLZ.com](http://SKLZ.com) to submit your concept. Some restrictions may apply.

### 1-YEAR LIMITED WARRANTY

This warranty does not cover damages resulting from accident, misuse, abuse or lost merchandise and is only valid in the USA. Need proof of purchase for warranty coverage. **Questions? Email [customerservice@sklz.com](mailto:customerservice@sklz.com) or call toll free 1-877-225-7275.**


Made in China. ©2018 Pro Performance Sports, LLC. All rights reserved. Manufactured and distributed by SKLZ/Pro Performance Sports; 2081 Faraday Avenue, Carlsbad, CA 92008 USA. SKLZ is a registered trademark of Pro Performance Sports, LLC, its subsidiaries and affiliates. Product features, appearance and specifications may be subject to change without notice. Unauthorized duplication is a violation of applicable local and international laws.

## IN THE BOX




## GETTING STARTED

### ASSEMBLE CHUTE




1. Attach the bottom left chute (A) to top left chute (C) by placing the knobs from part A into the openings in part (C). Once in place, slide them into the locking position. Repeat to connect the bottom right chute (B) and the top right chute (D).




2. Connect the two pieces that were just assembled by placing the knobs from the right side of the chute into the openings on the left side of the chute. Once in place, slide them into the locking position.

### ATTACH CHUTE TO RING



3. Place the assembled chute from the previous step around the ring (E) and twist into place.



4. Secure the chute to the ring (E) by using the ring clips (F) and screws (G). The ring clips will clip into the ring, insert screw (G) into the ring and tighten to attach the chute. Repeat on other ring clips.

### SETUP AND USE



5. Lower your height-adjustable hoop or get on a ladder. Clip the plastic hooks onto the rim from the inside with even spacing. The net will be on the inside of the Kick-Out.



6. Grab the lip at the bottom of the chute and rotate to the position you'd like the ball returned to.