

Cuisinart® Classic Stainless Kettle

ESSENTIAL PRECAUTION

Never leave your Cuisinart® Classic Stainless Kettle on high heat. A low to medium heat setting is recommended. To boil water in your kettle, a medium-high setting is sufficient. **Never set the burner on high.** Never leave your Cuisinart® Classic Stainless Kettle or any kettle empty over a hot burner. Doing so can ruin the kettle and cause damage to the stovetop.

EASY MAINTENANCE

Immediately after each use, fill the kettle with warm water and liquid dish detergent; let stand until lukewarm. Use a sponge or soft cloth to clean the inside of tea kettle. Do not use steel wool or other metal pads that make coarse scratches. Rinse thoroughly and dry immediately for a flawless finish. **Never wash your kettle in a dishwasher.**

TO REMOVE STAINS

Calcium in your water may leave a multicolored stain. This is from a harmless deposit and can be removed with a little warm vinegar.

TO REMOVE BURNER STAINS

Stains on the outside bottom (not sides) of your kettle can be removed with an oven cleaner. Follow the manufacturer's directions and spray or brush the cleaner on only the outside bottom of the kettle. If the directions call for using the cleaner in a warm oven, heat the kettle before applying the cleaner. Rinse thoroughly after cleaning.

CAUTION: Detergent fumes can be irritating. Carry out this procedure under a hood with an exhaust fan or in a well-ventilated room.

COOKING ON A GLASS STOVETOP

To avoid scratching a glass cooktop, do not slide the kettle on the glass surface. Please consult your glass cooktop manual for information and recommendations on use.

USING OVER A GAS BURNER

When heating over a gas burner, make certain the flame touches only the kettle bottom. If the flame comes up the sides, energy is wasted and the sides of the kettle may become permanently discolored.

IMPORTANT NOTE: Your Cuisinart® Classic Stainless Kettle has exceptionally high thermoconductivity, and even a low setting on some gas burners will overheat. An inexpensive gas "flame-tamer" placed between the burner and the bottom of the kettle solves this problem. Flame-tamers are readily available at most hardware stores.

BEFORE FIRST USE:

1. Remove any labels/hang tags. If your kettle has a max fill label (porcelain types), **DO NOT** remove it from the kettle.
2. Wash in warm soapy water and rinse thoroughly.

USAGE INSTRUCTIONS:

- Fill the kettle only up to the MAX FILL mark. **DO NOT OVERFILL.**
- Kettle should be placed on a burner no larger than the bottom of the kettle.
- For whistling kettles, when you hear the whistle, turn off the burner, remove the kettle from the burner, and wait for approximately 20 seconds until the water ceases to boil. **DO NOT POUR BOILING WATER.** Always use a pot holder or mitt when pouring. Handles may become hot, especially if other pots are being heated on the range.
- Do not attempt to pour from the kettle unless the lid is snapped closed/locked in place.
- Depending on where you live, some water may have excessive amounts of minerals in it. Periodically remove mineral deposits by boiling water with 2 tablespoons of baking soda and the juice of half a lemon. Do not use steel wool or harsh abrasives to clean your kettle.
- Do not place an empty kettle on a hot burner.
- **NEVER ALLOW YOUR KETTLE TO BOIL DRY.** A kettle that has been boiled dry may be damaged and should not be used. Electric burners may also be damaged when a kettle is boiled dry.
- Stainless steel kettles should be cleaned with a soft cloth. Stainless steel cleaners may be used on exterior surfaces.
- Those living in areas with high mineral content water may need to use a commercial lime removal product. Follow package directions.
- **NEVER** wash your kettle in a dishwasher.

LIFETIME WARRANTY

Subject to the exclusions and limitations contained herein, Conair LLC dba Cuisinart ("Cuisinart") warrants that the Cuisinart® Classic Stainless Kettle will be free from material defects in materials and workmanship under normal home use conditions throughout the original purchaser's lifetime, beginning on the date this Classic Stainless Kettle was purchased in its original, sealed packaging, unless otherwise specified in this Lifetime Warranty. This Lifetime Warranty is only for U.S. consumers (defined herein as purchasers at retail for personal, family, or household use) who originally purchase the Classic Stainless Kettle from Cuisinart or an authorized Cuisinart® reseller (if you are unsure whether a retailer or other point of sale is an authorized or unauthorized Cuisinart reseller, contact Cuisinart).

This Lifetime Warranty does NOT cover:

- Normal wear and tear;
- Any Classic Stainless Kettle purchased by commercial purchasers or for commercial or nonhousehold uses;
- Accessories, parts, or software added to the Classic Stainless Kettle after the system is shipped from Cuisinart;
- Any costs associated with the replacement or repair of the Classic Stainless Kettle, including labor, installation, or other costs incurred by you without prior Cuisinart approval;

- Damage to the Classic Stainless Kettle, defective conditions, or nonconformities due to: (1) external causes, including shipping, accidents, abnormal conditions (such as mechanical or environmental); (2) usage not in accordance with Classic Stainless Kettle instructions; (3) misuse, neglect, unauthorized alteration, unauthorized repair; and (4) acts of god or other events beyond Cuisinart's control;
- Though necessary repairs and maintenance might be performed by any company, damage caused by you or any nonauthorized third party may void this Lifetime Warranty;
- Damage caused by accessories or replacement parts not specifically authorized by Cuisinart, may void this Lifetime Warranty; and
- Any Classic Stainless Kettle where the original Classic Stainless Kettle identification markings (trademark or serial number) have been removed, altered, or obliterated from the Classic Stainless Kettle.

It is recommended that you visit our website, <https://www.cuisinart.com/register-your-product.html>, for a fast, efficient way to complete your Classic Stainless Kettle registration. However, Classic Stainless Kettle registration does not eliminate the need for the consumer to maintain the original proof of purchase in order to obtain the warranty benefits. In the event that you do not have proof of purchase date, the purchase date for purposes of this Lifetime Warranty will be the date of manufacture.

HASSLE-FREE WARRANTY

If the Classic Stainless Kettle that is the subject of this Lifetime Warranty fails during the warranty period for reasons covered by this Lifetime Warranty, Cuisinart will, at its option, repair the Classic Stainless Kettle, replace the Classic Stainless Kettle with another identical or reasonably equivalent Classic Stainless Kettle, or if Cuisinart is unable to repair or replace the Classic Stainless Kettle, refund the purchase price, less the amount directly attributable to the consumer's prior usage of the Classic Stainless Kettle. To obtain a return shipping label, visit us at <https://www.cuisinart.com/customer-care/product-assistance/product-inquiry/>, or call our Consumer Service Center toll-free at **1-800-726-0190** to speak with a representative.

Upon receipt of the Classic Stainless Kettle, Cuisinart will inspect the Classic Stainless Kettle and, if required under this Lifetime Warranty, attempt to repair, replace, or refund the Classic Stainless Kettle within thirty (30) days. However, there may be delays beyond Cuisinart's control, in which case that time period may be extended as reasonably necessary.

IMPORTANT: If the nonconforming Classic Stainless Kettle is to be serviced by someone other than Cuisinart's Authorized Service Center, please remind the servicer to call our Consumer Service Center at **1-800-726-0190** to ensure that the problem is properly diagnosed, the Classic Stainless Kettle is serviced with the correct parts, and the Classic Stainless Kettle is still under warranty.

CALIFORNIA RESIDENTS ONLY

The Lifetime Warranty period begins on the date the Classic Stainless Kettle was delivered, which may be different than the date the Classic Stainless Kettle was purchased. California residents also have the option of obtaining the benefits of this Lifetime Warranty by bringing the Classic Stainless Kettle to (A) the store where it was purchased or (B) another retail store that sells Cuisinart® Classic Stainless Kettles of the same type. The retail store shall then, according to its preference, either repair the Classic Stainless Kettle, refer the consumer to an independent repair facility, replace the Classic Stainless Kettle with another identical or reasonably equivalent Classic Stainless Kettle, or refund the purchase price less the amount directly attributable to the consumer's prior usage of the Classic Stainless Kettle. California residents may also, according to their preference, return a nonconforming Classic Stainless Kettle directly to Cuisinart for repair or, if necessary, replacement with another identical or reasonably equivalent Classic Stainless Kettle by calling our Consumer Service Center toll-free at **1-800-726-0190**. Cuisinart will be responsible for the cost of such repair, replacement, and/or shipping and handling for such a nonconforming Classic Stainless Kettle under warranty.

THIS LIFETIME WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS THAT VARY FROM STATE TO STATE OR BY JURISDICTION. IN THE EVENT THIS LIFETIME WARRANTY IS BREACHED, YOU MAY HAVE CLAIMS FOR REPLACEMENT, DAMAGES, OR OTHER PENALTIES.

LIMITATIONS OF LIABILITY/ADDITIONAL LIMITATIONS AND EXCLUSIONS

ALL EXPRESS AND IMPLIED WARRANTIES ARE LIMITED IN DURATION TO THE LIFETIME WARRANTY PERIOD. NO WARRANTIES APPLY AFTER THAT PERIOD. SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, SO THIS LIMITATION MAY NOT APPLY TO YOU. CUISINART'S RESPONSIBILITY UNDER THIS OR ANY OTHER WARRANTY, IMPLIED OR EXPRESS, IS LIMITED TO REPAIR, REPLACEMENT, OR REFUND, AS SET FORTH ABOVE. THESE REMEDIES ARE THE SOLE AND EXCLUSIVE REMEDIES FOR ANY BREACH OF WARRANTY. TO THE MAXIMUM EXTENT PERMITTED BY LAW, CUISINART IS NOT RESPONSIBLE FOR ANY DIRECT, INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES RESULTING FROM ANY BREACH OF WARRANTY OR UNDER ANY OTHER LEGAL THEORY (INCLUDING, BUT NOT LIMITED TO, LOST PROFITS, DOWNTIME, GOODWILL, DAMAGE TO OR REPLACEMENT OF EQUIPMENT AND PROPERTY, AND ANY COSTS OF RECOVERING, REPROGRAMMING, OR REPRODUCING ANY PROGRAM OR DATA STORED IN OR USED WITH A SYSTEM CONTAINING THE CLASSIC STAINLESS KETTLE), EVEN IF CUISINART HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATIONS OR EXCLUSIONS MAY NOT APPLY TO YOU. ALL EXPRESS AND IMPLIED WARRANTIES ARE LIMITED IN DURATION TO THE LIFETIME WARRANTY PERIOD. NO WARRANTIES APPLY AFTER THAT PERIOD. SOME STATES (OR JURISDICTIONS) DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, SO THIS LIMITATION MAY NOT APPLY TO YOU.

This Lifetime Warranty is issued by:

Conair LLC
 1 Cummings Point Road
 Stamford, CT 06902
 1-800-726-0190