












ASSEMBLY INSTRUCTIONS


DINING TABLE 76"-96" WITH LEAF

A Table Top 1pc 	B Table Leaf 1pc 	C Mounting Plate 2pcs 	D Stretcher 1pc 
E Leg 2pcs 	F Trim 2pcs 	G Bolt w/ Lock Washer & Flat Washer 5/16" x 2" Ø5/16" x 1/2" Ø5/16" x 3/4" 8sets 	H Bolt w/ Lock Washer & Flat Washer 5/16" x 4" Ø5/16" x 1/2" Ø5/16" x 3/4" 4sets 
I Bolt w/ Lock Washer & Flat Washer 1/4" x 2" Ø1/4" x 3/8" Ø1/4" x 3/4" 8sets 	J Allen Key 5/32" 1pc 		




This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.


- 1** Attach the Mounting Plate (C) to the Leg (E) using Bolt with Lock Washer & Flat Washer (G) with the Allen Key (J).




- 2** Attach the Stretcher (D) to the Leg (E) using Bolt with Lock Washer & Flat Washer (H) with the Allen Key (J). Then, attach the Leg (E) to the Table Top (A) using Bolt with Lock Washer & Flat Washer (I) with the Allen Key (J).




- 3** Attach the Trim (F) to the Leg (E).



4 Attach the Table Leaf (B) to the Table Top (A).



5 Pulling out and opening the Table Top (A) can storage the Table Leaf (B) inside the table.









Cleaning & Care

Treat surfaces with care. Surfaces are resistant to scratches but are not scratch resistant. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.

ASSEMBLY INSTRUCTIONS

DINING CHAIR


A Chair	B Front Leg	C Back Leg	D Bolt w/ Lock Washer & Flat Washer 5/16" x 2" Ø5/16" x 1/2" Ø5/16" x 3/4"
			
1pc	2pcs	2pcs	8sets
E Allen Key 5/32"			
			
1pc			



This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.

1

Attach the Front & Back Leg (B & C) to the Chair (A) using Bolt with Lock Washer & Flat Washer (D) with the Allen Key (E).



Take the Allen Key and turn the bolts until the legs are secured.

DO NOT TIGHTEN THE BOLTS COMPLETELY.

Stop when you feel you are adding force to tighten the bolts.

Stand the chair on an even surface and check for balance. If the chair wobbles slightly, apply downward pressure on the uneven leg and tighten the bolts to correct the imbalance. Once the chair is balanced, apply downward pressure evenly in the center of the chair and tighten all bolts, being careful not to over-tighten beyond the hole depth.

Helpful Tip:

While tightening the bolts from underneath, have someone sit in the chair.

Cleaning & Care

Treat surfaces with care. Surfaces are resistant to scratches but are not scratch resistant. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.