

SAFETY INFORMATION

Released Date: 2024-10-25

Please read and understand this entire manual before attempting to assemble, install or operate the product.


WARNING

- RISK OF ELECTRIC SHOCK - Before beginning installation, turn off electricity at the circuit breaker box or the main fuse box.

CAUTION

- For your safety, read instructions completely before beginning installation.
- If in doubt about electrical installation, consult a licensed electrician.

TOOLS REQUIRED




Ratings	120~277Vac, 60Hz	
	Model No.	Wattage
	PCDZ148MBK	38W
	PCDZ148SGD	38W

CARE AND MAINTENANCE


- Wipe clean using soft, dry cloth or static duster. Always avoid using harsh chemicals and abrasives to clean fixture as they may damage the finish.

If you need further assistance call Quoizel Customer Care at 1-800-645-3184 (9:00am - 5:00pm EST), or visit us on-line at www.quoizel.com.


PACKAGE CONTENTS



MOUNTING HARDWARE




1 Install Fixture Body to Cage




2 Install Rods

Optional Rods:



8 Feet Ceiling:
(2) 12"L Rods each side.
9 Feet Ceiling:
(2) 6"L Rods + (2) 12"L
Rods each side.



3 Separate Swivel Assembly




4 Install Swivels and Ceiling Canopy to Upper Rods




* Make sure two swivels
opening are in the same
direction while assembling.

5 Connect Fixture Wires to Driver




6 Install Inner Backplate



INSTALLATION


7

Install Lanyards




8

Wiring



9

Install Ceiling Canopy to Inner Backplate



Your installation is now complete! Restore electricity and save this sheet for future reference.