


ERP Table

Item	Symbol	Value	Unit	Item	Unit
Heat output				Type of heat input for electric storage local space heaters only (select one).	
Nominal heat output	P <sub>nom</sub>	1.8–2.0	kW	Manual heat charge control, with integrated thermostat.	No
Nominal heat output (indicative)	P <sub>min</sub>	0.75	kW	Manual heat charge control with room and/or outdoor temperature feedback.	No
Maximum continuous heat output	P <sub>max,c</sub>	2.00	kW	Electronic heat charge control with room and/or outdoor temperature feedback.	No
<b>Auxiliary electricity consumption</b>				Fan assisted heat output.	No
At nominal heat output	e <sub>lmax</sub>	N/A	kW	<b>Type of heat output/room temperature control (select one).</b>	
At minimum heat output	e <sub>lmin</sub>	N/A	kW	Single stage heat output an no room temperature control.	No
In standby mode	e <sub>lSB</sub>	0	kW	Two or more manual stages, no room temperature control.	No
				With mechanic thermostat room temperature control.	Yes
				With electronic room temperature control.	No
				Electronic room temperature control plus day timer.	No
				Electronic room temperature control plus week timer.	No
				<b>Other control options (multiple selections possible).</b>	
				Room temperature control, with presence detection.	No
				Room temperature control, with open window detection.	No
				With distance control option.	No
				With adaptive start control.	No
				With working time limitation.	No
				With black bulb sensor.	No

# User manual

## Convactor heater



1. Convactor heater main body
2. Carry handles
3. Adjustable thermostat
4. 750 W heat setting switch
5. 1250 W heat setting switch
6. Moulded feet



To register for your extended guarantee, scan the QR code or visit [guarantee.uppc.com/beldray](http://guarantee.uppc.com/beldray) and register your product within 30 days of purchase. For any further queries, visit [www.beldray.com](http://www.beldray.com).



**Disposal of Waste Batteries and Electrical and Electronic Equipment**

This product is labelled with this crossed out wheel bin symbol in accordance with European Directive 2012/19/EC to indicate that it must not be disposed of with your other household waste. Due to the presence of hazardous substances, mixtures or components, electrical and electronic devices that are not subject to selective sorting are potentially dangerous to the environment and human health. Please check your local city office or waste disposal service for the return and recycling of this product.

Manufactured by:  
 Ultimate Products UK Ltd.,  
 Victoria Street, Manchester OL9 0DD. **UK.**  
 Ultimate Products Europe Ltd.,  
 19 Baggot Street Lower, Dublin D02 X658. **ROI.**

**MADE IN CHINA.**  
 ©Beldray trademark. All rights reserved.  
 CD020610/MD020423/V3



Please retain instructions for future reference.



**WARNING – READ BEFORE USE** Do not leave the appliance unattended while in use. Do not use in dusty environments. Do not use heating appliances with an extension cord. The appliance must be used on a stable, heat-resistant surface. This appliance can be used for no longer than 4 hours, after which time it must be switched off. Ensure that the appliance has fully cooled down before its next use. Ensure that the appliance has at least 1 metre of free space in all directions before use. Ensure that any flammable materials, such as furniture and curtains, are at least 1 metre away from the appliance when in use.

**SAFETY INSTRUCTIONS**

- When using electrical appliances, basic safety precautions should always be followed.
- Check that the voltage indicated on the rating plate corresponds with that of the local network before connecting the appliance to the mains power supply.
- Children younger than 3 years old should be kept away from the appliance unless continuously supervised.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities and knowledge, only if it has been installed in its intended operating position and they have been supervised/instructed and understand the hazards involved.
- Children shall not play with the appliance.
- Children should not perform cleaning or user maintenance, unless they are older than 8 and supervised.
- This appliance is not a toy.
- Nominal voltage is still present in this appliance as long as the appliance is connected to the electrical source.
- If the power supply cord, plug or any part of the appliance is malfunctioning or if it has been dropped or damaged, cease using the appliance immediately to avoid potential injury.
- This appliance contains no user serviceable parts, only a qualified electrician should carry out repairs. Improper repairs may place the user at risk of harm.
- Do not allow the power cord to hang over sharp edges or come into contact with hot surfaces.
- Do not run the supply cord under carpets, rugs etc. or anywhere where it may present a trip hazard.
- Do not immerse the appliance or plug in water or any other liquid.
- Do not operate the appliance with wet hands.
- Do not use this appliance in the immediate surroundings of a bath, a shower or swimming pool.
- Do not remove from the mains power supply by pulling the cord; switch off and remove the plug by hand.
- Do not leave the appliance plugged in or operating overnight.
- Do not use the appliance for anything other than its intended use.
- Do not attempt to move the appliance whilst it is in use.
- Do not use the appliance with a programmer, timer, separate

- remote-control system or any other device that will switch the appliance on automatically, as there is a risk of fire if the heater is covered or positioned incorrectly.
- Only lift the appliance with the carry handles provided.
- The appliance should be used on a stable, heat-resistant surface.
- Do not use on carpets, rugs or other flammable floor-based textiles.
- The appliance must not be located immediately below or next to a mains power supply.
- Never use accessories that are not recommended or supplied by the manufacturer. It could cause danger to the user and damage to the appliance.
- This appliance is intended for domestic use only. It should not be used for commercial purposes.



**CAUTION:** Hot surface – do not touch the hot section or heating components of the appliance. Some parts of this appliance can become very hot and cause burns. Particular attention has to be given where children and vulnerable people are present.



**WARNING:** In order to avoid overheating, do not cover the appliance. This appliance is not equipped with a device to control the room’s temperature. Do not use this appliance in small rooms whilst occupied by persons incapable of leaving the room on their own, unless constant supervision is provided.

**Thermal cut-out device**

The convector heater is fitted with a thermal safety cut-out device, built in to prevent it from overheating. Should the convector heater start to overheat, the thermal safety cut-out system will automatically operate and the heat settings will switch off. If this happens:

- STEP 1:** Switch off the convector heater using the activated heat setting switch.
- STEP 2:** Check that convector heater is unplugged from the mains power supply and allow it to cool for approx. 15 minutes.
- STEP 3:** Clear any debris or dust from the vent, taking care not to damage the convector heater.
- STEP 4:** Plug in and switch on the convector heater at the mains power supply.



**CAUTION:** In order to avoid a hazard, due to inadvertent resetting of the thermal cut-out, the convector heater must not be supplied through an external switching device, such as a timer or connected to a circuit that is regularly switched on and off by the utility.

**Care and maintenance**

Always unplug the convector heater from the mains power supply and allow to cool sufficiently before performing any cleaning or maintenance. Wipe the convector heater with a soft, damp cloth and allow to dry thoroughly. Do not clean the convector heater with abrasive chemicals or materials such as scourers, as this may damage the convector heater and impair future function. This includes insecticide and chemical solvents.

**Instructions for use**

**Before first use**

- STEP 1:** Check that there is no damage to the convector heater.
- STEP 2:** Attach the two moulded feet to the bottom of the convector heater using the four small screws provided.
- STEP 3:** Position the convector heater on a flat, stable, heat-resistant surface in an open space, at least 1 metre away from furniture, curtains or any other flammable materials. Do not block the air intake on the back of the convector heater.



**NOTE:** When using the convector heater for the first time, a slight odour may be emitted. This is normal and will soon subside. Allow for sufficient ventilation around the convector heater.

**Using the convector heater**

- STEP 1:** Plug in and switch on the convector heater at the mains power supply.
- STEP 2:** To turn on the convector heater, turn the adjustable thermostat to the maximum setting.
- STEP 3:** Operate the convector heater on a low heat setting by flicking the 750 W heat setting button.
- STEP 4:** For a medium heat setting, press the 1250 W heat setting button.
- STEP 5:** Flick both of the heat setting switches to operate the convector heater on the highest heat setting (2000 W).
- STEP 6:** When the desired temperature has been reached, turn the adjustable thermostat in an anticlockwise direction until it clicks and the lights on the heat setting switches turn off. The heater will cycle on and off to maintain the temperature of the room.
- STEP 7:** Turn off the convector heater by flicking any active power switches.



**NOTE:** The corresponding heat indicator light will illuminate whilst the convector heater is warming up and will cycle on and off during use to show that the correct temperature is being maintained.

**Storage**

Check that the convector heater is completely cool before storing in a cool, dry place. Never wrap the cord tightly around the convector heater; wrap it loosely to avoid causing damage.

**Specifications**

Product code: EH3334  
Voltage: 220–240 V ~ 50 Hz  
Power: 2000 W