

Deluxe 5-in-1 Sit, Snack & Go Convertible Booster Seat

B0060 User Guide

Suitable for children capable of sitting upright unassisted to 4 years old, up to 50 lbs. (22.7 kg).

- Booster Seat fits most kitchen and dining room chairs with a minimum measurement of 16" W x 15.5" D and backrest height of 8" H.



⚠ WARNING

Children have suffered **head injuries**, including skull fractures, after falling with or from booster seats.

- Check that booster seat is **securely attached** to adult chair before each use.
- **ALWAYS** use restraints until child is able to get in and out of booster seat without help. Adjust to fit snugly.
- **NEVER** allow child to **push away** from table.
- **NEVER** lift and **carry** child in booster seat.
- Stay near and **watch** your child during use.
- **NEVER** adjust the booster height with child in it.
- **ALWAYS** fasten seat and back straps securely to adult chair.
- **ALWAYS** ensure that all chair protector pads are located completely on the adult chair surface.
- This booster seat is only to be used with standard kitchen or dining room chairs. **NEVER** use this product as a bath seat, on a tabletop, stool, swivel chair, or any other seating surface where the straps cannot secure it properly.
- Until child is able to get in and out of the booster seat without help (about 2 1/2 years old), the child should be secured in the booster seat at all times by the restraining system. The tray is not designed to hold the child in the chair.
- Use this product only for children capable of sitting upright unassisted.
- Prevent serious injury or death. **DO NOT** use in motor vehicles.


- Tray made without BPA.
- Remove all contents from packaging and discard box, and/or poly bags.
- Lay out and identify all parts.
- Please do not return this product to the place of purchase. To address any issues, please visit us at www.safety1st.com to chat. You can also text us at (812) 652-2525 or call Consumer Care at (800) 544-1108. Please provide the model number (B0060) and manufacture date, located on the underside of the booster seat base.

• **Before Assembly:** Wipe down trays with a soft cloth and warm soapy water.

- **Discontinue use if damaged, broken, or if parts are missing.**

Parts List

- | | |
|----------|-----------------------------|
| A | Tray |
| B | Seat Back |
| C | Booster Seat |
| D | Restraint Straps and Buckle |
| E | Legs (2) |
| F | Arm Rests (Left and Right) |
| G | Chair Straps (2 Sets) |
| H | Seat Pad |



Lista de piezas



- | | |
|----------|-------------------------------|
| A | Charola |
| B | Respaldo |
| C | Asiento elevador |
| D | Correas de sujeción y hebilla |
| E | Patas (2) |
| F | Apoyabrazos (left and right) |
| G | Correas de la silla (2 sets) |
| H | Almohadilla del asiento |

To Assemble

1 Booster Seat:

Lift the seat back to the upright position (**Figure 1a**).

Press the seat back down into slots until it locks into place (**Figure 1b**).



1

Asiento elevador:

Levante el respaldo del asiento hasta la posición vertical (**Figura 1a**).

Presione el asiento hacia abajo en las ranuras hasta que encaje en su lugar (**Figura 1b**).

DOREL

To Assemble (continued)

2 Chair Straps:


Snap the buckles together (**Figure 2a**).

Make sure the "loop" on the chair straps is facing outward and threaded in the buckle as shown (**Figure 2b**).



With the buckle "loop" facing outward, insert the sewn ends of the chair straps into the slots on the back of the booster (**Figure 2c**).

With the buckle "loop" facing outward, insert sewn ends of chair straps into the slots on the sides of the booster (**Figure 2d**).

Pull each strap to ensure strap is secure. Chair straps should not come out when pulled (**Figure 2e**).



2d




3 Adjust Height (Up):

Turn booster over.

To release each leg lock: Pull the lock back and lift each leg up to the vertical position (**Figure 3a**).

Press each leg down into position until they lock into place (**Figure 3b**).



⚠ CAUTION

To prevent falls or tipping over:

- **ALWAYS** remove child before adjusting booster seat.
- **ALWAYS** ensure height adjustments are set to the same height.

3 Cómo subir el asiento:

Retire la charola y saque al niño del asiento. Voltee el asiento.

Cómo soltar las trabas de pata: Tire de la traba hacia atrás y levante cada pata hasta la posición vertical (**Figura 3a**).

Empuje cada una de las patas hacia abajo hasta que se trabe en posición (**Figura 3b**).


⚠ PRECAUCIÓN

Para evitar caídas o vuelcos:

- **SIEMPRE** retire al niño antes de ajustar el asiento elevador.
- **SIEMPRE** compruebe que los ajustes de altura estén configurados a la misma altura.

Adjust Height (Down):

To store legs, pull up on the leg to unlock. Fold the leg down into the booster seat until it's secured by the leg lock (**Figure 3c**).




Cómo bajar el asiento:

Para guardar las patas, tire de la pata hacia arriba para desbloquearla. Rote la pata hacia abajo en el asiento elevador hasta que quede asegurada por el bloqueo de la pata (**Figura 3c**).

4 Seat Pad:

Pull the back of the seat pad over seat back. Unbuckle the restraint. Pull the center restraint through the front slot. Pull sides of restraint through the back slot (**Figure 4**).



To remove, unbuckle the restraint and route them through the slots in the seat pad. Pull the seat pad over the seat back and off the booster.


4 Almohadilla del asiento:

Tire de la parte posterior de la almohadilla para colocarla sobre el respaldo del asiento. Desabroche la correa de retención. Tire de la correa central de retención a través de la ranura delantera. Tire de las correas laterales de retención a través de la ranura posterior (**Figura 4**).

Para quitárla, desabroche el sistema de sujeción y páselo por las ranuras de la almohadilla del asiento. Tire de la almohadilla del asiento hacia atrás y fuera del asiento elevador.

5 Modes that Grow with Your Child

- 1 Full seat with armrests and tray
 - 2 Full seat with armrests without tray
 - 3 Full seat without armrests
 - 4 Backless seat with armrests
 - 5 Backless seat without armrests
- NOTE:** Height adjustment is optional in any mode.



To Use

1 Chair Straps:


Pass the bottom chair strap completely under the base of the chair and secure the buckle (Figure 1a). Adjust the chair strap snugly against the chair.

Pass the rear chair strap around the back of the chair and secure the buckle (Figure 1b). Adjust the chair strap snugly against the chair.

WARNING


Children have suffered head injuries, including skull fractures, after falling with or from booster seats.

- **ALWAYS** use both sets of chair straps to completely secure booster to the chair.
- If chair is cushioned and cushion cannot be removed, **BECERTAIN** that the bottom chair strap is fastened snugly after putting child in seat.
- Make sure all pieces are assembled correctly. Test for proper assembly before placing child in seat.
- **ALWAYS** secure child in booster seat using restraint straps.



2 Restraint System:

Position your child in the booster seat. Place the center restraint straps between your child's legs and buckle into position (Figure 2a). Adjust the restraint straps to fit snugly (Figure 2b).



3 Tray:


The tray has three positions to accommodate your growing child. Align the tray with the tabs on arm rests as desired and press the tray down until it snaps into place. Pull on the tray to ensure that it is completely engaged (Figure 3).

To remove tray: Pull handle on one side of the tray and lift off booster seat.

TIP: For toddlers, remove the tray and your toddler can begin using the table.

WARNING

The tray is not a restraint device. **ALWAYS** use restraint straps to secure child in booster seat.



5 modos de crecer con su hijo

- 1 Asiento completo, con apoyabrazos y charola
 - 2 Asiento completo, con apoyabrazos y sin charola
 - 3 Asiento completo, sin apoyabrazos
 - 4 Asiento sin respaldo, con apoyabrazos
 - 5 Asiento sin respaldo y sin apoyabrazos
- NOTA:** El ajuste de altura es opcional en cualquier modo.

Cómo utilizar

1 Correas de la silla:


Pase la correa inferior de la silla completamente debajo de la base de la misma y ajuste la hebilla (Figura 1a). Ajuste la correa de la silla firmemente contra la silla.

Pase la correa trasera de la silla alrededor del respaldo de la misma y ajuste la hebilla (Figura 1b). Ajuste la correa de la silla por seguridad. Ajuste la correa de la silla firmemente contra la silla.

ADVERTENCIA


Algunos niños han sufrido lesiones en la cabeza, incluso fracturas de cráneo, por caer con o de asientos elevadores.

- **SIEMPRE** use ambas correas de la silla para asegurar completamente el asiento elevador a la silla.
- Si la silla es acolchada y el cojín no puede quitarse, **ASEGÚRESE** de que la correa inferior de la silla esté ajustada firmemente luego de colocar al niño en la silla.
- Asegúrese de que todas las piezas estén armadas correctamente. Antes de sentar al niño, controle el armado de la silla.
- **SIEMPRE** asegure al niño en el asiento elevador utilizando las correas de retención.



2 Sistema de retención:

Coloque al niño en el asiento elevador. Coloque las correas de sujeción centrales entre las piernas de su hijo y abróchelas en su posición (Figura 2a). Ajuste las correas de sujeción para que se ajusten bien (Figura 2b).



3 Charola:

La charola tiene tres posiciones, lo que permite adaptar el asiento al tamaño del niño. Alinee la charola con las lenguetas en los apoyabrazos como deseé y presiónela hacia abajo hasta que se encuele en posición. Tire de la charola para asegurarse de que esté completamente encuajada (Figura 3).

Para extraer la charola: Jale de la manija al costado de la charola y levante el asiento.

CONSEJO: Para niños pequeños, retire la charola a fin de permitir que utilicen la mesa.

ADVERTENCIA


La charola no es un dispositivo de retención. **SIEMPRE** utilice las correas de retención para asegurar al niño en el asiento elevador.

To Use (continued)

4 Arm Rests:

To remove, press the button in the hole on the back of the booster and pull the back post up (Figure 4a). Slightly twist the arm rest and pull out the front post (Figure 4b).


To reattach, position the arm rests with the buttons at the back and the three tray tabs facing out (Figure 4a). Press button on post and push arm posts down into holes until it clicks.



Cómo utilizar (continuación)


4 Apoyabrazos:

Para retirarlos, presione el botón en el orificio de la parte posterior del asiento elevador y tire hacia arriba (Figura 4a). Gire ligeramente el reposabrazos y extraiga el poste delantero (Figura 4b).



5 Respaldo:


Para quitarlo, tire del asiento hacia atrás y hacia arriba para desbloquearlo y empújelo hacia atrás hasta que las pestañas salgan de la ranura (Figura 5a).



Travel and Storage

Fold Booster:

- 1 Remove the tray.
- 2 Unbuckle the chair straps and remove the booster seat from the dining chair.
- 3 Pull up the seat back to unlock it and fold it into the booster seat.
- 4 Turn booster seat upside down and fold the legs inward. Press the legs down to engage the lock (Figure 1a).
- 5 Align the tray with the tabs on the arm rests in reversed position and press tray down until it snaps into place (Figure 1b).
- 6 Buckle the side chair straps and tighten straps (Figure 1b).
- 7 Buckle the back chair straps and use them as a shoulder strap (Figure 1c).



Viajes y almacenamiento

Cómo plegar el asiento elevador:

- 1 Retire la charola.
- 2 Desabroche las correas de la silla, retire el asiento elevador de la silla para comer.
- 3 Levante el respaldo del asiento para desbloquearlo y plegarlo en el asiento elevado.
- 4 Voltee el asiento y pliegue las patas. Presione las patas hacia abajo para tratarlas (Figura 1a).
- 5 Alinee la bandeja con las lenguetas de los reposabrazos en posición invertida y presione la bandeja hacia abajo hasta que encaje en su lugar (Figura 1b).
- 6 Abroche las correas laterales de la silla y ajústelas (Figura 1b).
- 7 Abroche las correas posteriores y úselas como correa de hombro (Figura 1c).

To Clean

Booster, Tray, and Seat Pad:

Clean before first use and after each use. Wipe with soft cloth and warm soapy water and drip dry. Use only mild non-abrasive soap. Tray is dishwasher safe for rinse cycle only.

Para limpiar

Asiento elevador, charola y almohadilla del asiento: Lávelo antes de utilizarlo por primera vez y después de cada uso. Limpie con un paño suave y agua jabonosa templada y déjelo secar. Use únicamente un jabón suave y no abrasivo. La charola puede lavarse en lavavajillas, únicamente en el ciclo de enjuague.