



- 1 Put the Chair Body (A) on a smooth flat surface, attach Front Leg (D) to the Chair Body (A) using Bolt (I), Lock Washer (G) and Flat Washer (H) on both holes of Chair Body (A) by Allen Key (J). Turn the Allen Key (J) in Bolt (I). But not too tight.



Take the Allen Key, and turn the bolts until the legs are secure. **DO NOT TIGHTEN COMPLETELY.** Stop when you feel you are adding force to tighten the bolt.

- 2** Then attach the Left Back Leg (E) & Right Back Leg (F) to the Chair Body (A) using Bolt (I), Lock Washer (G), Flat Washer (H) in both holes of Left Back Leg (E) & Right Back Leg (F) and Chair Body (A). Turn the Allen Key (J) in Bolt (I).

Stand chair up on an even surface and check that it is balanced. If there is a slight wobble, apply downward pressure in the corner where a leg is uneven. Keeping pressure in that corner, tighten all bolts. If balanced, apply downward pressure evenly in the center and tighten all bolts. Do not over-tighten beyond hole depth.



Helpful Tip:
-Instead of applying downward pressure while reaching under to tighten bolts, have someone sit in the chair while you tighten the bolts.

Turn left or turn right to adjust the leveler until the chair is stabilized.

Cleaning & Care

Treat surface with care. Surface is resistant to scratches but is not scratch resistant. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.