



BEST CHOICE
PRODUCTS



INSTRUCTION MANUAL

2-Piece Pre-Lit
Polar Bear Family

! NOTICE

Please retain these instructions for future reference.

- This product is intended for outdoor use and should be assembled outdoors only.
- This item is not intended for permanent installation or use.
- Unplug item when not in use or if left unattended.
- Ensure that your voltage is consistent with specifications.
- If any parts are missing, broken, damaged, or worn, stop using this product until repairs are made and/or factory replacement parts are installed.
- Do not use this item in a way inconsistent with the manufacturer's instructions as this could void the product warranty.
- This set includes two figures: one cub and one mother.



1 PERSON
ASSEMBLY






UP TO 30 MIN.
ASSEMBLY









! WARNING

- Do not plug into a wall outlet until item is fully assembled and lights are properly connected.
- Do not use in extreme weather conditions.
- This product contains glitter, do not assemble indoors to avoid unintended property damage and cleanup.
- Do not allow glitter to contact your eyes or face as this may result in skin irritation or injury.
- Keep item away from all heat sources (fireplace, stove, heater, etc.).
- Please use the provided stakes to properly secure the figures.
- Do not secure wiring with staples, nails, or sharp hooks.
- Do not hang ornaments or other objects from the cord.
- Unplug item before removing or changing bulbs.
- Replace burned-out bulbs immediately. Make sure to purchase bulbs of the same rated voltage and wattage.

HARDWARE



PARTS




Separate each part. Carefully remove any protective wrap. Do not use a knife as this may damage essential parts or light bulbs.

PRODUCT ASSEMBLY

1


Attach the part B upper body to the part C lower body by inserting the two prongs on the lower body into the lots on the upper body.

Thread the two knobs on the front of the bear body through the locks on the lower body and secure with two part 1 cotter pins.



2

Insert one part F tail into the part C lower body.




PRODUCT ASSEMBLY

3

Attach the part A head to the part B upper body by inserting the two prongs on the base of the head into the openings on the upper body.


Thread the wire knob through the lock on the front of the upper body and secure with one part 1 cotter pin.



4

Attach the part D & E legs to the part B upper body and secure with two part 3 zip ties


Connect the two legs by inserting the attached "L" bar on the part D right leg into the slot on the part E left leg.



PRODUCT ASSEMBLY

5


Wrap one part H scarf around the neck of the bear figure, then secure to the ground with four part 2 stakes. Plug into a wall outlet to turn on the lights.



6

Locate the part G bear cub figure and wrap one part H scarf around the neck of the bear figure, then secure to the ground with two part 2 stakes. Plug into a wall outlet to turn on the lights.

Plug into a wall outlet to turn on the lights.



TROUBLESHOOTING


PROBLEM	REASON	SOLUTION
One section does not light	Broken or loose bulb	Inspect bulbs individually and replace broken bulbs
Lights do not work	Not plugged in	Firmly plug into wall outlet
	Extension cord does not have power	Plug in/turn on extension cord
	Broken or loose bulb	Inspect bulbs individually and replace broken bulbs
	Blown fuse	Replace fuse on plug

LIGHT SPECIFICATIONS


BULB TYPE(S)	BULB SIZE	WATTAGE	VOLTAGE	WHAT IF 1 BULB BREAKS
LED	5MM	0.07W	3.6V	The entire string of lights up to that point will shut off

CHANGING BROKEN LIGHTS


Unplug the product from power supply.



1
Locate the defective light and grip the plastic housing.



2
Pull straight up to remove. Do not pull or twist the glass bulb.



3
Push the new bulb straight in, making sure the tab on the bulb's collar (+) sits opposite to the tab on the receiver (-).



HELP CENTER



Question about your product? We're here to help. Visit us at:

help.bestchoiceproducts.com



Chat Support



Product Inquiry



Orders FAQ



Product Assembly



Returns & Refunds

PRODUCT WARRANTY INFORMATION

All items can be returned for any reason within 60 days of the receipt and will receive a full refund as long as the item is returned in its original product packaging and all accessories from its original shipment are included. All returned items will receive a full refund back to the original payment method. All returned items will not be charged a re-stocking fee.

All returned items require an RA (Return Authorization) number, which can only be provided by a Best Choice Products Customer Service Representative when the return request is submitted. Items received without an RA may not be accepted or may increase your return processing time. Once an item has been received by Best Choice Products, refunds or replacements will be processed within 5 business days.

All returns must be shipped back to the Best Choice Products Return Center at the customer's expense. If the reason for return is a result of an error by Best Choice Products then Best Choice Products will provide a pre-paid shipping label via email. Boxes for return shipping will not be provided by Best Choice Products, and is the customer's responsibility to either use the original shipping boxes or purchase new boxes.

Pictures may be required for some returns to ensure an item is not damaged prior to its return. Items returned are not considered undamaged until they are received by Best Choice Products and verified as such. All damages to items are the customer's responsibility until the item has been received by and acknowledge by Best Choice Products as undamaged.

WARNING

Manufacturer and seller expressly disclaim any and all liability for personal injury, property damage or loss, whether direct, indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, unapproved modification, or neglect of this product.