












ASSEMBLY INSTRUCTION

E376B TUFTING UPHOLSTERED HEADBOARD


A Headboard	B Left Wooden Frame	C Right Wooden Frame	D Wooden Leg	E Bolt 1/4" x 78mm
				
1pc	1pc	1pc	2pcs	2pcs
F Bolt 1/4" x 65mm	G Flat Washer	H Lock Washer	I Allen Wrench	J Slate
				
10pcs	12pcs	12pcs	1pc	2pcs



This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.


1

Attached Left Wooden Frame (B) and Right Wooden Frame (C) to the Headboard (A) use Bolt (F), Lock Washer (H) and Flat Washer (G) on holes of Slates (J). Turn the Allen Wrench (I) in Bolt (F).



2

Attached Wooden Leg (D) to the Wooden Frame (B) (C) use Bolt (E), Lock Washer (H) and Flat Washer (G) on both of holes. Turn the Allen Wrench (I) in Bolt (E).















Cleaning & Care

Treat surface with care. Surface is resistant to scratches but is not scratch resistant. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.

ASSEMBLY INSTRUCTION

E376B FULL & QUEEN TUFTING UPHOLSTERED FOOTBOARD & SIDE RAIL & REGULAR SLAT


A Footboard	B Side Rails	C Wooden Leg	D Support Leg	E Wooden Slat
				
1pc	2pcs	2pcs	6pcs	3pcs
F Screw	G Bolt 1/4" x 75mm	H Bolt 1/4" x 50mm	I Flat Washer	J Lock Washer
				
12pcs	2pcs	6pcs	8pcs	8pcs
K Allen Wrench				
				
1pc				



This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.


1

Attached Wooden Leg(C) to the Footboard(A) use Bolt(G), Lock Washer(J) and Flat Washer(I) on both of holes. Turn the Allen Wrench(K) in Bolt(G).




2

Attached Side Rail(B) to the Headboard and Footboard(A).



3

Assembly Support Leg (D) to Wooden Slats(E) use Bolt(H), Lock Washer(J) and Flat Washer(I) by Allen Wrench(K). Assembly Wooden Slats(E) to Side Rail(B) use Screw (F) as showing.



Cleaning & Care

Treat surface with care. Surface is resistant to scratches but is not scratch resistant. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.