


ASSEMBLY INSTRUCTION


END TABLE WITH SHELF

A Top Frame




1pc

B Leg




4pcs

C Wood Top



1pc

D Bottom Frame




1pc

E Glass Bottom




1pc

F Bolt
1/4" x 1/2"




8pcs

G Bolt
1/4" x 7/8"



8pcs

H Leveler
1/4" x 7/8"



4pcs

I Pad
10mm x 1mm




4pcs

J Allen Wrench
1/4"



1pc




This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.

***** Do not tighten screws & bolts until the entire unit is completely assembled.**


1

Attach Leg (B) to Top Frame (A) by using Bolt (F) and Allen Wrench (J) as shown.




2

Attach the assembled frame to Wood Top (C) by using Bolt (G) and Allen Wrench (J) as shown.




3

Attach Bottom Frame (D) by using Bolt (G) and Allen Wrench (J), then insert the Leveler (H) as shown.

**4**

Turn the assembled unit up. Put the Pad (I) and place Glass Bottom (E) on the Bottom Frame (D) as shown.



Cleaning & Care

Treat surfaces with care. Surfaces are resistant to scratches but are not scratch resistant. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.