

INSTRUCTION MANUAL

10-Foot Solar LED Patio Umbrella

SKY3297 + SKY3298 + SKY3435 + SKY3788 + SKY3789 + SKY3790 SKY3791 + SKY3792 + SKY4042 + SKY4043 + SKY4044 + SKY5013 SKY5846 + SKY6406 + SKY6407 + SKY6707 + SKY6708 + SKY7420 SKY7424 + SKY7425 + SKY7712 + SKY7713 + SKY7714 + SKY7715 SKY7716 + SKY7717 + SKY7718 + SKY7719



Solar panel requires 6 to 7 hours of direct sunlight to fully charge.



Do not use without umbrella base weights.

Recommended Weight: >100 lbs.

bestchoiceproducts.com



Please retain these instructions for future reference.


- This product is intended for residential use only.
- Umbrella stand is not included. Do not use this umbrella without an umbrella stand.
- · Umbrella is suitable for rain showers and light wind.
- Do not use umbrella in inclement weather, such as snow, heavy rain, thunderstorms, or strong wind.
- · Always remove umbrella from its stand/table when not in use.
- If using the umbrella with a table, make sure the plastic umbrella ring is inserted into the hole in the center of the table.
- If any parts are missing, broken, damaged, or worn, stop using this product until repairs are made and/or factory replacement parts are installed.
- Do not use this item in a way inconsistent with the manufacturer's instructions as this could void the product warranty.


BATTERY WARNINGS

The following safety hazards may result in serious injury or death:

- Do not mix alkaline, standard (Carbon Zinc) and rechargeable (Nickel Cadmium, Nickel Metal Hydride, or Lithium Ion) batteries.
- To optimize lifespan, remove battery from product if it will not be used for an extended period of time.
- · Do not mix old and new batteries.
- Do not attempt to charge non-rechargeable batteries as this may result in rupture or leakage and cause personal injury or property damage.
- Battery installation, replacement, or charging should be handled by adults.
- Exhausted batteries should be removed and disposed of in accordance with local, state, and federal regulations.
- The supply terminals should not be short-circuited.
- Do not put batteries next to or in a heat source (fire, electronic heating device, etc.)
- Do not hit batteries against hard objects.
- · Do not submerge batteries in water.
- Batteries should be inserted with the correct polarity (+ -).

PARTS








BEFORE FIRST USE

- 1. Hold the part A umbrella upside down and shake gently to separate the umbrella ribs. If necessary, carefully pull the ribs apart to free them.
- 2. Slowly turn the crank to open the umbrella. Make sure that the ribs are not stuck together.

CHARGING THE LIGHTS

- Solar panel requires 6 to 7 hours of direct sunlight to fully charge.
- · LED lights last for 6 to 7 hours on a single charge.
- If lights are not working, fully charge the solar panel and try again.

PRODUCT ASSEMBLY







Unscrew the solar panel

Insert the battery connector.

Replace the solar panel.


Insert the umbrella into an umbrella stand (not included).

2 Firmly insert the part A umbrella into the part B pole until it locks in place.

PRODUCT ASSEMBLY




Slowly turn the crank to open the umbrella canopy. Press the button to adjust the tilt to your desired position *(see Tilt Mechanism Use)*. Press power switch to turn on LED lights.




TILT MECHANISM USE

- 1. Locate and gently push the lock button, then tilt the umbrella canopy to your desired position.
- 2. Release the button and continue to tilt until satisfied; the button will automatically lock.



MARNING

• This system uses a **press & release** lock system. Do not hold the button down when in use as this will prevent the lock from engaging and damage the lighting features.



CLEANING AND STORAGE

- Wipe clean with mild detergent, warm water, and a soft cloth.
- Do not use abrasive materials or cleaners.
- Store in a dry area shielded from the weather.
- If necessary, cover with a furniture cover or tarp.



Question about your product? We're here to help. Visit us at:

help.bestchoiceproducts.com











Product Assembly



Returns & Refunds

PRODUCT WARRANTY INFORMATION

All items can be returned for any reason within 60 days of the receipt and will receive a full refund as long as the item is returned in its original product packaging and all accessories from its original shipment are included. All returned items will receive a full refund back to the original payment method. All returned items will not be charged a re-stocking fee.

All returned items require an RA (Return Authorization) number, which can only be provided by a Best Choice Products Customer Service Representative when the return request is submitted. Items received without an RA may not be accepted or may increase your return processing time. Once an item has been received by Best Choice Products, refunds or replacements will be processed within 5 business days.

All returns must be shipped back to the Best Choice Products Return Center at the customer's expense. If the reason for return is a result of an error by Best Choice Products then Best Choice Products will provide a pre-paid shipping label via email. Boxes for return shipping will not be provided by Best Choice Products, and is the customer's responsibility to either use the original shipping boxes or purchase new boxes.

Pictures may be required for some returns to ensure an item is not damaged prior to its return. Items returned are not considered undamaged until they are received by Best Choice Products and verified as such. All damages to items are the customer's responsibility until the item has been received by and acknowledge by Best Choice Products as undamaged.

© Best Choice Products, Inc. All rights reserved. Distributed by Best Choice Products, Inc. Tustin, CA 92780

△WARNING

Manufacturer and seller expressly disclaim any and all liability for personal injury, property damage or loss, whether direct, indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, unapproved modification, or neglect of this product.