

Lumination® Tela

Hexcel Louver Accessory



BEFORE YOU BEGIN

Read these instructions completely and carefully.

FOR USE WITH CEILING MOUNTED TRACK ONLY.

READ TRACK MANUFACTURER'S INSTALLATION INSTRUCTIONS FOR GUIDELINES ON TRACK INSTALLATION.

WARNING

RISK OF ELECTRIC SHOCK

Turn power off before inspection, installation or removal.

SKU	Material Description	Product Description
93047407	LHLHX	LHL HEXCEL LOUVER
93047410	LHSHX	LHS HEXCEL LOUVER
93047413	LHMHX	LHM HEXCEL LOUVER

IMPORTANT SAFETY INSTRUCTIONS


When installing or using this track system, basic safety precautions should always be followed, including the following:

- Read all instructions
- Do not install this track in damp or wet locations.
- Do not cut any track sections.
- Do not install any part of a track system less than 5 feet above the floor.
- Do not install any luminaire assembly closer than 6 inches from any curtain, or similar combustible material.
- Disconnect electrical power before adding to or changing the configuration of the track.
- Do not attempt to energize anything other than lighting track luminaires on the track. To reduce the risk of fire and electric shock, do not attempt to connect power tools, extension cords, appliances, and the like to the track.
- Do not connect a track to more than one branch circuit unless the track is constructed so that it can be used with more than one branch circuit. Check with a qualified electrician. Although the track lighting system may seem to operate acceptably, a dangerous overload of the neutral may occur and result in a risk of fire.


SAVE THESE INSTRUCTIONS

For future reference when adding fixtures or changing the track configuration.


Installation of Hexcel Louver on the LHX Series Track Light




1 Begin with fixture disconnected from the track.




2 Unscrew the top of the fixture and remove the optic and retaining ring.



3 Place the hexcel louver inside the cap so that it rests on the inner lip of the cap.



4 Replace the optic and retaining ring inside the cap.



5 Replace the cap and retaining ring inside the cap.