



# Oxivir® Five 16 Concentrate

# 57

## One-Step Disinfectant Cleaner

Dilutable, one-step disinfectant cleaner formulated with proprietary Hydrogen Peroxide technology.

### Features & Benefits

- One-step disinfectant cleaner powered by Accelerated Hydrogen Peroxide® (AHP®) technology
- Disinfects in just 5 minutes with no VOCs, no added fragrance and no NPEs
- Effective against Human Immunodeficiency Virus (HIV-1 (AIDS Virus)), Hepatitis C Virus, Poliovirus, Avian Influenza A, *Pseudomonas aeruginosa*, *Staphylococcus aureus*, *Methicillin-resistant Staphylococcus aureus (MRSA)*, *Salmonella enterica*, and *Vancomycin-resistant Enterococcus faecium (VRE)*
- Kills Norovirus and Canine Parvovirus and is compatible with most hard, non-porous surfaces
- Environmentally responsible-active ingredient breaks down to oxygen and water after use

### Applications

- Clean and disinfect high-touch surfaces in 5 minutes



\* Note: not recommended for floors at disinfectant strength (1:16).





# Oxivir® Five 16 Concentrate

## One-Step Disinfectant Cleaner

### Use Directions:\*

- Spray surfaces and let solution remain on surface for a minimum of 5 minutes
- Air Dry, wipe surfaces to dry and remove any residue, or rinse with potable water as necessary
- Prepare a fresh solution if the solution becomes visibly dirty or diluted

### Dilutable Disinfectant Cleaner

- 1:16 dilution – Virucidal, Bactericidal, and Fungicidal, including antibiotic resistant bacteria, in 5 minutes
- 1:128 dilution – Non-food contact sanitizer in 3 minutes or general purpose cleaning
- 1:256 dilution – Floor and general purpose cleaner

Note: Rinsing is not necessary unless floors are coated with finish or restorer.

All food contact surfaces must be rinsed with potable water. Do not use on glassware, utensils or dishes. Prior to first use on a particular surface, it is recommended to test in a small, discreet area if there is concern of incompatibility, or contact a Diversey representative.

\* Not recommended for floors at dilution 1:16. Refer to product label for complete use instructions.

| Technical data | Oxivir® Five 16 Concentrate                  |
|----------------|--|
| EPA Reg. No.   | 70627-58                                     |
| Color          | Colorless, liquid                            |
| pH             | 1.0 (Concentrate)<br>1.9 (Use Dilution 1:16) |
| Scent          | Characteristic of ingredients                |
| Shelf Life     | 3 Years                                      |

| Product                     | Pack size                                     | Dilution                                   | Product code |  |
|-----------------------------|---|--|--------------|--|
| Oxivir® Five 16 Concentrate | 4 x 1 gallon / 3.78 L Containers              | 1:16, 1:64, 1:128, 1:256                   | 4963314      |  |
| Oxivir® Five 16 Concentrate | 2 x 2.5 L / 84.5 oz. J-Fill® Bottles          | 1:16                                       | 4963331      |  |
| Oxivir® Five 16 Concentrate | 2 x 1.5 L / 1.59 Qt. RTD® Units (Fill)        | 1:16, 1:64, 1:128, 1:256                   | 4963357      |  |
| Oxivir® Five 16 Concentrate | 2 x 1.4 L / 1.48 Qt. SmartDose™ Bottles       | 1:16 (Spray Bottle),<br>1:256 (Mop Bucket) | 5019296      |  |
| Oxivir® Five 16 Concentrate | 2 x 1.5 gallon / 5.67 L Command Center® Units | 1:16, 1:64, 1:128, 1:256                   | 5271361      |  |
| Oxivir® Five 16 Concentrate | 12 x 32 oz. / 946 mL Empty Spray Bottles      |  | D1222663     |  |
| Oxivir® Five 16 Concentrate | 1 x 5 gallon Container                        | 1:16, 1:64, 1:128, 1:256                   | 101104070    |  |
| Oxivir® Five 16 Concentrate | 1 x 55 gallon Drum Container                  | 1:16, 1:64, 1:128, 1:256                   | 101104069    |  |

### SmartDose™ Icons



### Safe handling

Please make sure your employees read and understand the product label and Safety Data Sheet before using this product. The label contains directions for use; and both the label and SDS contain hazard warnings, precautionary statements and first aid procedures. SDS are available online at [www.diversey.com](http://www.diversey.com) or by calling 888.352.2249. Improper use or dilution may result in damage to surfaces and may result in health and physical hazards that match those of the concentrate.

AHP® and Design are trademarks of Diversey, Inc.

[www.diversey.com](http://www.diversey.com)

© 2020 Diversey, Inc. All Rights Reserved. PSS750 (20/127)